



REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
20 FUEGO LT 1000-XH	S4010JE	1	6Q376801	DRAG KNOB
20 FUEGO LT 1000-XH	S4010JE	2	6Q346101	DRAG RING
20 FUEGO LT 1000-XH	S4010JE	3	6Q621901	DRAG DISC WASHER
20 FUEGO LT 1000-XH	S4010JE	4	6J678901	ATD WASHER ASSY (1pack-1 pcs)
20 FUEGO LT 1000-XH	S4010JE	5	-----	-----
20 FUEGO LT 1000-XH	S4010JE	6	6Q697001	SPOOL ASSY (2-5)
20 FUEGO LT 1000-XH	S4010JE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 1000-XH	S4010JE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 1000-XH	S4010JE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 1000-XH	S4010JE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 1000-XH	S4010JE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 1000-XH	S4010JE	12	6Q797701	CLICK LEAF SPRING
20 FUEGO LT 1000-XH	S4010JE	13	6Q798201	CLICK HOLDER
20 FUEGO LT 1000-XH	S4010JE	14	6Q344001	CLICK HOLDER WASHER
20 FUEGO LT 1000-XH	S4010JE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 1000-XH	S4010JE	16	6Q177001	ROTOR NUT
20 FUEGO LT 1000-XH	S4010JE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 1000-XH	S4010JE	18	6Q139543	ROTOR
20 FUEGO LT 1000-XH	S4010JE	19	6H443301	KICK LEVER SPRING
20 FUEGO LT 1000-XH	S4010JE	20	6Q139601	KICK LEVER
20 FUEGO LT 1000-XH	S4010JE	21	6H417701	KICK LEVER SCREW
20 FUEGO LT 1000-XH	S4010JE	22	6Q139801	ARMLEVER SHAFT
20 FUEGO LT 1000-XH	S4010JE	23	6H576101	ARMLEVER SHAFT PLATE
20 FUEGO LT 1000-XH	S4010JE	24	6H442401	ARMLEVER SPRING
20 FUEGO LT 1000-XH	S4010JE	25	6Q121501	ARMLEVER SPRING HOLDER
20 FUEGO LT 1000-XH	S4010JE	26	6Q146501	ARMLEVER SPRING COVER
20 FUEGO LT 1000-XH	S4010JE	27	6Q342901	ARMLEVER SPRING COVER SCREW
20 FUEGO LT 1000-XH	S4010JE	28	6Q121620	ARMLEVER
20 FUEGO LT 1000-XH	S4010JE	29	6Q121701	ARMLEVER SCREW COLLER
20 FUEGO LT 1000-XH	S4010JE	30	6Q343401	ARMLEVER SCREW
20 FUEGO LT 1000-XH	S4010JE	31	6G195602	ROLLER SCREW
20 FUEGO LT 1000-XH	S4010JE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 1000-XH	S4010JE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 1000-XH	S4010JE	34	6J089901	LINE ROLLER
20 FUEGO LT 1000-XH	S4010JE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 1000-XH	S4010JE	36	6Q788301	BAIL ASSY
20 FUEGO LT 1000-XH	S4010JE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 1000-XH	S4010JE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 1000-XH	S4010JE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 1000-XH	S4010JE	40	6J354801	MAGSEALED PLATE O-RING
20 FUEGO LT 1000-XH	S4010JE	41	-----	-----
20 FUEGO LT 1000-XH	S4010JE	42	6Q266601	MAGSEALED CAP
20 FUEGO LT 1000-XH	S4010JE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 1000-XH	S4010JE	44	6J001403	CLUTCH RING
20 FUEGO LT 1000-XH	S4010JE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 1000-XH	S4010JE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 1000-XH	S4010JE	47	6G467302	PINION BALL BEARING(A)
20 FUEGO LT 1000-XH	S4010JE	48	63758502	PINION BALL BEARING(A) WASHER
20 FUEGO LT 1000-XH	S4010JE	49	6Q409201	PINION GEAR
20 FUEGO LT 1000-XH	S4010JE	50	6H931701	PINION BALL BEARING(B) SPRING WASHER
20 FUEGO LT 1000-XH	S4010JE	51	6H959601	PINION BALL BEARING(B)

20 FUEGO LT 1000-XH	S4010JE	52	6J387701	PINION COLLAR
20 FUEGO LT 1000-XH	S4010JE	53	6Q625801	BODY
20 FUEGO LT 1000-XH	S4010JE	54	6Q375301	MAIN SHAFT
20 FUEGO LT 1000-XH	S4010JE	55	-----	OSCILLATING POST(A)
20 FUEGO LT 1000-XH	S4010JE	56	6Q119104	OSCILLATING POST(B)
20 FUEGO LT 1000-XH	S4010JE	57	6Q118101	STOPPER CAM
20 FUEGO LT 1000-XH	S4010JE	58	6H697801	STOPPER LEVER SPRING
20 FUEGO LT 1000-XH	S4010JE	59	6Q118001	STOPPER LEVER
20 FUEGO LT 1000-XH	S4010JE	60	6Q626501	REAR COVER
20 FUEGO LT 1000-XH	S4010JE	61	6Q342901	REAR COVER SCREW
20 FUEGO LT 1000-XH	S4010JE	62	6H607902	OSCILLATING GEAR WASHER
20 FUEGO LT 1000-XH	S4010JE	63	6Q375201	OSCILLATING GEAR
20 FUEGO LT 1000-XH	S4010JE	64	6H770601	OSCILLATING GEAR ORING
20 FUEGO LT 1000-XH	S4010JE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 1000-XH	S4010JE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 1000-XH	S4010JE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 1000-XH	S4010JE	68	6G670501	DRIVE GEAR O-RING
20 FUEGO LT 1000-XH	S4010JE	69	6Q409301	DRIVE GEAR
20 FUEGO LT 1000-XH	S4010JE	70	63758502	DRIVE WASHER
20 FUEGO LT 1000-XH	S4010JE	71	6G467302	DRIVE BALL BEARING(A)
20 FUEGO LT 1000-XH	S4010JE	72	6Q625901	BODY COVER
20 FUEGO LT 1000-XH	S4010JE	73	6Q342701	BODY COVER SCREW
20 FUEGO LT 1000-XH	S4010JE	74	6Q342601	BODY COVER SCREW
20 FUEGO LT 1000-XH	S4010JE	75	6J100201	HANDLE PACKING
20 FUEGO LT 1000-XH	S4010JE	76	6Q663401	HANDLE ASSY
20 FUEGO LT 1000-XH	S4010JE	77	6G522706	DRIVE BALL BEARING(B)
20 FUEGO LT 1000-XH	S4010JE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 1000-XH	S4010JE	79	6G162401	HANDLE CAP O-RING
20 FUEGO LT 1000-XH	S4010JE	80	6Q345101	HANDLE CAP
20 FUEGO LT 1000-XH	S4010JE	81	6J639900	ONEWAY CLUTCH WASHER
20 FUEGO LT 2000-XH	S4020JE	1	6Q376801	DRAG KNOB
20 FUEGO LT 2000-XH	S4020JE	2	6Q346101	DRAG RING
20 FUEGO LT 2000-XH	S4020JE	3	6Q621901	DRAG DISC WASHER
20 FUEGO LT 2000-XH	S4020JE	4	6J678901	ATD WASHER ASSY (1pack-1 pcs)
20 FUEGO LT 2000-XH	S4020JE	5	-----	-----
20 FUEGO LT 2000-XH	S4020JE	2~6	6Q626101	SPOOL ASSY (2-5)
20 FUEGO LT 2000-XH	S4020JE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 2000-XH	S4020JE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 2000-XH	S4020JE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 2000-XH	S4020JE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 2000-XH	S4020JE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 2000-XH	S4020JE	12	6H416101	CLICK LEAF SPRING
20 FUEGO LT 2000-XH	S4020JE	13	6M021401	CLICK HOLDER
20 FUEGO LT 2000-XH	S4020JE	14	6Q344001	CLICK HOLDER WASHER
20 FUEGO LT 2000-XH	S4020JE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 2000-XH	S4020JE	16	6Q177001	ROTOR NUT
20 FUEGO LT 2000-XH	S4020JE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 2000-XH	S4020JE	18	6Q139526	ROTOR
20 FUEGO LT 2000-XH	S4020JE	19	6H443301	KICK LEVER SPRING
20 FUEGO LT 2000-XH	S4020JE	20	6Q139601	KICK LEVER
20 FUEGO LT 2000-XH	S4020JE	21	6H417701	KICK LEVER SCREW
20 FUEGO LT 2000-XH	S4020JE	22	6Q139801	ARMLEVER SHAFT
20 FUEGO LT 2000-XH	S4020JE	23	6H576101	ARMLEVER SHAFT PLATE
20 FUEGO LT 2000-XH	S4020JE	24	6H442401	ARMLEVER SPRING
20 FUEGO LT 2000-XH	S4020JE	25	6Q121501	ARMLEVER SPRING HOLDER
20 FUEGO LT 2000-XH	S4020JE	26	6Q146501	ARMLEVER SPRING COVER
20 FUEGO LT 2000-XH	S4020JE	27	6Q342901	ARMLEVER SPRING COVER SCREW
20 FUEGO LT 2000-XH	S4020JE	28	6Q121620	ARMLEVER
20 FUEGO LT 2000-XH	S4020JE	29	6Q121701	ARMLEVER SCREW COLLER
20 FUEGO LT 2000-XH	S4020JE	30	6Q343401	ARMLEVER SCREW
20 FUEGO LT 2000-XH	S4020JE	31	6G195602	ROLLER SCREW
20 FUEGO LT 2000-XH	S4020JE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 2000-XH	S4020JE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 2000-XH	S4020JE	34	6J089901	LINE ROLLER
20 FUEGO LT 2000-XH	S4020JE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 2000-XH	S4020JE	36	6Q139901	BAIL ASSY
20 FUEGO LT 2000-XH	S4020JE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 2000-XH	S4020JE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 2000-XH	S4020JE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 2000-XH	S4020JE	40	6J354801	MAGSEALED PLATE O-RING
20 FUEGO LT 2000-XH	S4020JE	41	-----	-----
20 FUEGO LT 2000-XH	S4020JE	42	6Q266601	MAGSEALED CAP
20 FUEGO LT 2000-XH	S4020JE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 2000-XH	S4020JE	44	6J001403	CLUTCH RING
20 FUEGO LT 2000-XH	S4020JE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 2000-XH	S4020JE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 2000-XH	S4020JE	47	6G467302	PINION BALL BEARING(A)
20 FUEGO LT 2000-XH	S4020JE	48	63758502	PINION BALL BEARING(A) WASHER
20 FUEGO LT 2000-XH	S4020JE	49	6Q409201	PINION GEAR
20 FUEGO LT 2000-XH	S4020JE	50	6H931701	PINION BALL BEARING(B) SPRING WASHER
20 FUEGO LT 2000-XH	S4020JE	51	6H959601	PINION BALL BEARING(B)
20 FUEGO LT 2000-XH	S4020JE	52	6J387701	PINION COLLAR
20 FUEGO LT 2000-XH	S4020JE	53	6Q625801	BODY
20 FUEGO LT 2000-XH	S4020JE	54	6Q375301	MAIN SHAFT
20 FUEGO LT 2000-XH	S4020JE	55	-----	-----
20 FUEGO LT 2000-XH	S4020JE	56	6Q119104	OSCILLATING POST(B)
20 FUEGO LT 2000-XH	S4020JE	57	6Q118101	STOPPER CAM
20 FUEGO LT 2000-XH	S4020JE	58	6H697801	STOPPER LEVER SPRING
20 FUEGO LT 2000-XH	S4020JE	59	6Q118001	STOPPER LEVER
20 FUEGO LT 2000-XH	S4020JE	60	6Q626501	REAR COVER
20 FUEGO LT 2000-XH	S4020JE	61	6Q342901	REAR COVER SCREW

20 FUEGO LT 2000-XH	S4020JE	62	6H607902	OSCILLATING GEAR WASHER
20 FUEGO LT 2000-XH	S4020JE	63	6Q375201	OSCILLATING GEAR
20 FUEGO LT 2000-XH	S4020JE	64	6H770601	OSCILLATING GEAR ORING
20 FUEGO LT 2000-XH	S4020JE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 2000-XH	S4020JE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 2000-XH	S4020JE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 2000-XH	S4020JE	68	6G670501	DRIVE GEAR O-RING
20 FUEGO LT 2000-XH	S4020JE	69	6Q409301	DRIVE GEAR
20 FUEGO LT 2000-XH	S4020JE	70	63758502	DRIVE WASHER
20 FUEGO LT 2000-XH	S4020JE	71	6G467302	DRIVE BALL BEARING(A)
20 FUEGO LT 2000-XH	S4020JE	72	6Q625901	BODY COVER
20 FUEGO LT 2000-XH	S4020JE	73	6Q342701	BODY COVER SCREW
20 FUEGO LT 2000-XH	S4020JE	74	6Q342601	BODY COVER SCREW
20 FUEGO LT 2000-XH	S4020JE	75	6J100201	HANDLE PACKING
20 FUEGO LT 2000-XH	S4020JE	76	6Q663401	HANDLE ASSY
20 FUEGO LT 2000-XH	S4020JE	77	6G522706	DRIVE BALL BEARING(B)
20 FUEGO LT 2000-XH	S4020JE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 2000-XH	S4020JE	79	6G162401	HANDLE CAP O-RING
20 FUEGO LT 2000-XH	S4020JE	80	6Q345101	HANDLE CAP
20 FUEGO LT 2000-XH	S4020JE	81	6J639901	ONEWAY CLUTCH WASHER
20 FUEGO LT 2500-XH	S4040JE	1	6Q346201	DRAG KNOB
20 FUEGO LT 2500-XH	S4040JE	2	6Q346101	DRAG RING
20 FUEGO LT 2500-XH	S4040JE	3	6Q621901	DRAG DISC WASHER
20 FUEGO LT 2500-XH	S4040JE	4	6J678801	ATD WASHER ASSY (1pack-3 pcs)
20 FUEGO LT 2500-XH	S4040JE	5	6Q346001	DRAG LIP WASHER
20 FUEGO LT 2500-XH	S4040JE	2~6	6Q624501	SPOOL ASSY (2-5)
20 FUEGO LT 2500-XH	S4040JE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 2500-XH	S4040JE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 2500-XH	S4040JE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 2500-XH	S4040JE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 2500-XH	S4040JE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 2500-XH	S4040JE	12	6H416101	CLICK LEAF SPRING
20 FUEGO LT 2500-XH	S4040JE	13	6M021401	CLICK HOLDER
20 FUEGO LT 2500-XH	S4040JE	14	6Q344001	CLICK HOLDER WASHER
20 FUEGO LT 2500-XH	S4040JE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 2500-XH	S4040JE	16	6Q177001	ROTOR NUT
20 FUEGO LT 2500-XH	S4040JE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 2500-XH	S4040JE	18	6Q343015	ROTOR
20 FUEGO LT 2500-XH	S4040JE	19	6H413601	KICK LEVER SPRING
20 FUEGO LT 2500-XH	S4040JE	20	6Q343101	KICK LEVER
20 FUEGO LT 2500-XH	S4040JE	21	6H417701	KICK LEVER SCREW
20 FUEGO LT 2500-XH	S4040JE	22	6Q343301	ARMLEVER SHAFT
20 FUEGO LT 2500-XH	S4040JE	23	6H576101	ARMLEVER SHAFT PLATE
20 FUEGO LT 2500-XH	S4040JE	24	6J642801	ARMLEVER SPRING
20 FUEGO LT 2500-XH	S4040JE	25	6Q121501	ARMLEVER SPRING HOLDER
20 FUEGO LT 2500-XH	S4040JE	26	6Q343501	ARMLEVER SPRING COVER
20 FUEGO LT 2500-XH	S4040JE	27	6Q342901	ARMLEVER SPRING COVER SCREW
20 FUEGO LT 2500-XH	S4040JE	28	6Q121620	ARMLEVER
20 FUEGO LT 2500-XH	S4040JE	29	6Q121701	ARMLEVER SCREW COLLER
20 FUEGO LT 2500-XH	S4040JE	30	6Q343401	ARMLEVER SCREW
20 FUEGO LT 2500-XH	S4040JE	31	6G195602	ROLLER SCREW
20 FUEGO LT 2500-XH	S4040JE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 2500-XH	S4040JE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 2500-XH	S4040JE	34	6J089901	LINE ROLLER
20 FUEGO LT 2500-XH	S4040JE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 2500-XH	S4040JE	36	6Q343601	BAIL ASSY
20 FUEGO LT 2500-XH	S4040JE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 2500-XH	S4040JE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 2500-XH	S4040JE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 2500-XH	S4040JE	40	6J354801	MAGSEALED PLATE O-RING
20 FUEGO LT 2500-XH	S4040JE	41	-----	-----
20 FUEGO LT 2500-XH	S4040JE	42	6Q266601	MAGSEALED CAP
20 FUEGO LT 2500-XH	S4040JE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 2500-XH	S4040JE	44	6J001403	CLUTCH RING
20 FUEGO LT 2500-XH	S4040JE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 2500-XH	S4040JE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 2500-XH	S4040JE	47	6G467302	PINION BALL BEARING(A)
20 FUEGO LT 2500-XH	S4040JE	48	63758502	PINION BALL BEARING(A) WASHER
20 FUEGO LT 2500-XH	S4040JE	49	6Q360301	PINION GEAR
20 FUEGO LT 2500-XH	S4040JE	50	6H931701	PINION BALL BEARING(B) SPRING WASHER
20 FUEGO LT 2500-XH	S4040JE	51	6H959601	PINION BALL BEARING(B)
20 FUEGO LT 2500-XH	S4040JE	52	-----	-----
20 FUEGO LT 2500-XH	S4040JE	53	6Q531018	BODY
20 FUEGO LT 2500-XH	S4040JE	54	6Q341501	MAIN SHAFT
20 FUEGO LT 2500-XH	S4040JE	55	6Q126301	OSCILLATING POST(A)
20 FUEGO LT 2500-XH	S4040JE	56	6Q119101	OSCILLATING POST(B)
20 FUEGO LT 2500-XH	S4040JE	57	6Q118101	STOPPER CAM
20 FUEGO LT 2500-XH	S4040JE	58	6H697801	STOPPER LEVER SPRING
20 FUEGO LT 2500-XH	S4040JE	59	6Q118001	STOPPER LEVER
20 FUEGO LT 2500-XH	S4040JE	60	6Q626401	REAR COVER
20 FUEGO LT 2500-XH	S4040JE	61	6Q342901	REAR COVER SCREW
20 FUEGO LT 2500-XH	S4040JE	62	6H595701	OSCILLATING GEAR WASHER
20 FUEGO LT 2500-XH	S4040JE	63	6Q139001	OSCILLATING GEAR
20 FUEGO LT 2500-XH	S4040JE	64	6H770601	OSCILLATING GEAR ORING
20 FUEGO LT 2500-XH	S4040JE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 2500-XH	S4040JE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 2500-XH	S4040JE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 2500-XH	S4040JE	68	6G670501	DRIVE GEAR O-RING
20 FUEGO LT 2500-XH	S4040JE	69	6Q360401	DRIVE GEAR
20 FUEGO LT 2500-XH	S4040JE	70	63758502	DRIVE WASHER
20 FUEGO LT 2500-XH	S4040JE	71	6G467302	DRIVE BALL BEARING(A)

20 FUEGO LT 2500-XH	S4040JE	72	6Q624301	BODY COVER
20 FUEGO LT 2500-XH	S4040JE	73	6Q342701	BODY COVER SCREW
20 FUEGO LT 2500-XH	S4040JE	74	6Q342601	BODY COVER SCREW
20 FUEGO LT 2500-XH	S4040JE	75	6J100201	HANDLE PACKING
20 FUEGO LT 2500-XH	S4040JE	76	6Q663601	HANDLE ASSY
20 FUEGO LT 2500-XH	S4040JE	77	6G522706	DRIVE BALL BEARING(B)
20 FUEGO LT 2500-XH	S4040JE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 2500-XH	S4040JE	79	6G162401	HANDLE CAP O-RING
20 FUEGO LT 2500-XH	S4040JE	80	6Q345101	HANDLE CAP
20 FUEGO LT 2500-XH	S4040JE	81	6J639901	ONEWAY CLUTCH WASHER
20 FUEGO LT 3000-CXH	S4050JE	1	6Q346201	DRAG KNOB
20 FUEGO LT 3000-CXH	S4050JE	2	6Q346101	DRAG RING
20 FUEGO LT 3000-CXH	S4050JE	3	6Q621901	DRAG DISC WASHER
20 FUEGO LT 3000-CXH	S4050JE	4	6J678801	ATD WASHER ASSY (1pack-3 pcs)
20 FUEGO LT 3000-CXH	S4050JE	5	6Q346001	DRAG LIP WASHER
20 FUEGO LT 3000-CXH	S4050JE	2~6	6Q659801	SPOOL ASSY (2-5)
20 FUEGO LT 3000-CXH	S4050JE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 3000-CXH	S4050JE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 3000-CXH	S4050JE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 3000-CXH	S4050JE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 3000-CXH	S4050JE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 3000-CXH	S4050JE	12	6H416101	CLICK LEAF SPRING
20 FUEGO LT 3000-CXH	S4050JE	13	6M021401	CLICK HOLDER
20 FUEGO LT 3000-CXH	S4050JE	14	6Q344001	CLICK HOLDER WASHER
20 FUEGO LT 3000-CXH	S4050JE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 3000-CXH	S4050JE	16	6Q177001	ROTOR NUT
20 FUEGO LT 3000-CXH	S4050JE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 3000-CXH	S4050JE	18	6Q120524	ROTOR
20 FUEGO LT 3000-CXH	S4050JE	19	6H413601	KICK LEVER SPRING
20 FUEGO LT 3000-CXH	S4050JE	20	6Q120701	KICK LEVER
20 FUEGO LT 3000-CXH	S4050JE	21	6H417701	KICK LEVER SCREW
20 FUEGO LT 3000-CXH	S4050JE	22	6Q121201	ARMLEVER SHAFT
20 FUEGO LT 3000-CXH	S4050JE	23	6H576101	ARMLEVER SHAFT PLATE
20 FUEGO LT 3000-CXH	S4050JE	24	6H545701	ARMLEVER SPRING
20 FUEGO LT 3000-CXH	S4050JE	25	6Q121501	ARMLEVER SPRING HOLDER
20 FUEGO LT 3000-CXH	S4050JE	26	6Q121801	ARMLEVER SPRING COVER
20 FUEGO LT 3000-CXH	S4050JE	27	6Q342901	ARMLEVER SPRING COVER SCREW
20 FUEGO LT 3000-CXH	S4050JE	28	6Q121620	ARMLEVER
20 FUEGO LT 3000-CXH	S4050JE	29	6Q121701	ARMLEVER SCREW COLLER
20 FUEGO LT 3000-CXH	S4050JE	30	6Q343401	ARMLEVER SCREW
20 FUEGO LT 3000-CXH	S4050JE	31	6G195602	ROLLER SCREW
20 FUEGO LT 3000-CXH	S4050JE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 3000-CXH	S4050JE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 3000-CXH	S4050JE	34	6J089901	LINE ROLLER
20 FUEGO LT 3000-CXH	S4050JE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 3000-CXH	S4050JE	36	6Q121901	BAIL ASSY
20 FUEGO LT 3000-CXH	S4050JE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 3000-CXH	S4050JE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 3000-CXH	S4050JE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 3000-CXH	S4050JE	40	6J354801	MAGSEALED PLATE O-RING
20 FUEGO LT 3000-CXH	S4050JE	41	-----	-----
20 FUEGO LT 3000-CXH	S4050JE	42	6Q266601	MAGSEALED CAP
20 FUEGO LT 3000-CXH	S4050JE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 3000-CXH	S4050JE	44	6J001403	CLUTCH RING
20 FUEGO LT 3000-CXH	S4050JE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 3000-CXH	S4050JE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 3000-CXH	S4050JE	47	6G467302	PINION BALL BEARING(A)
20 FUEGO LT 3000-CXH	S4050JE	48	63758502	PINION BALL BEARING(A) WASHER
20 FUEGO LT 3000-CXH	S4050JE	49	6Q360301	PINION GEAR
20 FUEGO LT 3000-CXH	S4050JE	50	6H931701	PINION BALL BEARING(B) SPRING WASHER
20 FUEGO LT 3000-CXH	S4050JE	51	6H959601	PINION BALL BEARING(B)
20 FUEGO LT 3000-CXH	S4050JE	52	-----	-----
20 FUEGO LT 3000-CXH	S4050JE	53	6Q659601	BODY
20 FUEGO LT 3000-CXH	S4050JE	54	6Q461401	MAIN SHAFT
20 FUEGO LT 3000-CXH	S4050JE	55	6Q126301	OSCILLATING POST(A)
20 FUEGO LT 3000-CXH	S4050JE	56	6Q119101	OSCILLATING POST(B)
20 FUEGO LT 3000-CXH	S4050JE	57	6Q118101	STOPPER CAM
20 FUEGO LT 3000-CXH	S4050JE	58	6H697801	STOPPER LEVER SPRING
20 FUEGO LT 3000-CXH	S4050JE	59	6Q118001	STOPPER LEVER
20 FUEGO LT 3000-CXH	S4050JE	60	6Q626401	REAR COVER
20 FUEGO LT 3000-CXH	S4050JE	61	6Q342901	REAR COVER SCREW
20 FUEGO LT 3000-CXH	S4050JE	62	6H595701	OSCILLATING GEAR WASHER
20 FUEGO LT 3000-CXH	S4050JE	63	6Q118401	OSCILLATING GEAR
20 FUEGO LT 3000-CXH	S4050JE	64	6H770601	OSCILLATING GEAR ORING
20 FUEGO LT 3000-CXH	S4050JE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 3000-CXH	S4050JE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 3000-CXH	S4050JE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 3000-CXH	S4050JE	68	6G670501	DRIVE GEAR O-RING
20 FUEGO LT 3000-CXH	S4050JE	69	6Q360401	DRIVE GEAR
20 FUEGO LT 3000-CXH	S4050JE	70	63758502	DRIVE WASHER
20 FUEGO LT 3000-CXH	S4050JE	71	6G467302	DRIVE BALL BEARING(A)
20 FUEGO LT 3000-CXH	S4050JE	72	6Q531209	BODY COVER
20 FUEGO LT 3000-CXH	S4050JE	73	6Q342701	BODY COVER SCREW
20 FUEGO LT 3000-CXH	S4050JE	74	6Q342601	BODY COVER SCREW
20 FUEGO LT 3000-CXH	S4050JE	75	6J100201	HANDLE PACKING
20 FUEGO LT 3000-CXH	S4050JE	76	6Q663601	HANDLE ASSY
20 FUEGO LT 3000-CXH	S4050JE	77	6G522706	DRIVE BALL BEARING(B)
20 FUEGO LT 3000-CXH	S4050JE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 3000-CXH	S4050JE	79	6G162401	HANDLE CAP O-RING
20 FUEGO LT 3000-CXH	S4050JE	80	6Q345101	HANDLE CAP
20 FUEGO LT 3000-CXH	S4050JE	81	6J639901	ONEWAY CLUTCH WASHER

20 FUEGO LT 4000-CXH	S4070JE	1	6Q352901	DRAG KNOB
20 FUEGO LT 4000-CXH	S4070JE	2	6Q346101	DRAG RING
20 FUEGO LT 4000-CXH	S4070JE	3	6Q621901	DRAG DISC WASHER
20 FUEGO LT 4000-CXH	S4070JE	4	6J678801	ATD WASHER ASSY (1pack-3 pcs)
20 FUEGO LT 4000-CXH	S4070JE	5	6Q346001	DRAG LIP WASHER
20 FUEGO LT 4000-CXH	S4070JE	2~6	6Q674901	SPOOL ASSY (2-5)
20 FUEGO LT 4000-CXH	S4070JE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 4000-CXH	S4070JE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 4000-CXH	S4070JE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 4000-CXH	S4070JE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 4000-CXH	S4070JE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 4000-CXH	S4070JE	12	6H416101	CLICK LEAF SPRING
20 FUEGO LT 4000-CXH	S4070JE	13	6M021401	CLICK HOLDER
20 FUEGO LT 4000-CXH	S4070JE	14	6Q344001	CLICK HOLDER WASHER
20 FUEGO LT 4000-CXH	S4070JE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 4000-CXH	S4070JE	16	6Q177001	ROTOR NUT
20 FUEGO LT 4000-CXH	S4070JE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 4000-CXH	S4070JE	18	6Q351811	ROTOR
20 FUEGO LT 4000-CXH	S4070JE	19	6H413601	KICK LEVER SPRING
20 FUEGO LT 4000-CXH	S4070JE	20	6Q351901	KICK LEVER
20 FUEGO LT 4000-CXH	S4070JE	21	6H417701	KICK LEVER SCREW
20 FUEGO LT 4000-CXH	S4070JE	22	6Q129501	ARMLEVER SHAFT
20 FUEGO LT 4000-CXH	S4070JE	23	6H576101	ARMLEVER SHAFT PLATE
20 FUEGO LT 4000-CXH	S4070JE	24	6H414201	ARMLEVER SPRING
20 FUEGO LT 4000-CXH	S4070JE	25	6Q121501	ARMLEVER SPRING HOLDER
20 FUEGO LT 4000-CXH	S4070JE	26	6Q352101	ARMLEVER SPRING COVER
20 FUEGO LT 4000-CXH	S4070JE	27	6Q342901	ARMLEVER SPRING COVER SCREW
20 FUEGO LT 4000-CXH	S4070JE	28	6Q121620	ARMLEVER
20 FUEGO LT 4000-CXH	S4070JE	29	6Q121701	ARMLEVER SCREW COLLER
20 FUEGO LT 4000-CXH	S4070JE	30	6Q343401	ARMLEVER SCREW
20 FUEGO LT 4000-CXH	S4070JE	31	6G195602	ROLLER SCREW
20 FUEGO LT 4000-CXH	S4070JE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 4000-CXH	S4070JE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 4000-CXH	S4070JE	34	6J089901	LINE ROLLER
20 FUEGO LT 4000-CXH	S4070JE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 4000-CXH	S4070JE	36	6Q352201	BAIL ASSY
20 FUEGO LT 4000-CXH	S4070JE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 4000-CXH	S4070JE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 4000-CXH	S4070JE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 4000-CXH	S4070JE	40	6J354801	MAGSEALED PLATE O-RING
20 FUEGO LT 4000-CXH	S4070JE	41	-----	-----
20 FUEGO LT 4000-CXH	S4070JE	42	6Q266601	MAGSEALED CAP
20 FUEGO LT 4000-CXH	S4070JE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 4000-CXH	S4070JE	44	6J001403	CLUTCH RING
20 FUEGO LT 4000-CXH	S4070JE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 4000-CXH	S4070JE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 4000-CXH	S4070JE	47	6G535104	PINION BALL BEARING(A)
20 FUEGO LT 4000-CXH	S4070JE	48	63758502	PINION BALL BEARING(A) WASHER
20 FUEGO LT 4000-CXH	S4070JE	49	6q367501	PINION GEAR
20 FUEGO LT 4000-CXH	S4070JE	50	6H931701	PINION BALL BEARING(B) SPRING WASHER
20 FUEGO LT 4000-CXH	S4070JE	51	6G466202	PINION BALL BEARING(B)
20 FUEGO LT 4000-CXH	S4070JE	52	-----	-----
20 FUEGO LT 4000-CXH	S4070JE	53	6Q674601	BODY
20 FUEGO LT 4000-CXH	S4070JE	54	6Q351001	MAIN SHAFT
20 FUEGO LT 4000-CXH	S4070JE	55	6Q126302	OSCILLATING POST(A)
20 FUEGO LT 4000-CXH	S4070JE	56	6Q119102	OSCILLATING POST(B)
20 FUEGO LT 4000-CXH	S4070JE	57	6Q118101	STOPPER CAM
20 FUEGO LT 4000-CXH	S4070JE	58	6H697801	STOPPER LEVER SPRING
20 FUEGO LT 4000-CXH	S4070JE	59	6Q118001	STOPPER LEVER
20 FUEGO LT 4000-CXH	S4070JE	60	6Q674801	REAR COVER
20 FUEGO LT 4000-CXH	S4070JE	61	6Q342901	REAR COVER SCREW
20 FUEGO LT 4000-CXH	S4070JE	62	6H595701	OSCILLATING GEAR WASHER
20 FUEGO LT 4000-CXH	S4070JE	63	6Q350901	OSCILLATING GEAR
20 FUEGO LT 4000-CXH	S4070JE	64	6G466001	OSCILLATING GEAR ORING
20 FUEGO LT 4000-CXH	S4070JE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 4000-CXH	S4070JE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 4000-CXH	S4070JE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 4000-CXH	S4070JE	68	6G670501	DRIVE GEAR O-RING
20 FUEGO LT 4000-CXH	S4070JE	69	6Q367601	DRIVE GEAR
20 FUEGO LT 4000-CXH	S4070JE	70	63758502	DRIVE WASHER
20 FUEGO LT 4000-CXH	S4070JE	71	6G467302	DRIVE BALL BEARING(A)
20 FUEGO LT 4000-CXH	S4070JE	72	6Q674701	BODY COVER
20 FUEGO LT 4000-CXH	S4070JE	73	6Q342701	BODY COVER SCREW
20 FUEGO LT 4000-CXH	S4070JE	74	6Q342601	BODY COVER SCREW
20 FUEGO LT 4000-CXH	S4070JE	75	6J100201	HANDLE PACKING
20 FUEGO LT 4000-CXH	S4070JE	76	6Q675201	HANDLE ASSY
20 FUEGO LT 4000-CXH	S4070JE	77	6G522706	DRIVE BALL BEARING(B)
20 FUEGO LT 4000-CXH	S4070JE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 4000-CXH	S4070JE	79	6G162401	HANDLE CAP O-RING
20 FUEGO LT 4000-CXH	S4070JE	80	6Q345101	HANDLE CAP
20 FUEGO LT 4000-CXH	S4070JE	81	6J639900	ONEWAY CLUTCH WASHER
20 FUEGO LT 5000-CXH	S4080JE	1	6Q352901	DRAG KNOB
20 FUEGO LT 5000-CXH	S4080JE	2	6Q346101	DRAG RING
20 FUEGO LT 5000-CXH	S4080JE	3	6Q621901	DRAG DISC WASHER
20 FUEGO LT 5000-CXH	S4080JE	4	6J678801	ATD WASHER ASSY (1pack-3 pcs)
20 FUEGO LT 5000-CXH	S4080JE	5	6Q346001	DRAG LIP WASHER
20 FUEGO LT 5000-CXH	S4080JE	2~6	6Q675401	SPOOL ASSY (2-5)
20 FUEGO LT 5000-CXH	S4080JE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 5000-CXH	S4080JE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 5000-CXH	S4080JE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 5000-CXH	S4080JE	10	6E398003	SPOOL WASHER (C)

20 FUEGO LT 5000-CXH	S4080JE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 5000-CXH	S4080JE	12	6H416101	CLICK LEAF SPRING
20 FUEGO LT 5000-CXH	S4080JE	13	6M021401	CLICK HOLDER
20 FUEGO LT 5000-CXH	S4080JE	14	6Q344001	CLICK HOLDER WASHER
20 FUEGO LT 5000-CXH	S4080JE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 5000-CXH	S4080JE	16	6Q177001	ROTOR NUT
20 FUEGO LT 5000-CXH	S4080JE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 5000-CXH	S4080JE	18	6Q129220	ROTOR
20 FUEGO LT 5000-CXH	S4080JE	19	6H413601	KICK LEVER SPRING
20 FUEGO LT 5000-CXH	S4080JE	20	6Q129301	KICK LEVER
20 FUEGO LT 5000-CXH	S4080JE	21	6H417701	KICK LEVER SCREW
20 FUEGO LT 5000-CXH	S4080JE	22	6Q129501	ARMLEVER SHAFT
20 FUEGO LT 5000-CXH	S4080JE	23	6H576101	ARMLEVER SHAFT PLATE
20 FUEGO LT 5000-CXH	S4080JE	24	6H414201	ARMLEVER SPRING
20 FUEGO LT 5000-CXH	S4080JE	25	6Q121501	ARMLEVER SPRING HOLDER
20 FUEGO LT 5000-CXH	S4080JE	26	6Q129601	ARMLEVER SPRING COVER
20 FUEGO LT 5000-CXH	S4080JE	27	6Q342901	ARMLEVER SPRING COVER SCREW
20 FUEGO LT 5000-CXH	S4080JE	28	6Q121620	ARMLEVER
20 FUEGO LT 5000-CXH	S4080JE	29	6Q121701	ARMLEVER SCREW COLLER
20 FUEGO LT 5000-CXH	S4080JE	30	6Q343401	ARMLEVER SCREW
20 FUEGO LT 5000-CXH	S4080JE	31	6G195602	ROLLER SCREW
20 FUEGO LT 5000-CXH	S4080JE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 5000-CXH	S4080JE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 5000-CXH	S4080JE	34	6J089901	LINE ROLLER
20 FUEGO LT 5000-CXH	S4080JE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 5000-CXH	S4080JE	36	6Q129701	BAIL ASSY
20 FUEGO LT 5000-CXH	S4080JE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 5000-CXH	S4080JE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 5000-CXH	S4080JE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 5000-CXH	S4080JE	40	6J354801	MAGSEALED PLATE O-RING
20 FUEGO LT 5000-CXH	S4080JE	41	-----	-----
20 FUEGO LT 5000-CXH	S4080JE	42	6Q266601	MAGSEALED CAP
20 FUEGO LT 5000-CXH	S4080JE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 5000-CXH	S4080JE	44	6J001403	CLUTCH RING
20 FUEGO LT 5000-CXH	S4080JE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 5000-CXH	S4080JE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 5000-CXH	S4080JE	47	6G535104	PINION BALL BEARING(A)
20 FUEGO LT 5000-CXH	S4080JE	48	63758502	PINION BALL BEARING(A) WASHER
20 FUEGO LT 5000-CXH	S4080JE	49	6Q367501	PINION GEAR
20 FUEGO LT 5000-CXH	S4080JE	50	6H931701	PINION BALL BEARING(B) SPRING WASHER
20 FUEGO LT 5000-CXH	S4080JE	51	6G466202	PINION BALL BEARING(B)
20 FUEGO LT 5000-CXH	S4080JE	52	-----	-----
20 FUEGO LT 5000-CXH	S4080JE	53	6Q674601	BODY
20 FUEGO LT 5000-CXH	S4080JE	54	6Q351001	MAIN SHAFT
20 FUEGO LT 5000-CXH	S4080JE	55	6Q126302	OSCILLATING POST(A)
20 FUEGO LT 5000-CXH	S4080JE	56	6Q119102	OSCILLATING POST(B)
20 FUEGO LT 5000-CXH	S4080JE	57	6Q118101	STOPPER CAM
20 FUEGO LT 5000-CXH	S4080JE	58	6H697801	STOPPER LEVER SPRING
20 FUEGO LT 5000-CXH	S4080JE	59	6Q118001	STOPPER LEVER
20 FUEGO LT 5000-CXH	S4080JE	60	6Q674801	REAR COVER
20 FUEGO LT 5000-CXH	S4080JE	61	6Q342901	REAR COVER SCREW
20 FUEGO LT 5000-CXH	S4080JE	62	6H595701	OSCILLATING GEAR WASHER
20 FUEGO LT 5000-CXH	S4080JE	63	6Q350901	OSCILLATING GEAR
20 FUEGO LT 5000-CXH	S4080JE	64	6G466001	OSCILLATING GEAR ORING
20 FUEGO LT 5000-CXH	S4080JE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 5000-CXH	S4080JE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 5000-CXH	S4080JE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 5000-CXH	S4080JE	68	6G670501	DRIVE GEAR O-RING
20 FUEGO LT 5000-CXH	S4080JE	69	6Q367601	DRIVE GEAR
20 FUEGO LT 5000-CXH	S4080JE	70	63758502	DRIVE WASHER
20 FUEGO LT 5000-CXH	S4080JE	71	6G467302	DRIVE BALL BEARING(A)
20 FUEGO LT 5000-CXH	S4080JE	72	6Q674701	BODY COVER
20 FUEGO LT 5000-CXH	S4080JE	73	6Q342701	BODY COVER SCREW
20 FUEGO LT 5000-CXH	S4080JE	74	6Q342601	BODY COVER SCREW
20 FUEGO LT 5000-CXH	S4080JE	75	6J100201	HANDLE PACKING
20 FUEGO LT 5000-CXH	S4080JE	76	6Q675201	HANDLE ASSY
20 FUEGO LT 5000-CXH	S4080JE	77	6G522706	DRIVE BALL BEARING(B)
20 FUEGO LT 5000-CXH	S4080JE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 5000-CXH	S4080JE	79	6G162401	HANDLE CAP O-RING
20 FUEGO LT 5000-CXH	S4080JE	80	6Q345101	HANDLE CAP
20 FUEGO LT 5000-CXH	S4080JE	81	6J639900	ONEWAY CLUTCH WASHER
20 FUEGO LT 6000-H	S4090JE	1	6Q364201	DRAG KNOB
20 FUEGO LT 6000-H	S4090JE	2	61704101	DRAG RING
20 FUEGO LT 6000-H	S4090JE	3	6J577501	DRAG DISC WASHER
20 FUEGO LT 6000-H	S4090JE	4	6J679001	ATD WASHER ASSY (1pack-3 pcs)
20 FUEGO LT 6000-H	S4090JE	5	6Q377601	DRAG LIP WASHER
20 FUEGO LT 6000-H	S4090JE	2~6	6Q676001	SPOOL ASSY (2-5)
20 FUEGO LT 6000-H	S4090JE	7	6Q416201	SPOOL WASHER (A)
20 FUEGO LT 6000-H	S4090JE	8	6G466206	SPOOL BALL BEARING
20 FUEGO LT 6000-H	S4090JE	9	6E096505	SPOOL WASHER (B)
20 FUEGO LT 6000-H	S4090JE	10	6F050104	SPOOL WASHER (C)
20 FUEGO LT 6000-H	S4090JE	11	6Q363801	SPOOL WASHER (D)
20 FUEGO LT 6000-H	S4090JE	12	6H416101	CLICK LEAF SPRING
20 FUEGO LT 6000-H	S4090JE	13	6M021501	CLICK HOLDER
20 FUEGO LT 6000-H	S4090JE	14	6Q377501	CLICK HOLDER WASHER
20 FUEGO LT 6000-H	S4090JE	15	6H995201	ROTOR NUT PACKING
20 FUEGO LT 6000-H	S4090JE	16	6Q363701	ROTOR NUT
20 FUEGO LT 6000-H	S4090JE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 6000-H	S4090JE	18	6Q134522	ROTOR
20 FUEGO LT 6000-H	S4090JE	19	6H413601	KICK LEVER SPRING
20 FUEGO LT 6000-H	S4090JE	20	6Q134601	KICK LEVER

20 FUEGO LT 6000-H	S4090JE	21	6H417701	KICK LEVER SCREW
20 FUEGO LT 6000-H	S4090JE	22	6Q134801	ARMLEVER SHAFT
20 FUEGO LT 6000-H	S4090JE	23	6H576101	ARMLEVER SHAFT PLATE
20 FUEGO LT 6000-H	S4090JE	24	6H640701	ARMLEVER SPRING
20 FUEGO LT 6000-H	S4090JE	25	6Q121501	ARMLEVER SPRING HOLDER
20 FUEGO LT 6000-H	S4090JE	26	6Q134901	ARMLEVER SPRING COVER
20 FUEGO LT 6000-H	S4090JE	27	6Q342901	ARMLEVER SPRING COVER SCREW
20 FUEGO LT 6000-H	S4090JE	28	6Q121620	ARMLEVER
20 FUEGO LT 6000-H	S4090JE	29	6Q121701	ARMLEVER SCREW COLLAR
20 FUEGO LT 6000-H	S4090JE	30	6Q343401	ARMLEVER SCREW
20 FUEGO LT 6000-H	S4090JE	31	6G195602	ROLLER SCREW
20 FUEGO LT 6000-H	S4090JE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 6000-H	S4090JE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 6000-H	S4090JE	34	6J089901	LINE ROLLER
20 FUEGO LT 6000-H	S4090JE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 6000-H	S4090JE	36	6Q135001	BAIL ASSY
20 FUEGO LT 6000-H	S4090JE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 6000-H	S4090JE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 6000-H	S4090JE	39	6J289301	MAGSEALED PLATE
20 FUEGO LT 6000-H	S4090JE	40	6J212901	MAGSEALED PLATE O-RING
20 FUEGO LT 6000-H	S4090JE	41	6J238801	MAGSEALED PLATE WASHER
20 FUEGO LT 6000-H	S4090JE	42	6Q363501	MAGSEALED CAP
20 FUEGO LT 6000-H	S4090JE	43	6J309101	ONEWAY CLUTCH
20 FUEGO LT 6000-H	S4090JE	44	6J690501	CLUTCH RING
20 FUEGO LT 6000-H	S4090JE	45	6Q195701	PINION BEARING PLATE SCREW
20 FUEGO LT 6000-H	S4090JE	46	6Q205901	PINION BEARING PLATE
20 FUEGO LT 6000-H	S4090JE	47	66354801	PINION BALL BEARING(A)
20 FUEGO LT 6000-H	S4090JE	48	63712824	PINION BALL BEARING(A) WASHER
20 FUEGO LT 6000-H	S4090JE	49	6Q366401	PINION GEAR
20 FUEGO LT 6000-H	S4090JE	50	6G572501	PINION BALL BEARING(B) SPRING WASHER
20 FUEGO LT 6000-H	S4090JE	51	6G467106	PINION BALL BEARING(B)
20 FUEGO LT 6000-H	S4090JE	52	-----	-----
20 FUEGO LT 6000-H	S4090JE	53	6Q675701	BODY
20 FUEGO LT 6000-H	S4090JE	54	6Q362601	MAIN SHAFT
20 FUEGO LT 6000-H	S4090JE	55	6Q126303	OSCILLATING POST(A)
20 FUEGO LT 6000-H	S4090JE	56	6Q119103	OSCILLATING POST(B)
20 FUEGO LT 6000-H	S4090JE	57	6Q133401	STOPPER CAM
20 FUEGO LT 6000-H	S4090JE	58	6H697801	STOPPER LEVER SPRING
20 FUEGO LT 6000-H	S4090JE	59	6Q118001	STOPPER LEVER
20 FUEGO LT 6000-H	S4090JE	60	6Q675901	REAR COVER
20 FUEGO LT 6000-H	S4090JE	61	6Q342901	REAR COVER SCREW
20 FUEGO LT 6000-H	S4090JE	62	6G644201	OSCILLATING GEAR WASHER
20 FUEGO LT 6000-H	S4090JE	63	6Q133501	OSCILLATING GEAR
20 FUEGO LT 6000-H	S4090JE	64	6B853101	OSCILLATING GEAR ORING
20 FUEGO LT 6000-H	S4090JE	65	6G522103	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 6000-H	S4090JE	66	6G467105	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 6000-H	S4090JE	67	6H463401	OSCILLATING GEAR SCREW
20 FUEGO LT 6000-H	S4090JE	68	6G645301	DRIVE GEAR O-RING
20 FUEGO LT 6000-H	S4090JE	69	6Q362801	DRIVE GEAR
20 FUEGO LT 6000-H	S4090JE	70	63737808	DRIVE WASHER
20 FUEGO LT 6000-H	S4090JE	71	6G523405	DRIVE BALL BEARING(A)
20 FUEGO LT 6000-H	S4090JE	72	6Q675801	BODY COVER
20 FUEGO LT 6000-H	S4090JE	73	6Q342701	BODY COVER SCREW
20 FUEGO LT 6000-H	S4090JE	74	6Q342601	BODY COVER SCREW
20 FUEGO LT 6000-H	S4090JE	75	6H730801	HANDLE PACKING
20 FUEGO LT 6000-H	S4090JE	76	6Q676301	HANDLE ASSY
20 FUEGO LT 6000-H	S4090JE	77	6B861705	DRIVE BALL BEARING(B)
20 FUEGO LT 6000-H	S4090JE	78	6G525101	DRIVE BEARING RETAINER
20 FUEGO LT 6000-H	S4090JE	79	6G672401	HANDLE CAP O-RING
20 FUEGO LT 6000-H	S4090JE	80	6Q364801	HANDLE CAP
20 FUEGO LT 6000-H	S4090JE	81	-----	-----
20 FUEGO LT 1000	S4010BE	1	6Q376801	DRAG KNOB
20 FUEGO LT 1000	S4010BE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 1000	S4010BE	3	6Q621901	KEY WASHER
20 FUEGO LT 1000	S4010BE	4	6J678901	ATD DRAG WASHER (1PC 1PK)
20 FUEGO LT 1000	S4010BE	5	-----	-----
20 FUEGO LT 1000	S4010BE	6	6Q697301	SPOOL ASSY(2TO6)
20 FUEGO LT 1000	S4010BE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 1000	S4010BE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 1000	S4010BE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 1000	S4010BE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 1000	S4010BE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 1000	S4010BE	12	6Q797701	CLICK LEAF SPRING
20 FUEGO LT 1000	S4010BE	13	6Q798201	CLICK HOLDER
20 FUEGO LT 1000	S4010BE	14	6Q344001	ROTOR WASHER
20 FUEGO LT 1000	S4010BE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 1000	S4010BE	16	6Q177001	ROTOR NUT
20 FUEGO LT 1000	S4010BE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 1000	S4010BE	18	6Q139543	ROTOR
20 FUEGO LT 1000	S4010BE	19	6H443301	BAIL TRIP LEVER SPRING
20 FUEGO LT 1000	S4010BE	20	6Q139601	BAIL TRIP LEVER
20 FUEGO LT 1000	S4010BE	21	6H417701	BAIL TRIP LEVER SCREW
20 FUEGO LT 1000	S4010BE	22	6Q139801	ARM LEVER SHAFT
20 FUEGO LT 1000	S4010BE	23	6H576101	ARM LEVER SHAFT PLATE
20 FUEGO LT 1000	S4010BE	24	6H442401	ARM LEVER SPRING
20 FUEGO LT 1000	S4010BE	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO LT 1000	S4010BE	26	6Q146501	ARM LEVER SPRING COVER
20 FUEGO LT 1000	S4010BE	27	6Q342901	ARM LEVER SPRING COVER SCREW
20 FUEGO LT 1000	S4010BE	28	6Q121620	ARM LEVER
20 FUEGO LT 1000	S4010BE	29	6Q121701	ARM LEVER SCREW COLLAR
20 FUEGO LT 1000	S4010BE	30	6Q343401	ARM LEVER SCREW

20 FUEGO LT 1000	S4010BE	31	6G195602	ROLLER SCREW
20 FUEGO LT 1000	S4010BE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 1000	S4010BE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 1000	S4010BE	34	6J089901	LINE ROLLER
20 FUEGO LT 1000	S4010BE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 1000	S4010BE	36	6Q788301	BAIL
20 FUEGO LT 1000	S4010BE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 1000	S4010BE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 1000	S4010BE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 1000	S4010BE	40	6J354801	MAGSEALED PLATE O RING
20 FUEGO LT 1000	S4010BE	41	-----	-----
20 FUEGO LT 1000	S4010BE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 1000	S4010BE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 1000	S4010BE	44	6J001403	CLUTCH RING
20 FUEGO LT 1000	S4010BE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 1000	S4010BE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 1000	S4010BE	47	6G467302	PINION BALL BEARING (A)
20 FUEGO LT 1000	S4010BE	48	63758502	PINION BEARING WASHER
20 FUEGO LT 1000	S4010BE	49	6Q375701	PINION GEAR
20 FUEGO LT 1000	S4010BE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 1000	S4010BE	51	6H959601	PINION BALL BEARING (B)
20 FUEGO LT 1000	S4010BE	52	6J387701	PINION BEARING COLLAR
20 FUEGO LT 1000	S4010BE	53	6Q625801	BODY
20 FUEGO LT 1000	S4010BE	54	6Q375301	MAIN SHAFT
20 FUEGO LT 1000	S4010BE	55	-----	-----
20 FUEGO LT 1000	S4010BE	56	6Q119104	OSCILLATING POST
20 FUEGO LT 1000	S4010BE	57	6Q118101	ANTI REVERSE CAM
20 FUEGO LT 1000	S4010BE	58	6H697801	ANTI REVERSE CAM SPRING
20 FUEGO LT 1000	S4010BE	59	6Q118001	ANTI REVERSE LEVER
20 FUEGO LT 1000	S4010BE	60	6Q626501	REAR COVER
20 FUEGO LT 1000	S4010BE	61	6Q342901	REAR COVER SCREW
20 FUEGO LT 1000	S4010BE	62	6H607902	OSCILLATING GEAR WASHER
20 FUEGO LT 1000	S4010BE	63	6Q375201	OSCILLATING GEAR
20 FUEGO LT 1000	S4010BE	64	6H770601	OSCILLATING GEAR O RING
20 FUEGO LT 1000	S4010BE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 1000	S4010BE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 1000	S4010BE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 1000	S4010BE	68	6G670501	DRIVE GEAR O RING
20 FUEGO LT 1000	S4010BE	69	6Q375801	DRIVE GEAR
20 FUEGO LT 1000	S4010BE	70	63758502	DRIVE WASHER
20 FUEGO LT 1000	S4010BE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 1000	S4010BE	72	6Q625901	BODY COVER
20 FUEGO LT 1000	S4010BE	73	6Q342701	BODY COVER SCREW (A)
20 FUEGO LT 1000	S4010BE	74	6Q342601	BODY COVER SCREW (B)
20 FUEGO LT 1000	S4010BE	75	6J100201	BODY COVER PACKING
20 FUEGO LT 1000	S4010BE	76	6Q663401	HANDLE ASSY
20 FUEGO LT 1000	S4010BE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 1000	S4010BE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 1000	S4010BE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 1000	S4010BE	80	6Q345101	HANDLE CAP
20 FUEGO LT 1000	S4010BE	81	6J639901	ONEWAY CLUTCH WASHER
20 FUEGO LT 2000	S4020BE	1	6Q376801	DRAG KNOB
20 FUEGO LT 2000	S4020BE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 2000	S4020BE	3	6Q621901	KEY WASHER
20 FUEGO LT 2000	S4020BE	4	6J678901	ATD DRAG WASHER (1PC 1PK)
20 FUEGO LT 2000	S4020BE	5	-----	-----
20 FUEGO LT 2000	S4020BE	6	6Q697501	SPOOL ASSY(2T06)
20 FUEGO LT 2000	S4020BE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 2000	S4020BE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 2000	S4020BE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 2000	S4020BE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 2000	S4020BE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 2000	S4020BE	12	6Q797701	CLICK LEAF SPRING
20 FUEGO LT 2000	S4020BE	13	6Q798201	CLICK HOLDER
20 FUEGO LT 2000	S4020BE	14	6Q344001	ROTOR WASHER
20 FUEGO LT 2000	S4020BE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 2000	S4020BE	16	6Q177001	ROTOR NUT
20 FUEGO LT 2000	S4020BE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 2000	S4020BE	18	6Q139543	ROTOR
20 FUEGO LT 2000	S4020BE	19	6H443301	BAIL TRIP LEVER SPRING
20 FUEGO LT 2000	S4020BE	20	6Q139601	BAIL TRIP LEVER
20 FUEGO LT 2000	S4020BE	21	6H417701	BAIL TRIP LEVER SCREW
20 FUEGO LT 2000	S4020BE	22	6Q139801	ARM LEVER SHAFT
20 FUEGO LT 2000	S4020BE	23	6H576101	ARM LEVER SHAFT PLATE
20 FUEGO LT 2000	S4020BE	24	6H442401	ARM LEVER SPRING
20 FUEGO LT 2000	S4020BE	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO LT 2000	S4020BE	26	6Q146501	ARM LEVER SPRING COVER
20 FUEGO LT 2000	S4020BE	27	6Q342901	ARM LEVER SPRING COVER SCREW
20 FUEGO LT 2000	S4020BE	28	6Q121620	ARM LEVER
20 FUEGO LT 2000	S4020BE	29	6Q121701	ARM LEVER SCREW COLLAR
20 FUEGO LT 2000	S4020BE	30	6Q343401	ARM LEVER SCREW
20 FUEGO LT 2000	S4020BE	31	6G195602	ROLLER SCREW
20 FUEGO LT 2000	S4020BE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 2000	S4020BE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 2000	S4020BE	34	6J089901	LINE ROLLER
20 FUEGO LT 2000	S4020BE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 2000	S4020BE	36	6Q788301	BAIL
20 FUEGO LT 2000	S4020BE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 2000	S4020BE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 2000	S4020BE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 2000	S4020BE	40	6J354801	MAGSEALED PLATE O RING

20 FUEGO LT 2000	S4020BE	41	-----	-----
20 FUEGO LT 2000	S4020BE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 2000	S4020BE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 2000	S4020BE	44	6J001403	CLUTCH RING
20 FUEGO LT 2000	S4020BE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 2000	S4020BE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 2000	S4020BE	47	6G467302	PINION BALL BEARING (A)
20 FUEGO LT 2000	S4020BE	48	63758502	PINION BEARING WASHER
20 FUEGO LT 2000	S4020BE	49	6Q375701	PINION GEAR
20 FUEGO LT 2000	S4020BE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 2000	S4020BE	51	6H959601	PINION BALL BEARING (B)
20 FUEGO LT 2000	S4020BE	52	6J387701	PINION BEARING COLLAR
20 FUEGO LT 2000	S4020BE	53	6Q625801	BODY
20 FUEGO LT 2000	S4020BE	54	6Q375301	MAIN SHAFT
20 FUEGO LT 2000	S4020BE	55	-----	-----
20 FUEGO LT 2000	S4020BE	56	6Q119104	OSCILLATING POST
20 FUEGO LT 2000	S4020BE	57	6Q118101	ANTI REVERSE CAM
20 FUEGO LT 2000	S4020BE	58	6H697801	ANTI REVERSE CAM SPRING
20 FUEGO LT 2000	S4020BE	59	6Q118001	ANTI REVERSE LEVER
20 FUEGO LT 2000	S4020BE	60	6Q626501	REAR COVER
20 FUEGO LT 2000	S4020BE	61	6Q342901	REAR COVER SCREW
20 FUEGO LT 2000	S4020BE	62	6H607902	OSCILLATING GEAR WASHER
20 FUEGO LT 2000	S4020BE	63	6Q375201	OSCILLATING GEAR
20 FUEGO LT 2000	S4020BE	64	6H770601	OSCILLATING GEAR O RING
20 FUEGO LT 2000	S4020BE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 2000	S4020BE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 2000	S4020BE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 2000	S4020BE	68	6G670501	DRIVE GEAR O RING
20 FUEGO LT 2000	S4020BE	69	6Q375801	DRIVE GEAR
20 FUEGO LT 2000	S4020BE	70	63758502	DRIVE WASHER
20 FUEGO LT 2000	S4020BE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 2000	S4020BE	72	6Q625901	BODY COVER
20 FUEGO LT 2000	S4020BE	73	6Q342701	BODY COVER SCREW (A)
20 FUEGO LT 2000	S4020BE	74	6Q342601	BODY COVER SCREW (B)
20 FUEGO LT 2000	S4020BE	75	6J100201	BODY COVER PACKING
20 FUEGO LT 2000	S4020BE	76	6Q663401	HANDLE ASSY
20 FUEGO LT 2000	S4020BE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 2000	S4020BE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 2000	S4020BE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 2000	S4020BE	80	6Q345101	HANDLE CAP
20 FUEGO LT 2000	S4020BE	81	6J639901	ONEWAY CLUTCH WASHER
20 FUEGO LT 2500	S4040BE	1	6Q346201	DRAG KNOB
20 FUEGO LT 2500	S4040BE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 2500	S4040BE	3	6Q621901	KEY WASHER
20 FUEGO LT 2500	S4040BE	4	6J678801	ATD WASHER ASSY (1pack-3 pcs)
20 FUEGO LT 2500	S4040BE	5	6Q346001	EARED WASHER
20 FUEGO LT 2500	S4040BE	6	6Q697701	SPOOL ASSY(2T06)
20 FUEGO LT 2500	S4040BE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 2500	S4040BE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 2500	S4040BE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 2500	S4040BE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 2500	S4040BE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 2500	S4040BE	12	6Q797701	CLICK LEAF SPRING
20 FUEGO LT 2500	S4040BE	13	6Q798201	CLICK HOLDER
20 FUEGO LT 2500	S4040BE	14	6Q344001	ROTOR WASHER
20 FUEGO LT 2500	S4040BE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 2500	S4040BE	16	6Q177001	ROTOR NUT
20 FUEGO LT 2500	S4040BE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 2500	S4040BE	18	6Q343031	ROTOR
20 FUEGO LT 2500	S4040BE	19	6H413601	BAIL TRIP LEVER SPRING
20 FUEGO LT 2500	S4040BE	20	6Q343101	BAIL TRIP LEVER
20 FUEGO LT 2500	S4040BE	21	6H417701	BAIL TRIP LEVER SCREW
20 FUEGO LT 2500	S4040BE	22	6Q343301	ARM LEVER SHAFT
20 FUEGO LT 2500	S4040BE	23	6H576101	ARM LEVER SHAFT PLATE
20 FUEGO LT 2500	S4040BE	24	6J642801	ARM LEVER SPRING
20 FUEGO LT 2500	S4040BE	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO LT 2500	S4040BE	26	6Q343501	ARM LEVER SPRING COVER
20 FUEGO LT 2500	S4040BE	27	6Q342901	ARM LEVER SPRING COVER SCREW
20 FUEGO LT 2500	S4040BE	28	6Q121620	ARM LEVER
20 FUEGO LT 2500	S4040BE	29	6Q121701	ARM LEVER SCREW COLLAR
20 FUEGO LT 2500	S4040BE	30	6Q343401	ARM LEVER SCREW
20 FUEGO LT 2500	S4040BE	31	6G195602	ROLLER SCREW
20 FUEGO LT 2500	S4040BE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 2500	S4040BE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 2500	S4040BE	34	6J089901	LINE ROLLER
20 FUEGO LT 2500	S4040BE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 2500	S4040BE	36	6Q777001	BAIL
20 FUEGO LT 2500	S4040BE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 2500	S4040BE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 2500	S4040BE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 2500	S4040BE	40	6J354801	MAGSEALED PLATE O RING
20 FUEGO LT 2500	S4040BE	41	-----	-----
20 FUEGO LT 2500	S4040BE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 2500	S4040BE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 2500	S4040BE	44	6J001403	CLUTCH RING
20 FUEGO LT 2500	S4040BE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 2500	S4040BE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 2500	S4040BE	47	6G467302	PINION BALL BEARING (A)
20 FUEGO LT 2500	S4040BE	48	63758502	PINION BEARING WASHER
20 FUEGO LT 2500	S4040BE	49	6Q341701	PINION GEAR
20 FUEGO LT 2500	S4040BE	50	6H931701	PINION SPRING WASHER

20 FUEGO LT 2500	S4040BE	51	6H959601	PINION BALL BEARING (B)
20 FUEGO LT 2500	S4040BE	52	-----	-----
20 FUEGO LT 2500	S4040BE	53	6Q624201	BODY
20 FUEGO LT 2500	S4040BE	54	6Q341501	MAIN SHAFT
20 FUEGO LT 2500	S4040BE	55	6Q126301	OSCILLATING POST (A)
20 FUEGO LT 2500	S4040BE	56	6Q119101	OSCILLATING POST (B)
20 FUEGO LT 2500	S4040BE	57	6Q118101	ANTI REVERSE CAM
20 FUEGO LT 2500	S4040BE	58	6H697801	ANTI REVERSE CAM SPRING
20 FUEGO LT 2500	S4040BE	59	6Q118001	ANTI REVERSE LEVER
20 FUEGO LT 2500	S4040BE	60	6Q626401	REAR COVER
20 FUEGO LT 2500	S4040BE	61	6Q342901	REAR COVER SCREW
20 FUEGO LT 2500	S4040BE	62	6H595701	OSCILLATING GEAR WASHER
20 FUEGO LT 2500	S4040BE	63	6Q139001	OSCILLATING GEAR
20 FUEGO LT 2500	S4040BE	64	6H770601	OSCILLATING GEAR O RING
20 FUEGO LT 2500	S4040BE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 2500	S4040BE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 2500	S4040BE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 2500	S4040BE	68	6G670501	DRIVE GEAR O RING
20 FUEGO LT 2500	S4040BE	69	6Q341801	DRIVE GEAR
20 FUEGO LT 2500	S4040BE	70	63758502	DRIVE WASHER
20 FUEGO LT 2500	S4040BE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 2500	S4040BE	72	6Q624301	BODY COVER
20 FUEGO LT 2500	S4040BE	73	6Q342701	BODY COVER SCREW (A)
20 FUEGO LT 2500	S4040BE	74	6Q342601	BODY COVER SCREW (B)
20 FUEGO LT 2500	S4040BE	75	61100201	BODY COVER PACKING
20 FUEGO LT 2500	S4040BE	76	6Q663601	HANDLE ASSY
20 FUEGO LT 2500	S4040BE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 2500	S4040BE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 2500	S4040BE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 2500	S4040BE	80	6Q345101	HANDLE CAP
20 FUEGO LT 2500	S4040BE	81	6J639901	ONEWAY CLUTCH WASHER
20 FUEGO LT 3000 C	S4050BE	1	6Q346201	DRAG KNOB
20 FUEGO LT 3000 C	S4050BE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 3000 C	S4050BE	3	6Q621901	KEY WASHER
20 FUEGO LT 3000 C	S4050BE	4	6J678801	ATD WASHER ASSY (1pack-3 pcs)
20 FUEGO LT 3000 C	S4050BE	5	6Q346001	EARED WASHER
20 FUEGO LT 3000 C	S4050BE	6	6Q697901	SPOOL ASSY(2TO6)
20 FUEGO LT 3000 C	S4050BE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 3000 C	S4050BE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 3000 C	S4050BE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 3000 C	S4050BE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 3000 C	S4050BE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 3000 C	S4050BE	12	6Q797701	CLICK LEAF SPRING
20 FUEGO LT 3000 C	S4050BE	13	6Q798201	CLICK HOLDER
20 FUEGO LT 3000 C	S4050BE	14	6Q344001	ROTOR WASHER
20 FUEGO LT 3000 C	S4050BE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 3000 C	S4050BE	16	6Q177001	ROTOR NUT
20 FUEGO LT 3000 C	S4050BE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 3000 C	S4050BE	18	6Q120540	ROTOR
20 FUEGO LT 3000 C	S4050BE	19	6H413601	BAIL TRIP LEVER SPRING
20 FUEGO LT 3000 C	S4050BE	20	6Q120701	BAIL TRIP LEVER
20 FUEGO LT 3000 C	S4050BE	21	6H417701	BAIL TRIP LEVER SCREW
20 FUEGO LT 3000 C	S4050BE	22	6Q121201	ARM LEVER SHAFT
20 FUEGO LT 3000 C	S4050BE	23	6H576101	ARM LEVER SHAFT PLATE
20 FUEGO LT 3000 C	S4050BE	24	6H545701	ARM LEVER SPRING
20 FUEGO LT 3000 C	S4050BE	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO LT 3000 C	S4050BE	26	6Q121801	ARM LEVER SPRING COVER
20 FUEGO LT 3000 C	S4050BE	27	6Q342901	ARM LEVER SPRING COVER SCREW
20 FUEGO LT 3000 C	S4050BE	28	6Q121620	ARM LEVER
20 FUEGO LT 3000 C	S4050BE	29	6Q121701	ARM LEVER SCREW COLLAR
20 FUEGO LT 3000 C	S4050BE	30	6Q343401	ARM LEVER SCREW
20 FUEGO LT 3000 C	S4050BE	31	6G195602	ROLLER SCREW
20 FUEGO LT 3000 C	S4050BE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 3000 C	S4050BE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 3000 C	S4050BE	34	6J089901	LINE ROLLER
20 FUEGO LT 3000 C	S4050BE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 3000 C	S4050BE	36	6Q777101	BAIL
20 FUEGO LT 3000 C	S4050BE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 3000 C	S4050BE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 3000 C	S4050BE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 3000 C	S4050BE	40	6J354801	MAGSEALED PLATE O RING
20 FUEGO LT 3000 C	S4050BE	41	-----	-----
20 FUEGO LT 3000 C	S4050BE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 3000 C	S4050BE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 3000 C	S4050BE	44	6J001403	CLUTCH RING
20 FUEGO LT 3000 C	S4050BE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 3000 C	S4050BE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 3000 C	S4050BE	47	6G467302	PINION BALL BEARING (A)
20 FUEGO LT 3000 C	S4050BE	48	63758502	PINION BEARING WASHER
20 FUEGO LT 3000 C	S4050BE	49	6Q341701	PINION GEAR
20 FUEGO LT 3000 C	S4050BE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 3000 C	S4050BE	51	6H959601	PINION BALL BEARING (B)
20 FUEGO LT 3000 C	S4050BE	52	-----	-----
20 FUEGO LT 3000 C	S4050BE	53	6Q659601	BODY
20 FUEGO LT 3000 C	S4050BE	54	6Q461401	MAIN SHAFT
20 FUEGO LT 3000 C	S4050BE	55	6Q126301	OSCILLATING POST (A)
20 FUEGO LT 3000 C	S4050BE	56	6Q119101	OSCILLATING POST (B)
20 FUEGO LT 3000 C	S4050BE	57	6Q118101	ANTI REVERSE CAM
20 FUEGO LT 3000 C	S4050BE	58	6H697801	ANTI REVERSE CAM SPRING
20 FUEGO LT 3000 C	S4050BE	59	6Q118001	ANTI REVERSE LEVER
20 FUEGO LT 3000 C	S4050BE	60	6Q626401	REAR COVER

20 FUEGO LT 3000 C	S4050BE	61	6Q342901	REAR COVER SCREW
20 FUEGO LT 3000 C	S4050BE	62	6H595701	OSCILLATING GEAR WASHER
20 FUEGO LT 3000 C	S4050BE	63	6Q118401	OSCILLATING GEAR
20 FUEGO LT 3000 C	S4050BE	64	6H770601	OSCILLATING GEAR O RING
20 FUEGO LT 3000 C	S4050BE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 3000 C	S4050BE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 3000 C	S4050BE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 3000 C	S4050BE	68	6G670501	DRIVE GEAR O RING
20 FUEGO LT 3000 C	S4050BE	69	6Q341801	DRIVE GEAR
20 FUEGO LT 3000 C	S4050BE	70	63758502	DRIVE WASHER
20 FUEGO LT 3000 C	S4050BE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 3000 C	S4050BE	72	6Q624301	BODY COVER
20 FUEGO LT 3000 C	S4050BE	73	6Q342701	BODY COVER SCREW (A)
20 FUEGO LT 3000 C	S4050BE	74	6Q342601	BODY COVER SCREW (B)
20 FUEGO LT 3000 C	S4050BE	75	6J100201	BODY COVER PACKING
20 FUEGO LT 3000 C	S4050BE	76	6Q663601	HANDLE ASSY
20 FUEGO LT 3000 C	S4050BE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 3000 C	S4050BE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 3000 C	S4050BE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 3000 C	S4050BE	80	6Q345101	HANDLE CAP
20 FUEGO LT 3000 C	S4050BE	81	6J639901	ONEWAY CLUTCH WASHER
20 FUEGO LT 4000 C	S4070BE	1	6Q352901	DRAG KNOB
20 FUEGO LT 4000 C	S4070BE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 4000 C	S4070BE	3	6Q621901	KEY WASHER
20 FUEGO LT 4000 C	S4070BE	4	63758801	ATD WASHER ASSY 1PACK 3 PCS
20 FUEGO LT 4000 C	S4070BE	5	6Q346001	EARED WASHER
20 FUEGO LT 4000 C	S4070BE	6	6Q702701	SPOOL ASSY
20 FUEGO LT 4000 C	S4070BE	7	6Q382701	SPOOL BEARING WASHER (A)
20 FUEGO LT 4000 C	S4070BE	8	6E332501	SPOOL BALL BEARING (A)
20 FUEGO LT 4000 C	S4070BE	9	6B411706	SPOOL BEARING WASHER (B)
20 FUEGO LT 4000 C	S4070BE	10	6E398003	SPOOL WASHER (A)
20 FUEGO LT 4000 C	S4070BE	11	6Q348502	SPOOL WASHER (B)
20 FUEGO LT 4000 C	S4070BE	12	6Q797701	CLICK LEAF SPRING
20 FUEGO LT 4000 C	S4070BE	13	6Q798201	CLICK HOLDER
20 FUEGO LT 4000 C	S4070BE	14	6Q344001	SPOOL WASHER (C)
20 FUEGO LT 4000 C	S4070BE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 4000 C	S4070BE	16	6Q177001	ROTOR NUT
20 FUEGO LT 4000 C	S4070BE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 4000 C	S4070BE	18	6Q351826	ROTOR
20 FUEGO LT 4000 C	S4070BE	19	6H413601	BAIL TRIP LEVER SPRING
20 FUEGO LT 4000 C	S4070BE	20	6Q351901	BAIL TRIP LEVER
20 FUEGO LT 4000 C	S4070BE	21	6H417701	BAIL TRIP LEVER SCREW
20 FUEGO LT 4000 C	S4070BE	22	6Q129501	ARM LEVER SHAFT
20 FUEGO LT 4000 C	S4070BE	23	6H576101	ARM LEVER SPRING PLATE
20 FUEGO LT 4000 C	S4070BE	24	6H414201	ARM LEVER SPRING
20 FUEGO LT 4000 C	S4070BE	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO LT 4000 C	S4070BE	26	6Q352101	ARM LEVER COVER
20 FUEGO LT 4000 C	S4070BE	27	6Q342901	ARM LEVER COVER SCREW
20 FUEGO LT 4000 C	S4070BE	28	6Q121620	ARM LEVER
20 FUEGO LT 4000 C	S4070BE	29	6Q121701	ARM LEVER COLLAR
20 FUEGO LT 4000 C	S4070BE	30	6Q343401	ARM LEVER SCREW
20 FUEGO LT 4000 C	S4070BE	31	6G195602	ROLLER SCREW
20 FUEGO LT 4000 C	S4070BE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 4000 C	S4070BE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 4000 C	S4070BE	34	6J089901	LINE ROLLER
20 FUEGO LT 4000 C	S4070BE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 4000 C	S4070BE	36	6Q777201	BAIL
20 FUEGO LT 4000 C	S4070BE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 4000 C	S4070BE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 4000 C	S4070BE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 4000 C	S4070BE	40	6J354801	MADSEALED CAP O RING
20 FUEGO LT 4000 C	S4070BE	41	-----	-----
20 FUEGO LT 4000 C	S4070BE	42	6Q266601	MAGSEALED CAP
20 FUEGO LT 4000 C	S4070BE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 4000 C	S4070BE	44	6J001403	CLUTCH RING
20 FUEGO LT 4000 C	S4070BE	45	6Q126201	BEARING PLATE SCREW
20 FUEGO LT 4000 C	S4070BE	46	6Q195601	BEARING PLATE
20 FUEGO LT 4000 C	S4070BE	47	6G535104	PINION BALL BEARING (A)
20 FUEGO LT 4000 C	S4070BE	48	63758502	PINION BEARING (A) WASHER01mm
20 FUEGO LT 4000 C	S4070BE	49	6Q351201	PINION GEAR
20 FUEGO LT 4000 C	S4070BE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 4000 C	S4070BE	51	6G466202	PINON BALL BEARING (B)
20 FUEGO LT 4000 C	S4070BE	52	-----	-----
20 FUEGO LT 4000 C	S4070BE	53	6Q674601	BODY
20 FUEGO LT 4000 C	S4070BE	54	6Q351001	MAIN SHAFT
20 FUEGO LT 4000 C	S4070BE	55	6Q126302	OSCILLATING POST (A)
20 FUEGO LT 4000 C	S4070BE	56	6Q119102	OSCILLATING POST (B)
20 FUEGO LT 4000 C	S4070BE	57	6Q118101	ANTI REVERSE CAM
20 FUEGO LT 4000 C	S4070BE	58	6H697801	ANTI REVERSE CAM SPRING
20 FUEGO LT 4000 C	S4070BE	59	6Q118001	ANTI REVERSE LEVER
20 FUEGO LT 4000 C	S4070BE	60	6Q674801	REAR COVER
20 FUEGO LT 4000 C	S4070BE	61	6Q342901	REAR COVER SCREW
20 FUEGO LT 4000 C	S4070BE	62	6H595701	OSCILLATING GEAR WASHER
20 FUEGO LT 4000 C	S4070BE	63	6Q350901	OSCILLATING GEAR
20 FUEGO LT 4000 C	S4070BE	64	6G466001	OSCILLATING GEAR O RING
20 FUEGO LT 4000 C	S4070BE	65	6H129201	OSCILLATING BEARING WASHER01mm
20 FUEGO LT 4000 C	S4070BE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 4000 C	S4070BE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 4000 C	S4070BE	68	6G670501	DRIVE O RING
20 FUEGO LT 4000 C	S4070BE	69	6Q351301	DRIVE GEAR
20 FUEGO LT 4000 C	S4070BE	70	63758502	DRIVE BEARING WASHER01mm

20 FUEGO LT 4000 C	S4070BE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 4000 C	S4070BE	72	6Q674701	BODY COVER
20 FUEGO LT 4000 C	S4070BE	73	6Q342701	BODY COVER SCREW (A)
20 FUEGO LT 4000 C	S4070BE	74	6Q342601	BODY COVER SCREW (B)
20 FUEGO LT 4000 C	S4070BE	75	6J100201	HANDLE PACKING
20 FUEGO LT 4000 C	S4070BE	76	6Q675201	HANDLE ASSY
20 FUEGO LT 4000 C	S4070BE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 4000 C	S4070BE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 4000 C	S4070BE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 4000 C	S4070BE	80	6Q345101	HANDLE CAP
20 FUEGO LT 4000 C	S4070BE	81	6J639901	ONEWAY CLUTCH WASHER
20 FUEGO LT 4000 CP	S4070KE	1	6Q352901	DRAG KNOB
20 FUEGO LT 4000 CP	S4070KE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 4000 CP	S4070KE	3	6Q621901	KEY WASHER
20 FUEGO LT 4000 CP	S4070KE	4	6J678801	ATD WASHER ASSY 1PACK 3 PCS
20 FUEGO LT 4000 CP	S4070KE	5	6Q346001	EARED WASHER
20 FUEGO LT 4000 CP	S4070KE	6	6Q702901	SPOOL ASSY
20 FUEGO LT 4000 CP	S4070KE	7	6Q382701	SPOOL BEARING WASHER (A)
20 FUEGO LT 4000 CP	S4070KE	8	6E332501	SPOOL BALL BEARING (A)
20 FUEGO LT 4000 CP	S4070KE	9	6B411706	SPOOL BEARING WASHER (B)
20 FUEGO LT 4000 CP	S4070KE	10	6E398003	SPOOL WASHER (A)
20 FUEGO LT 4000 CP	S4070KE	11	6Q348502	SPOOL WASHER (B)
20 FUEGO LT 4000 CP	S4070KE	12	6Q797701	CLICK LEAF SPRING
20 FUEGO LT 4000 CP	S4070KE	13	6Q798201	CLICK HOLDER
20 FUEGO LT 4000 CP	S4070KE	14	6Q344001	SPOOL WASHER (C)
20 FUEGO LT 4000 CP	S4070KE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 4000 CP	S4070KE	16	6Q177001	ROTOR NUT
20 FUEGO LT 4000 CP	S4070KE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 4000 CP	S4070KE	18	6Q351826	ROTOR
20 FUEGO LT 4000 CP	S4070KE	19	6H413601	BAIL TRIP LEVER SPRING
20 FUEGO LT 4000 CP	S4070KE	20	6Q351901	BAIL TRIP LEVER
20 FUEGO LT 4000 CP	S4070KE	21	6H417701	BAIL TRIP LEVER SCREW
20 FUEGO LT 4000 CP	S4070KE	22	6Q129501	ARM LEVER SHAFT
20 FUEGO LT 4000 CP	S4070KE	23	6H576101	ARM LEVER SPRING PLATE
20 FUEGO LT 4000 CP	S4070KE	24	6H414201	ARM LEVER SPRING
20 FUEGO LT 4000 CP	S4070KE	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO LT 4000 CP	S4070KE	26	6Q352101	ARM LEVER COVER
20 FUEGO LT 4000 CP	S4070KE	27	6Q342901	ARM LEVER COVER SCREW
20 FUEGO LT 4000 CP	S4070KE	28	6Q121620	ARM LEVER
20 FUEGO LT 4000 CP	S4070KE	29	6Q121701	ARM LEVER COLLAR
20 FUEGO LT 4000 CP	S4070KE	30	6Q343401	ARM LEVER SCREW
20 FUEGO LT 4000 CP	S4070KE	31	6G195602	ROLLER SCREW
20 FUEGO LT 4000 CP	S4070KE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 4000 CP	S4070KE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 4000 CP	S4070KE	34	6J089901	LINE ROLLER
20 FUEGO LT 4000 CP	S4070KE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 4000 CP	S4070KE	36	6Q777201	BAIL
20 FUEGO LT 4000 CP	S4070KE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 4000 CP	S4070KE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 4000 CP	S4070KE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 4000 CP	S4070KE	40	6J354801	MADSEALED CAP O RING
20 FUEGO LT 4000 CP	S4070KE	41	-----	-----
20 FUEGO LT 4000 CP	S4070KE	42	6Q266601	MAGSEALED CAP
20 FUEGO LT 4000 CP	S4070KE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 4000 CP	S4070KE	44	6J001403	CLUTCH RING
20 FUEGO LT 4000 CP	S4070KE	45	6Q126201	BEARING PLATE SCREW
20 FUEGO LT 4000 CP	S4070KE	46	6Q195601	BEARING PLATE
20 FUEGO LT 4000 CP	S4070KE	47	6G535104	PINION BALL BEARING (A)
20 FUEGO LT 4000 CP	S4070KE	48	63758502	PINION BEARING (A) WASHER01mm
20 FUEGO LT 4000 CP	S4070KE	49	6Q678801	PINION GEAR
20 FUEGO LT 4000 CP	S4070KE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 4000 CP	S4070KE	51	6G466202	PINON BALL BEARING (B)
20 FUEGO LT 4000 CP	S4070KE	52	-----	-----
20 FUEGO LT 4000 CP	S4070KE	53	6Q674601	BODY
20 FUEGO LT 4000 CP	S4070KE	54	6Q351001	MAIN SHAFT
20 FUEGO LT 4000 CP	S4070KE	55	6Q126302	OSCILLATING POST (A)
20 FUEGO LT 4000 CP	S4070KE	56	6Q119102	OSCILLATING POST (B)
20 FUEGO LT 4000 CP	S4070KE	57	6Q118101	ANTI REVERSE CAM
20 FUEGO LT 4000 CP	S4070KE	58	6H697801	ANTI REVERSE CAM SPRING
20 FUEGO LT 4000 CP	S4070KE	59	6Q118001	ANTI REVERSE LEVER
20 FUEGO LT 4000 CP	S4070KE	60	6Q674801	REAR COVER
20 FUEGO LT 4000 CP	S4070KE	61	6Q342901	REAR COVER SCREW
20 FUEGO LT 4000 CP	S4070KE	62	6H595701	OSCILLATING GEAR WASHER
20 FUEGO LT 4000 CP	S4070KE	63	6Q350901	OSCILLATING GEAR
20 FUEGO LT 4000 CP	S4070KE	64	6G466001	OSCILLATING GEAR O RING
20 FUEGO LT 4000 CP	S4070KE	65	6H129201	OSCILLATING BEARING WASHER01mm
20 FUEGO LT 4000 CP	S4070KE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 4000 CP	S4070KE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 4000 CP	S4070KE	68	6G670501	DRIVE O RING
20 FUEGO LT 4000 CP	S4070KE	69	6Q703501	DRIVE GEAR
20 FUEGO LT 4000 CP	S4070KE	70	63758502	DRIVE BEARING WASHER01mm
20 FUEGO LT 4000 CP	S4070KE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 4000 CP	S4070KE	72	6Q674701	BODY COVER
20 FUEGO LT 4000 CP	S4070KE	73	6Q342701	BODY COVER SCREW (A)
20 FUEGO LT 4000 CP	S4070KE	74	6Q342601	BODY COVER SCREW (B)
20 FUEGO LT 4000 CP	S4070KE	75	6J100201	HANDLE PACKING
20 FUEGO LT 4000 CP	S4070KE	76	6Q675201	HANDLE ASSY
20 FUEGO LT 4000 CP	S4070KE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 4000 CP	S4070KE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 4000 CP	S4070KE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 4000 CP	S4070KE	80	6Q345101	HANDLE CAP

20 FUEGO LT 4000 CP	S4070KE	81	6J639901	ONEWAY CLUTCH WASHER
20 FUEGO LT 5000 C	S4080BE	1	6Q352901	DRAG KNOB
20 FUEGO LT 5000 C	S4080BE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 5000 C	S4080BE	3	6Q621901	KEY WASHER
20 FUEGO LT 5000 C	S4080BE	4	6J678801	ATD WASHER ASSY 1PACK 3 PCS
20 FUEGO LT 5000 C	S4080BE	5	6Q346001	EARED WASHER
20 FUEGO LT 5000 C	S4080BE	6	6Q703101	SPOOL ASSY
20 FUEGO LT 5000 C	S4080BE	7	6Q382701	SPOOL BEARING WASHER (A)
20 FUEGO LT 5000 C	S4080BE	8	6E332501	SPOOL BALL BEARING (A)
20 FUEGO LT 5000 C	S4080BE	9	6B411706	SPOOL BEARING WASHER (B)
20 FUEGO LT 5000 C	S4080BE	10	6E398003	SPOOL WASHER (A)
20 FUEGO LT 5000 C	S4080BE	11	6Q348502	SPOOL WASHER (B)
20 FUEGO LT 5000 C	S4080BE	12	6Q797701	CLICK LEAF SPRING
20 FUEGO LT 5000 C	S4080BE	13	6Q798201	CLICK HOLDER
20 FUEGO LT 5000 C	S4080BE	14	6Q344001	SPOOL WASHER (C)
20 FUEGO LT 5000 C	S4080BE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 5000 C	S4080BE	16	6Q177001	ROTOR NUT
20 FUEGO LT 5000 C	S4080BE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 5000 C	S4080BE	18	6Q129232	ROTOR
20 FUEGO LT 5000 C	S4080BE	19	6H413601	BAIL TRIP LEVER SPRING
20 FUEGO LT 5000 C	S4080BE	20	6Q129301	BAIL TRIP LEVER
20 FUEGO LT 5000 C	S4080BE	21	6H417701	BAIL TRIP LEVER SCREW
20 FUEGO LT 5000 C	S4080BE	22	6Q129501	ARM LEVER SHAFT
20 FUEGO LT 5000 C	S4080BE	23	6H576101	ARM LEVER SPRING PLATE
20 FUEGO LT 5000 C	S4080BE	24	6H414201	ARM LEVER SPRING
20 FUEGO LT 5000 C	S4080BE	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO LT 5000 C	S4080BE	26	6Q129601	ARM LEVER COVER
20 FUEGO LT 5000 C	S4080BE	27	6Q342901	ARM LEVER COVER SCREW
20 FUEGO LT 5000 C	S4080BE	28	6Q121620	ARM LEVER
20 FUEGO LT 5000 C	S4080BE	29	6Q121701	ARM LEVER COLLAR
20 FUEGO LT 5000 C	S4080BE	30	6Q343401	ARM LEVER SCREW
20 FUEGO LT 5000 C	S4080BE	31	6G195602	ROLLER SCREW
20 FUEGO LT 5000 C	S4080BE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 5000 C	S4080BE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 5000 C	S4080BE	34	6J089901	LINE ROLLER
20 FUEGO LT 5000 C	S4080BE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 5000 C	S4080BE	36	6Q777301	BAIL
20 FUEGO LT 5000 C	S4080BE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 5000 C	S4080BE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 5000 C	S4080BE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 5000 C	S4080BE	40	6J354801	MADSEALED CAP O RING
20 FUEGO LT 5000 C	S4080BE	41	-----	-----
20 FUEGO LT 5000 C	S4080BE	42	6Q266601	MAGSEALED CAP
20 FUEGO LT 5000 C	S4080BE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 5000 C	S4080BE	44	6J001403	CLUTCH RING
20 FUEGO LT 5000 C	S4080BE	45	6Q126201	BEARING PLATE SCREW
20 FUEGO LT 5000 C	S4080BE	46	6Q195601	BEARING PLATE
20 FUEGO LT 5000 C	S4080BE	47	6G535104	PINION BALL BEARING (A)
20 FUEGO LT 5000 C	S4080BE	48	63758502	PINION BEARING (A) WASHER01mm
20 FUEGO LT 5000 C	S4080BE	49	6Q351201	PINION GEAR
20 FUEGO LT 5000 C	S4080BE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 5000 C	S4080BE	51	6G466202	PINON BALL BEARING (B)
20 FUEGO LT 5000 C	S4080BE	52	-----	-----
20 FUEGO LT 5000 C	S4080BE	53	6Q674601	BODY
20 FUEGO LT 5000 C	S4080BE	54	6Q351001	MAIN SHAFT
20 FUEGO LT 5000 C	S4080BE	55	6Q126302	OSCILLATING POST (A)
20 FUEGO LT 5000 C	S4080BE	56	6Q119102	OSCILLATING POST (B)
20 FUEGO LT 5000 C	S4080BE	57	6Q118101	ANTI REVERSE CAM
20 FUEGO LT 5000 C	S4080BE	58	6H697801	ANTI REVERSE CAM SPRING
20 FUEGO LT 5000 C	S4080BE	59	6Q118001	ANTI REVERSE LEVER
20 FUEGO LT 5000 C	S4080BE	60	6Q674801	REAR COVER
20 FUEGO LT 5000 C	S4080BE	61	6Q342901	REAR COVER SCREW
20 FUEGO LT 5000 C	S4080BE	62	6H595701	OSCILLATING GEAR WASHER
20 FUEGO LT 5000 C	S4080BE	63	6Q350901	OSCILLATING GEAR
20 FUEGO LT 5000 C	S4080BE	64	6G466001	OSCILLATING GEAR O RING
20 FUEGO LT 5000 C	S4080BE	65	6H129201	OSCILLATING BEARING WASHER01mm
20 FUEGO LT 5000 C	S4080BE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 5000 C	S4080BE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 5000 C	S4080BE	68	6G670501	DRIVE O RING
20 FUEGO LT 5000 C	S4080BE	69	6Q351301	DRIVE GEAR
20 FUEGO LT 5000 C	S4080BE	70	63758502	DRIVE BEARING WASHER01mm
20 FUEGO LT 5000 C	S4080BE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 5000 C	S4080BE	72	6Q674701	BODY COVER
20 FUEGO LT 5000 C	S4080BE	73	6Q342701	BODY COVER SCREW (A)
20 FUEGO LT 5000 C	S4080BE	74	6Q342601	BODY COVER SCREW (B)
20 FUEGO LT 5000 C	S4080BE	75	6J100201	HANDLE PACKING
20 FUEGO LT 5000 C	S4080BE	76	6Q675201	HANDLE ASSY
20 FUEGO LT 5000 C	S4080BE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 5000 C	S4080BE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 5000 C	S4080BE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 5000 C	S4080BE	80	6Q345101	HANDLE CAP
20 FUEGO LT 5000 C	S4080BE	81	6J639901	ONEWAY CLUTCH WASHER
20 FUEGO LT 6000	S4090BE	1	6Q364201	DRAG KNOB
20 FUEGO LT 6000	S4090BE	2	61704101	DRAG WASHER RETAINER
20 FUEGO LT 6000	S4090BE	3	6J577501	KEY WASHER
20 FUEGO LT 6000	S4090BE	4	6J679001	ATD WASHER ASSY 1PACK 3 PCS
20 FUEGO LT 6000	S4090BE	5	6Q377601	EARED WASHER
20 FUEGO LT 6000	S4090BE	6	6Q703301	SPOOL ASSY
20 FUEGO LT 6000	S4090BE	7	6Q416201	SPOOL BEARING WASHER (A)
20 FUEGO LT 6000	S4090BE	8	6G466206	SPOOL BALL BEARING (A)
20 FUEGO LT 6000	S4090BE	9	6E096505	SPOOL BEARING WASHER (B)

20 FUEGO LT 6000	S4090BE	10	6F050104	SPOOL WASHER (A)
20 FUEGO LT 6000	S4090BE	11	6Q363801	SPOOL WASHER (B)
20 FUEGO LT 6000	S4090BE	12	6Q797701	CLICK LEAF SPRING
20 FUEGO LT 6000	S4090BE	13	6Q798301	CLICK HOLDER
20 FUEGO LT 6000	S4090BE	14	6Q377501	SPOOL WASHER (C)
20 FUEGO LT 6000	S4090BE	15	6H995201	ROTOR NUT PACKING
20 FUEGO LT 6000	S4090BE	16	6Q363701	ROTOR NUT
20 FUEGO LT 6000	S4090BE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 6000	S4090BE	18	6Q134533	ROTOR
20 FUEGO LT 6000	S4090BE	19	6H413601	BAIL TRIP LEVER SPRING
20 FUEGO LT 6000	S4090BE	20	6Q134601	BAIL TRIP LEVER
20 FUEGO LT 6000	S4090BE	21	6H417701	BAIL TRIP LEVER SCREW
20 FUEGO LT 6000	S4090BE	22	6Q134801	ARM LEVER SHAFT
20 FUEGO LT 6000	S4090BE	23	6H576101	ARM LEVER SPRING PLATE
20 FUEGO LT 6000	S4090BE	24	6H640701	ARM LEVER SPRING
20 FUEGO LT 6000	S4090BE	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO LT 6000	S4090BE	26	6Q134901	ARM LEVER COVER
20 FUEGO LT 6000	S4090BE	27	6Q342901	ARM LEVER COVER SCREW
20 FUEGO LT 6000	S4090BE	28	6Q121620	ARM LEVER
20 FUEGO LT 6000	S4090BE	29	6Q121701	ARM LEVER COLLAR
20 FUEGO LT 6000	S4090BE	30	6Q343401	ARM LEVER SCREW
20 FUEGO LT 6000	S4090BE	31	6G195602	ROLLER SCREW
20 FUEGO LT 6000	S4090BE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 6000	S4090BE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 6000	S4090BE	34	6J089901	LINE ROLLER
20 FUEGO LT 6000	S4090BE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 6000	S4090BE	36	6Q135001	BAIL
20 FUEGO LT 6000	S4090BE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 6000	S4090BE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 6000	S4090BE	39	6J289301	MAGSEALED PLATE
20 FUEGO LT 6000	S4090BE	40	6J212901	MADSEALED CAP O RING
20 FUEGO LT 6000	S4090BE	41	6J238801	MAGSEALED CAP WASHER
20 FUEGO LT 6000	S4090BE	42	6Q363501	MAGSEALED CAP
20 FUEGO LT 6000	S4090BE	43	6J309101	ONEWAY CLUTCH
20 FUEGO LT 6000	S4090BE	44	6J690501	CLUTCH RING
20 FUEGO LT 6000	S4090BE	45	6Q195701	BEARING PLATE SCREW
20 FUEGO LT 6000	S4090BE	46	6Q205901	BEARING PLATE
20 FUEGO LT 6000	S4090BE	47	66354801	PINION BALL BEARING (A)
20 FUEGO LT 6000	S4090BE	48	63712824	PINION BEARING (A) WASHER01mm
20 FUEGO LT 6000	S4090BE	49	6Q405001	PINION GEAR
20 FUEGO LT 6000	S4090BE	50	6G572501	PINION SPRING WASHER
20 FUEGO LT 6000	S4090BE	51	6G467108	PINON BALL BEARING (B)
20 FUEGO LT 6000	S4090BE	52	-----	-----
20 FUEGO LT 6000	S4090BE	53	6Q675701	BODY
20 FUEGO LT 6000	S4090BE	54	6Q362601	MAIN SHAFT
20 FUEGO LT 6000	S4090BE	55	6Q126303	OSCILLATING POST (A)
20 FUEGO LT 6000	S4090BE	56	6Q119103	OSCILLATING POST (B)
20 FUEGO LT 6000	S4090BE	57	6Q133401	ANTI REVERSE CAM
20 FUEGO LT 6000	S4090BE	58	6H697801	ANTI REVERSE CAM SPRING
20 FUEGO LT 6000	S4090BE	59	6Q118001	ANTI REVERSE LEVER
20 FUEGO LT 6000	S4090BE	60	6Q675901	REAR COVER
20 FUEGO LT 6000	S4090BE	61	6Q342901	REAR COVER SCREW
20 FUEGO LT 6000	S4090BE	62	6G644201	OSCILLATING GEAR WASHER
20 FUEGO LT 6000	S4090BE	63	6Q133501	OSCILLATING GEAR
20 FUEGO LT 6000	S4090BE	64	6B853101	OSCILLATING GEAR O RING
20 FUEGO LT 6000	S4090BE	65	6G522103	OSCILLATING BEARING WASHER01mm
20 FUEGO LT 6000	S4090BE	66	6G467108	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 6000	S4090BE	67	6H463401	OSCILLATING GEAR SCREW
20 FUEGO LT 6000	S4090BE	68	6G645301	DRIVE O RING
20 FUEGO LT 6000	S4090BE	69	6Q403701	DRIVE GEAR
20 FUEGO LT 6000	S4090BE	70	63737808	DRIVE BEARING WASHER01mm
20 FUEGO LT 6000	S4090BE	71	6G523405	DRIVE BALL BEARING (A)
20 FUEGO LT 6000	S4090BE	72	6Q675801	BODY COVER
20 FUEGO LT 6000	S4090BE	73	6Q342701	BODY COVER SCREW (A)
20 FUEGO LT 6000	S4090BE	74	6Q342601	BODY COVER SCREW (B)
20 FUEGO LT 6000	S4090BE	75	6H730801	HANDLE PACKING
20 FUEGO LT 6000	S4090BE	76	6Q676301	HANDLE ASSY
20 FUEGO LT 6000	S4090BE	77	6B861705	DRIVE BALL BEARING (B)
20 FUEGO LT 6000	S4090BE	78	6G525101	DRIVE BEARING RETAINER
20 FUEGO LT 6000	S4090BE	79	6G672401	HANDLE CAP O RING
20 FUEGO LT 6000	S4090BE	80	6Q364801	HANDLE CAP
20 FUEGO LT 6000	S4090BE	81	-----	-----
20 FUEGO LT 1000D	S4012BE	1	6Q376801	DRAG KNOB
20 FUEGO LT 1000D	S4012BE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 1000D	S4012BE	3	6Q621901	KEY WASHER
20 FUEGO LT 1000D	S4012BE	4	6J678901	DRAG WASHER
20 FUEGO LT 1000D	S4012BE	5	-----	-----
20 FUEGO LT 1000D	S4012BE	6	6Q765701	SPOOL ASSY(2-6)
20 FUEGO LT 1000D	S4012BE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 1000D	S4012BE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 1000D	S4012BE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 1000D	S4012BE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 1000D	S4012BE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 1000D	S4012BE	12	6H416101	CLICK LEAF SPRING
20 FUEGO LT 1000D	S4012BE	13	6M021401	CLICK HOLDER
20 FUEGO LT 1000D	S4012BE	14	6Q344001	ROTOR WASHER
20 FUEGO LT 1000D	S4012BE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 1000D	S4012BE	16	6Q177001	ROTOR NUT
20 FUEGO LT 1000D	S4012BE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 1000D	S4012BE	18	6Q139533	ROTOR
20 FUEGO LT 1000D	S4012BE	19	6H443301	KICK LEVER SPRING

20 FUEGO LT 1000D	S4012BE	20	6Q139601	KICK LEVER
20 FUEGO LT 1000D	S4012BE	21	6H417701	KICK LEVER SCREW
20 FUEGO LT 1000D	S4012BE	22	6Q139801	ARM LEVER SHAFT
20 FUEGO LT 1000D	S4012BE	23	6H576101	ARM LEVER SHAFT PLATE
20 FUEGO LT 1000D	S4012BE	24	6H442401	ARM LEVER SPRING
20 FUEGO LT 1000D	S4012BE	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO LT 1000D	S4012BE	26	6Q146501	ARM LEVER SPRING COVER
20 FUEGO LT 1000D	S4012BE	27	6Q342901	ARM LEVER SPRING COVER SCREW
20 FUEGO LT 1000D	S4012BE	28	6Q121620	ARM LEVER
20 FUEGO LT 1000D	S4012BE	29	6Q121701	ARM LEVER SCREW COLLAR
20 FUEGO LT 1000D	S4012BE	30	6Q343401	ARM LEVER SCREW
20 FUEGO LT 1000D	S4012BE	31	6G195602	ROLLER SCREW
20 FUEGO LT 1000D	S4012BE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 1000D	S4012BE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 1000D	S4012BE	34	6J089901	LINE ROLLER
20 FUEGO LT 1000D	S4012BE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 1000D	S4012BE	36	6Q139901	BAIL
20 FUEGO LT 1000D	S4012BE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 1000D	S4012BE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 1000D	S4012BE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 1000D	S4012BE	40	6J354801	MAGSEALED PLATE O RING
20 FUEGO LT 1000D	S4012BE	41	-----	-----
20 FUEGO LT 1000D	S4012BE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 1000D	S4012BE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 1000D	S4012BE	44	6J001403	CLUTCH RING
20 FUEGO LT 1000D	S4012BE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 1000D	S4012BE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 1000D	S4012BE	47	6G467302	PINION BALL BEARING (A)
20 FUEGO LT 1000D	S4012BE	48	63758502	PINION BEARING WASHER
20 FUEGO LT 1000D	S4012BE	49	6Q375701	PINION GEAR
20 FUEGO LT 1000D	S4012BE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 1000D	S4012BE	51	6H959601	PINION BALL BEARING (B)
20 FUEGO LT 1000D	S4012BE	52	6J387701	PINION BEARING COLLAR
20 FUEGO LT 1000D	S4012BE	53	6Q625801	BODY
20 FUEGO LT 1000D	S4012BE	54	6Q375301	MAIN SHAFT
20 FUEGO LT 1000D	S4012BE	55	-----	-----
20 FUEGO LT 1000D	S4012BE	56	6Q119104	OSCILLATING POST
20 FUEGO LT 1000D	S4012BE	57	6Q118101	STOPPER CAM
20 FUEGO LT 1000D	S4012BE	58	6H697801	STOPPER LEVER SPRING
20 FUEGO LT 1000D	S4012BE	59	6Q118001	STOPPER LEVER
20 FUEGO LT 1000D	S4012BE	60	6Q626501	REAR COVER
20 FUEGO LT 1000D	S4012BE	61	6Q342901	REAR CAP SCREW
20 FUEGO LT 1000D	S4012BE	62	6H607902	OSCILLATING GEAR WASHER
20 FUEGO LT 1000D	S4012BE	63	6Q375201	OSCILLATING GEAR
20 FUEGO LT 1000D	S4012BE	64	6H770601	OSCILLATING GEAR O RING
20 FUEGO LT 1000D	S4012BE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 1000D	S4012BE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 1000D	S4012BE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 1000D	S4012BE	68	6G670501	DRIVE GEAR O RING
20 FUEGO LT 1000D	S4012BE	69	6Q375801	DRIVE GEAR
20 FUEGO LT 1000D	S4012BE	70	63758502	DRIVE WASHER
20 FUEGO LT 1000D	S4012BE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 1000D	S4012BE	72	6Q625901	BODY COVER
20 FUEGO LT 1000D	S4012BE	73	6Q342701	BODY COVER SCREW (A)
20 FUEGO LT 1000D	S4012BE	74	6Q342601	BODY COVER SCREW (B)
20 FUEGO LT 1000D	S4012BE	75	6J100201	BODY COVER PACKING
20 FUEGO LT 1000D	S4012BE	76	6Q663401	HANDLE ASSY
20 FUEGO LT 1000D	S4012BE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 1000D	S4012BE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 1000D	S4012BE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 1000D	S4012BE	80	6Q345101	HANDLE CAP
20 FUEGO LT 1000D	S4012BE	81	6J639901	ONEWAY CLUTCH WASHER
20 FUEGO LT 2000D	S4022BE	1	6Q376801	DRAG KNOB
20 FUEGO LT 2000D	S4022BE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 2000D	S4022BE	3	6Q621901	KEY WASHER
20 FUEGO LT 2000D	S4022BE	4	6J678901	DRAG WASHER
20 FUEGO LT 2000D	S4022BE	5	-----	-----
20 FUEGO LT 2000D	S4022BE	6	6Q766001	SPOOL ASSY(2-6)
20 FUEGO LT 2000D	S4022BE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 2000D	S4022BE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 2000D	S4022BE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 2000D	S4022BE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 2000D	S4022BE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 2000D	S4022BE	12	6H416101	CLICK LEAF SPRING
20 FUEGO LT 2000D	S4022BE	13	6M021401	CLICK HOLDER
20 FUEGO LT 2000D	S4022BE	14	6Q344001	ROTOR WASHER
20 FUEGO LT 2000D	S4022BE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 2000D	S4022BE	16	6Q177001	ROTOR NUT
20 FUEGO LT 2000D	S4022BE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 2000D	S4022BE	18	6Q139533	ROTOR
20 FUEGO LT 2000D	S4022BE	19	6H443301	KICK LEVER SPRING
20 FUEGO LT 2000D	S4022BE	20	6Q139601	KICK LEVER
20 FUEGO LT 2000D	S4022BE	21	6H417701	KICK LEVER SCREW
20 FUEGO LT 2000D	S4022BE	22	6Q139801	ARM LEVER SHAFT
20 FUEGO LT 2000D	S4022BE	23	6H576101	ARM LEVER SHAFT PLATE
20 FUEGO LT 2000D	S4022BE	24	6H442401	ARM LEVER SPRING
20 FUEGO LT 2000D	S4022BE	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO LT 2000D	S4022BE	26	6Q146501	ARM LEVER SPRING COVER
20 FUEGO LT 2000D	S4022BE	27	6Q342901	ARM LEVER SPRING COVER SCREW
20 FUEGO LT 2000D	S4022BE	28	6Q121620	ARM LEVER
20 FUEGO LT 2000D	S4022BE	29	6Q121701	ARM LEVER SCREW COLLAR

20 FUEGO LT 2000D	S4022BE	30	6Q343401	ARM LEVER SCREW
20 FUEGO LT 2000D	S4022BE	31	6G195602	ROLLER SCREW
20 FUEGO LT 2000D	S4022BE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 2000D	S4022BE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 2000D	S4022BE	34	6J089901	LINE ROLLER
20 FUEGO LT 2000D	S4022BE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 2000D	S4022BE	36	6Q139901	BAIL
20 FUEGO LT 2000D	S4022BE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 2000D	S4022BE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 2000D	S4022BE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 2000D	S4022BE	40	6J354801	MAGSEALED PLATE O RING
20 FUEGO LT 2000D	S4022BE	41	-----	-----
20 FUEGO LT 2000D	S4022BE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 2000D	S4022BE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 2000D	S4022BE	44	6J001403	CLUTCH RING
20 FUEGO LT 2000D	S4022BE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 2000D	S4022BE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 2000D	S4022BE	47	6G467302	PINION BALL BEARING (A)
20 FUEGO LT 2000D	S4022BE	48	63758502	PINION BEARING WASHER
20 FUEGO LT 2000D	S4022BE	49	6Q375701	PINION GEAR
20 FUEGO LT 2000D	S4022BE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 2000D	S4022BE	51	6H959601	PINION BALL BEARING (B)
20 FUEGO LT 2000D	S4022BE	52	6J387701	PINION BEARING COLLAR
20 FUEGO LT 2000D	S4022BE	53	6Q625801	BODY
20 FUEGO LT 2000D	S4022BE	54	6Q375301	MAIN SHAFT
20 FUEGO LT 2000D	S4022BE	55	-----	-----
20 FUEGO LT 2000D	S4022BE	56	6Q119104	OSCILLATING POST
20 FUEGO LT 2000D	S4022BE	57	6Q118101	STOPPER CAM
20 FUEGO LT 2000D	S4022BE	58	6H697801	STOPPER LEVER SPRING
20 FUEGO LT 2000D	S4022BE	59	6Q118001	STOPPER LEVER
20 FUEGO LT 2000D	S4022BE	60	6Q626501	REAR COVER
20 FUEGO LT 2000D	S4022BE	61	6Q342901	REAR CAP SCREW
20 FUEGO LT 2000D	S4022BE	62	6H607902	OSCILLATING GEAR WASHER
20 FUEGO LT 2000D	S4022BE	63	6Q375201	OSCILLATING GEAR
20 FUEGO LT 2000D	S4022BE	64	6H770601	OSCILLATING GEAR O RING
20 FUEGO LT 2000D	S4022BE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 2000D	S4022BE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 2000D	S4022BE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 2000D	S4022BE	68	6G670501	DRIVE GEAR O RING
20 FUEGO LT 2000D	S4022BE	69	6Q375801	DRIVE GEAR
20 FUEGO LT 2000D	S4022BE	70	63758502	DRIVE WASHER
20 FUEGO LT 2000D	S4022BE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 2000D	S4022BE	72	6Q625901	BODY COVER
20 FUEGO LT 2000D	S4022BE	73	6Q342701	BODY COVER SCREW (A)
20 FUEGO LT 2000D	S4022BE	74	6Q342601	BODY COVER SCREW (B)
20 FUEGO LT 2000D	S4022BE	75	6J100201	BODY COVER PACKING
20 FUEGO LT 2000D	S4022BE	76	6Q663401	HANDLE ASSY
20 FUEGO LT 2000D	S4022BE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 2000D	S4022BE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 2000D	S4022BE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 2000D	S4022BE	80	6Q345101	HANDLE CAP
20 FUEGO LT 2000D	S4022BE	81	6J639901	ONEWAY CLUTCH WASHER
20 FUEGO LT 2500D	S4042BE	1	6Q346201	DRAG KNOB
20 FUEGO LT 2500D	S4042BE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 2500D	S4042BE	3	6Q621901	KEY WASHER
20 FUEGO LT 2500D	S4042BE	4	6J678801	DRAG WASHER
20 FUEGO LT 2500D	S4042BE	5	6Q346001	EARED WASHER
20 FUEGO LT 2500D	S4042BE	6	6Q766301	SPOOL ASSY(2-6)
20 FUEGO LT 2500D	S4042BE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 2500D	S4042BE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 2500D	S4042BE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 2500D	S4042BE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 2500D	S4042BE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 2500D	S4042BE	12	6H416101	CLICK LEAF SPRING
20 FUEGO LT 2500D	S4042BE	13	6M021401	CLICK HOLDER
20 FUEGO LT 2500D	S4042BE	14	6Q344001	ROTOR WASHER
20 FUEGO LT 2500D	S4042BE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 2500D	S4042BE	16	6Q177001	ROTOR NUT
20 FUEGO LT 2500D	S4042BE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 2500D	S4042BE	18	6Q343022	ROTOR
20 FUEGO LT 2500D	S4042BE	19	6H413601	KICK LEVER SPRING
20 FUEGO LT 2500D	S4042BE	20	6Q343101	KICK LEVER
20 FUEGO LT 2500D	S4042BE	21	6H417701	KICK LEVER SCREW
20 FUEGO LT 2500D	S4042BE	22	6Q343301	ARM LEVER SHAFT
20 FUEGO LT 2500D	S4042BE	23	6H576101	ARM LEVER SHAFT PLATE
20 FUEGO LT 2500D	S4042BE	24	6J642801	ARM LEVER SPRING
20 FUEGO LT 2500D	S4042BE	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO LT 2500D	S4042BE	26	6Q343501	ARM LEVER SPRING COVER
20 FUEGO LT 2500D	S4042BE	27	6Q342901	ARM LEVER SPRING COVER SCREW
20 FUEGO LT 2500D	S4042BE	28	6Q121620	ARM LEVER
20 FUEGO LT 2500D	S4042BE	29	6Q121701	ARM LEVER SCREW COLLAR
20 FUEGO LT 2500D	S4042BE	30	6Q343401	ARM LEVER SCREW
20 FUEGO LT 2500D	S4042BE	31	6G195602	ROLLER SCREW
20 FUEGO LT 2500D	S4042BE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 2500D	S4042BE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 2500D	S4042BE	34	6J089901	LINE ROLLER
20 FUEGO LT 2500D	S4042BE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 2500D	S4042BE	36	6Q777001	BAIL
20 FUEGO LT 2500D	S4042BE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 2500D	S4042BE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 2500D	S4042BE	39	6J688201	MAGSEALED PLATE

20 FUEGO LT 2500D	S4042BE	40	6J354801	MAGSEALED PLATE O RING
20 FUEGO LT 2500D	S4042BE	41	-----	-----
20 FUEGO LT 2500D	S4042BE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 2500D	S4042BE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 2500D	S4042BE	44	6J001403	CLUTCH RING
20 FUEGO LT 2500D	S4042BE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 2500D	S4042BE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 2500D	S4042BE	47	6G467302	PINION BALL BEARING (A)
20 FUEGO LT 2500D	S4042BE	48	63758502	PINION BEARING WASHER
20 FUEGO LT 2500D	S4042BE	49	6Q341701	PINION GEAR
20 FUEGO LT 2500D	S4042BE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 2500D	S4042BE	51	6H959601	PINION BALL BEARING (B)
20 FUEGO LT 2500D	S4042BE	52	-----	-----
20 FUEGO LT 2500D	S4042BE	53	6Q624201	BODY
20 FUEGO LT 2500D	S4042BE	54	6Q341501	MAIN SHAFT
20 FUEGO LT 2500D	S4042BE	55	6Q126301	OSCILLATING POST (A)
20 FUEGO LT 2500D	S4042BE	56	6Q119101	OSCILLATING POST (B)
20 FUEGO LT 2500D	S4042BE	57	6Q118101	STOPPER CAM
20 FUEGO LT 2500D	S4042BE	58	6H697801	STOPPER LEVER SPRING
20 FUEGO LT 2500D	S4042BE	59	6Q118001	STOPPER LEVER
20 FUEGO LT 2500D	S4042BE	60	6Q626401	REAR COVER
20 FUEGO LT 2500D	S4042BE	61	6Q342901	REAR CAP SCREW
20 FUEGO LT 2500D	S4042BE	62	6H595701	OSCILLATING GEAR WASHER
20 FUEGO LT 2500D	S4042BE	63	6Q139001	OSCILLATING GEAR
20 FUEGO LT 2500D	S4042BE	64	6H770601	OSCILLATING GEAR O RING
20 FUEGO LT 2500D	S4042BE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 2500D	S4042BE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 2500D	S4042BE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 2500D	S4042BE	68	6G670501	DRIVE GEAR O RING
20 FUEGO LT 2500D	S4042BE	69	6Q341801	DRIVE GEAR
20 FUEGO LT 2500D	S4042BE	70	63758502	DRIVE WASHER
20 FUEGO LT 2500D	S4042BE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 2500D	S4042BE	72	6Q624301	BODY COVER
20 FUEGO LT 2500D	S4042BE	73	6Q342701	BODY COVER SCREW (A)
20 FUEGO LT 2500D	S4042BE	74	6Q342601	BODY COVER SCREW (B)
20 FUEGO LT 2500D	S4042BE	75	6J100201	BODY COVER PACKING
20 FUEGO LT 2500D	S4042BE	76	6Q663601	HANDLE ASSY
20 FUEGO LT 2500D	S4042BE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 2500D	S4042BE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 2500D	S4042BE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 2500D	S4042BE	80	6Q345101	HANDLE CAP
20 FUEGO LT 2500D	S4042BE	81	6J639901	ONEWAY CLUTCH WASHER
20 FUEGO LT 3000DC	S4052BE	1	6Q346201	DRAG KNOB
20 FUEGO LT 3000DC	S4052BE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 3000DC	S4052BE	3	6Q621901	KEY WASHER
20 FUEGO LT 3000DC	S4052BE	4	6J678801	DRAG WASHER
20 FUEGO LT 3000DC	S4052BE	5	6Q346001	EARED WASHER
20 FUEGO LT 3000DC	S4052BE	6	6Q766601	SPOOL ASSY(2-6)
20 FUEGO LT 3000DC	S4052BE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 3000DC	S4052BE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 3000DC	S4052BE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 3000DC	S4052BE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 3000DC	S4052BE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 3000DC	S4052BE	12	6H416101	CLICK LEAF SPRING
20 FUEGO LT 3000DC	S4052BE	13	6M021401	CLICK HOLDER
20 FUEGO LT 3000DC	S4052BE	14	6Q344001	ROTOR WASHER
20 FUEGO LT 3000DC	S4052BE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 3000DC	S4052BE	16	6Q177001	ROTOR NUT
20 FUEGO LT 3000DC	S4052BE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 3000DC	S4052BE	18	6Q120531	ROTOR
20 FUEGO LT 3000DC	S4052BE	19	6H413601	KICK LEVER SPRING
20 FUEGO LT 3000DC	S4052BE	20	6Q120701	KICK LEVER
20 FUEGO LT 3000DC	S4052BE	21	6H417701	KICK LEVER SCREW
20 FUEGO LT 3000DC	S4052BE	22	6Q121201	ARM LEVER SHAFT
20 FUEGO LT 3000DC	S4052BE	23	6H576101	ARM LEVER SHAFT PLATE
20 FUEGO LT 3000DC	S4052BE	24	6H545701	ARM LEVER SPRING
20 FUEGO LT 3000DC	S4052BE	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO LT 3000DC	S4052BE	26	6Q121801	ARM LEVER SPRING COVER
20 FUEGO LT 3000DC	S4052BE	27	6Q342901	ARM LEVER SPRING COVER SCREW
20 FUEGO LT 3000DC	S4052BE	28	6Q121620	ARM LEVER
20 FUEGO LT 3000DC	S4052BE	29	6Q121701	ARM LEVER SCREW COLLAR
20 FUEGO LT 3000DC	S4052BE	30	6Q343401	ARM LEVER SCREW
20 FUEGO LT 3000DC	S4052BE	31	6G195602	ROLLER SCREW
20 FUEGO LT 3000DC	S4052BE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 3000DC	S4052BE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 3000DC	S4052BE	34	6J089901	LINE ROLLER
20 FUEGO LT 3000DC	S4052BE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 3000DC	S4052BE	36	6Q777101	BAIL
20 FUEGO LT 3000DC	S4052BE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 3000DC	S4052BE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 3000DC	S4052BE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 3000DC	S4052BE	40	6J354801	MAGSEALED PLATE O RING
20 FUEGO LT 3000DC	S4052BE	41	-----	-----
20 FUEGO LT 3000DC	S4052BE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 3000DC	S4052BE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 3000DC	S4052BE	44	6J001403	CLUTCH RING
20 FUEGO LT 3000DC	S4052BE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 3000DC	S4052BE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 3000DC	S4052BE	47	6G467302	PINION BALL BEARING (A)
20 FUEGO LT 3000DC	S4052BE	48	63758502	PINION BEARING WASHER
20 FUEGO LT 3000DC	S4052BE	49	6Q341701	PINION GEAR

20 FUEGO LT 3000DC	S4052BE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 3000DC	S4052BE	51	6H959601	PINION BALL BEARING (B)
20 FUEGO LT 3000DC	S4052BE	52	-----	-----
20 FUEGO LT 3000DC	S4052BE	53	6Q659601	BODY
20 FUEGO LT 3000DC	S4052BE	54	6Q461401	MAIN SHAFT
20 FUEGO LT 3000DC	S4052BE	55	6Q126301	OSCILLATING POST (A)
20 FUEGO LT 3000DC	S4052BE	56	6Q119101	OSCILLATING POST (B)
20 FUEGO LT 3000DC	S4052BE	57	6Q118101	STOPPER CAM
20 FUEGO LT 3000DC	S4052BE	58	6H697801	STOPPER LEVER SPRING
20 FUEGO LT 3000DC	S4052BE	59	6Q118001	STOPPER LEVER
20 FUEGO LT 3000DC	S4052BE	60	6Q626401	REAR COVER
20 FUEGO LT 3000DC	S4052BE	61	6Q342901	REAR CAP SCREW
20 FUEGO LT 3000DC	S4052BE	62	6H595701	OSCILLATING GEAR WASHER
20 FUEGO LT 3000DC	S4052BE	63	6Q118401	OSCILLATING GEAR
20 FUEGO LT 3000DC	S4052BE	64	6H770601	OSCILLATING GEAR O RING
20 FUEGO LT 3000DC	S4052BE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 3000DC	S4052BE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 3000DC	S4052BE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 3000DC	S4052BE	68	6G670501	DRIVE GEAR O RING
20 FUEGO LT 3000DC	S4052BE	69	6Q341801	DRIVE GEAR
20 FUEGO LT 3000DC	S4052BE	70	63758502	DRIVE WASHER
20 FUEGO LT 3000DC	S4052BE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 3000DC	S4052BE	72	6Q624301	BODY COVER
20 FUEGO LT 3000DC	S4052BE	73	6Q342701	BODY COVER SCREW (A)
20 FUEGO LT 3000DC	S4052BE	74	6Q342601	BODY COVER SCREW (B)
20 FUEGO LT 3000DC	S4052BE	75	6J100201	BODY COVER PACKING
20 FUEGO LT 3000DC	S4052BE	76	6Q663601	HANDLE ASSY
20 FUEGO LT 3000DC	S4052BE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 3000DC	S4052BE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 3000DC	S4052BE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 3000DC	S4052BE	80	6Q345101	HANDLE CAP
20 FUEGO LT 3000DC	S4052BE	81	6J639901	ONEWAY CLUTCH WASHER
20 FUEGO LT 4000DC	S4072BE	1	6Q352901	DRAG KNOB
20 FUEGO LT 4000DC	S4072BE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 4000DC	S4072BE	3	6Q621901	KEY WASHER
20 FUEGO LT 4000DC	S4072BE	4	6J678801	DRAG WASHER
20 FUEGO LT 4000DC	S4072BE	5	6Q346001	EARED WASHER
20 FUEGO LT 4000DC	S4072BE	6	6Q766901	SPOOL ASSY(2-6)
20 FUEGO LT 4000DC	S4072BE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 4000DC	S4072BE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 4000DC	S4072BE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 4000DC	S4072BE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 4000DC	S4072BE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 4000DC	S4072BE	12	6H416101	CLICK LEAF SPRING
20 FUEGO LT 4000DC	S4072BE	13	6M021401	CLICK HOLDER
20 FUEGO LT 4000DC	S4072BE	14	6Q344001	ROTOR WASHER
20 FUEGO LT 4000DC	S4072BE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 4000DC	S4072BE	16	6Q177001	ROTOR NUT
20 FUEGO LT 4000DC	S4072BE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 4000DC	S4072BE	18	6Q351817	ROTOR
20 FUEGO LT 4000DC	S4072BE	19	6H413601	KICK LEVER SPRING
20 FUEGO LT 4000DC	S4072BE	20	6Q351901	KICK LEVER
20 FUEGO LT 4000DC	S4072BE	21	6H417701	KICK LEVER SCREW
20 FUEGO LT 4000DC	S4072BE	22	6Q129501	ARM LEVER SHAFT
20 FUEGO LT 4000DC	S4072BE	23	6H576101	ARM LEVER SHAFT PLATE
20 FUEGO LT 4000DC	S4072BE	24	6H414201	ARM LEVER SPRING
20 FUEGO LT 4000DC	S4072BE	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO LT 4000DC	S4072BE	26	6Q352101	ARM LEVER SPRING COVER
20 FUEGO LT 4000DC	S4072BE	27	6Q342901	ARM LEVER SPRING COVER SCREW
20 FUEGO LT 4000DC	S4072BE	28	6Q121620	ARM LEVER
20 FUEGO LT 4000DC	S4072BE	29	6Q121701	ARM LEVER SCREW COLLAR
20 FUEGO LT 4000DC	S4072BE	30	6Q343401	ARM LEVER SCREW
20 FUEGO LT 4000DC	S4072BE	31	6G195602	ROLLER SCREW
20 FUEGO LT 4000DC	S4072BE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 4000DC	S4072BE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 4000DC	S4072BE	34	6J089901	LINE ROLLER
20 FUEGO LT 4000DC	S4072BE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 4000DC	S4072BE	36	6Q777201	BAIL
20 FUEGO LT 4000DC	S4072BE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 4000DC	S4072BE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 4000DC	S4072BE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 4000DC	S4072BE	40	6J354801	MAGSEALED PLATE O RING
20 FUEGO LT 4000DC	S4072BE	41	-----	-----
20 FUEGO LT 4000DC	S4072BE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 4000DC	S4072BE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 4000DC	S4072BE	44	6J001403	CLUTCH RING
20 FUEGO LT 4000DC	S4072BE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 4000DC	S4072BE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 4000DC	S4072BE	47	6G535104	PINION BALL BEARING (A)
20 FUEGO LT 4000DC	S4072BE	48	63758502	PINION BEARING WASHER
20 FUEGO LT 4000DC	S4072BE	49	6Q351201	PINION GEAR
20 FUEGO LT 4000DC	S4072BE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 4000DC	S4072BE	51	6G466202	PINION BALL BEARING (B)
20 FUEGO LT 4000DC	S4072BE	52	-----	-----
20 FUEGO LT 4000DC	S4072BE	53	6Q674601	BODY
20 FUEGO LT 4000DC	S4072BE	54	6Q351001	MAIN SHAFT
20 FUEGO LT 4000DC	S4072BE	55	6Q126302	OSCILLATING POST (A)
20 FUEGO LT 4000DC	S4072BE	56	6Q119102	OSCILLATING POST (B)
20 FUEGO LT 4000DC	S4072BE	57	6Q118101	STOPPER CAM
20 FUEGO LT 4000DC	S4072BE	58	6H697801	STOPPER LEVER SPRING
20 FUEGO LT 4000DC	S4072BE	59	6Q118001	STOPPER LEVER

20 FUEGO LT 4000DC	S4072BE	60	6Q674801	REAR COVER
20 FUEGO LT 4000DC	S4072BE	61	6Q342901	REAR CAP SCREW
20 FUEGO LT 4000DC	S4072BE	62	6H595701	OSCILLATING GEAR WASHER
20 FUEGO LT 4000DC	S4072BE	63	6Q350901	OSCILLATING GEAR
20 FUEGO LT 4000DC	S4072BE	64	6G466001	OSCILLATING GEAR O RING
20 FUEGO LT 4000DC	S4072BE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 4000DC	S4072BE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 4000DC	S4072BE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 4000DC	S4072BE	68	6G670501	DRIVE GEAR O RING
20 FUEGO LT 4000DC	S4072BE	69	6Q351301	DRIVE GEAR
20 FUEGO LT 4000DC	S4072BE	70	63758502	DRIVE WASHER
20 FUEGO LT 4000DC	S4072BE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 4000DC	S4072BE	72	6Q674701	BODY COVER
20 FUEGO LT 4000DC	S4072BE	73	6Q342701	BODY COVER SCREW (A)
20 FUEGO LT 4000DC	S4072BE	74	6Q342601	BODY COVER SCREW (B)
20 FUEGO LT 4000DC	S4072BE	75	6J100201	BODY COVER PACKING
20 FUEGO LT 4000DC	S4072BE	76	6Q675201	HANDLE ASSY
20 FUEGO LT 4000DC	S4072BE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 4000DC	S4072BE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 4000DC	S4072BE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 4000DC	S4072BE	80	6Q345101	HANDLE CAP
20 FUEGO LT 4000DC	S4072BE	81	6J639901	ONEWAY CLUTCH WASHER
20 FUEGO LT 5000DC	S4082BE	1	6Q352901	DRAG KNOB
20 FUEGO LT 5000DC	S4082BE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 5000DC	S4082BE	3	6Q621901	KEY WASHER
20 FUEGO LT 5000DC	S4082BE	4	6J678801	DRAG WASHER
20 FUEGO LT 5000DC	S4082BE	5	6Q346001	EARED WASHER
20 FUEGO LT 5000DC	S4082BE	6	6Q767201	SPOOL ASSY(2-6)
20 FUEGO LT 5000DC	S4082BE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 5000DC	S4082BE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 5000DC	S4082BE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 5000DC	S4082BE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 5000DC	S4082BE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 5000DC	S4082BE	12	6H416101	CLICK LEAF SPRING
20 FUEGO LT 5000DC	S4082BE	13	6M021401	CLICK HOLDER
20 FUEGO LT 5000DC	S4082BE	14	6Q344001	ROTOR WASHER
20 FUEGO LT 5000DC	S4082BE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 5000DC	S4082BE	16	6Q177001	ROTOR NUT
20 FUEGO LT 5000DC	S4082BE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 5000DC	S4082BE	18	6Q129226	ROTOR
20 FUEGO LT 5000DC	S4082BE	19	6H413601	KICK LEVER SPRING
20 FUEGO LT 5000DC	S4082BE	20	6Q129301	KICK LEVER
20 FUEGO LT 5000DC	S4082BE	21	6H417701	KICK LEVER SCREW
20 FUEGO LT 5000DC	S4082BE	22	6Q129501	ARM LEVER SHAFT
20 FUEGO LT 5000DC	S4082BE	23	6H576101	ARM LEVER SHAFT PLATE
20 FUEGO LT 5000DC	S4082BE	24	6H414201	ARM LEVER SPRING
20 FUEGO LT 5000DC	S4082BE	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO LT 5000DC	S4082BE	26	6Q129601	ARM LEVER SPRING COVER
20 FUEGO LT 5000DC	S4082BE	27	6Q342901	ARM LEVER SPRING COVER SCREW
20 FUEGO LT 5000DC	S4082BE	28	6Q121620	ARM LEVER
20 FUEGO LT 5000DC	S4082BE	29	6Q121701	ARM LEVER SCREW COLLAR
20 FUEGO LT 5000DC	S4082BE	30	6Q343401	ARM LEVER SCREW
20 FUEGO LT 5000DC	S4082BE	31	6G195602	ROLLER SCREW
20 FUEGO LT 5000DC	S4082BE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 5000DC	S4082BE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 5000DC	S4082BE	34	6J089901	LINE ROLLER
20 FUEGO LT 5000DC	S4082BE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 5000DC	S4082BE	36	6Q777301	BAIL
20 FUEGO LT 5000DC	S4082BE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 5000DC	S4082BE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 5000DC	S4082BE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 5000DC	S4082BE	40	6J354801	MAGSEALED PLATE O RING
20 FUEGO LT 5000DC	S4082BE	41	-----	-----
20 FUEGO LT 5000DC	S4082BE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 5000DC	S4082BE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 5000DC	S4082BE	44	6J001403	CLUTCH RING
20 FUEGO LT 5000DC	S4082BE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 5000DC	S4082BE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 5000DC	S4082BE	47	6G535104	PINION BALL BEARING (A)
20 FUEGO LT 5000DC	S4082BE	48	63758502	PINION BEARING WASHER
20 FUEGO LT 5000DC	S4082BE	49	6Q351201	PINION GEAR
20 FUEGO LT 5000DC	S4082BE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 5000DC	S4082BE	51	6G466202	PINION BALL BEARING (B)
20 FUEGO LT 5000DC	S4082BE	52	-----	-----
20 FUEGO LT 5000DC	S4082BE	53	6Q674601	BODY
20 FUEGO LT 5000DC	S4082BE	54	6Q351001	MAIN SHAFT
20 FUEGO LT 5000DC	S4082BE	55	6Q126302	OSCILLATING POST (A)
20 FUEGO LT 5000DC	S4082BE	56	6Q119102	OSCILLATING POST (B)
20 FUEGO LT 5000DC	S4082BE	57	6Q118101	STOPPER CAM
20 FUEGO LT 5000DC	S4082BE	58	6H697801	STOPPER LEVER SPRING
20 FUEGO LT 5000DC	S4082BE	59	6Q118001	STOPPER LEVER
20 FUEGO LT 5000DC	S4082BE	60	6Q674801	REAR COVER
20 FUEGO LT 5000DC	S4082BE	61	6Q342901	REAR CAP SCREW
20 FUEGO LT 5000DC	S4082BE	62	6H595701	OSCILLATING GEAR WASHER
20 FUEGO LT 5000DC	S4082BE	63	6Q350901	OSCILLATING GEAR
20 FUEGO LT 5000DC	S4082BE	64	6G466001	OSCILLATING GEAR O RING
20 FUEGO LT 5000DC	S4082BE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 5000DC	S4082BE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 5000DC	S4082BE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 5000DC	S4082BE	68	6G670501	DRIVE GEAR O RING
20 FUEGO LT 5000DC	S4082BE	69	6Q351301	DRIVE GEAR

20 FUEGO LT 5000DC	S4082BE	70	63758502	DRIVE WASHER
20 FUEGO LT 5000DC	S4082BE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 5000DC	S4082BE	72	6Q674701	BODY COVER
20 FUEGO LT 5000DC	S4082BE	73	6Q342701	BODY COVER SCREW (A)
20 FUEGO LT 5000DC	S4082BE	74	6Q342601	BODY COVER SCREW (B)
20 FUEGO LT 5000DC	S4082BE	75	6J100201	BODY COVER PACKING
20 FUEGO LT 5000DC	S4082BE	76	6Q675201	HANDLE ASSY
20 FUEGO LT 5000DC	S4082BE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 5000DC	S4082BE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 5000DC	S4082BE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 5000DC	S4082BE	80	6Q345101	HANDLE CAP
20 FUEGO LT 5000DC	S4082BE	81	6J639901	ONEWAY CLUTCH WASHER
20 FUEGO LT 6000D	S4092BE	1	6Q364201	DRAG KNOB
20 FUEGO LT 6000D	S4092BE	2	61704101	DRAG WASHER RETAINER
20 FUEGO LT 6000D	S4092BE	3	6J577501	KEY WASHER
20 FUEGO LT 6000D	S4092BE	4	6J679001	DRAG WASHER
20 FUEGO LT 6000D	S4092BE	5	6Q377601	EARED WASHER
20 FUEGO LT 6000D	S4092BE	6	6Q767501	SPOOL ASSY(2-6)
20 FUEGO LT 6000D	S4092BE	7	6Q416201	SPOOL WASHER (A)
20 FUEGO LT 6000D	S4092BE	8	6G466206	SPOOL BALL BEARING
20 FUEGO LT 6000D	S4092BE	9	6E096505	SPOOL WASHER (B)
20 FUEGO LT 6000D	S4092BE	10	6F050104	SPOOL WASHER (C)
20 FUEGO LT 6000D	S4092BE	11	6Q363801	SPOOL WASHER (D)
20 FUEGO LT 6000D	S4092BE	12	6H416101	CLICK LEAF SPRING
20 FUEGO LT 6000D	S4092BE	13	6M021501	CLICK HOLDER
20 FUEGO LT 6000D	S4092BE	14	6Q377501	ROTOR WASHER
20 FUEGO LT 6000D	S4092BE	15	6H995201	ROTOR NUT PACKING
20 FUEGO LT 6000D	S4092BE	16	6Q363701	ROTOR NUT
20 FUEGO LT 6000D	S4092BE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 6000D	S4092BE	18	6Q134527	ROTOR
20 FUEGO LT 6000D	S4092BE	19	6H413601	KICK LEVER SPRING
20 FUEGO LT 6000D	S4092BE	20	6Q134601	KICK LEVER
20 FUEGO LT 6000D	S4092BE	21	6H417701	KICK LEVER SCREW
20 FUEGO LT 6000D	S4092BE	22	6Q134801	ARM LEVER SHAFT
20 FUEGO LT 6000D	S4092BE	23	6H576101	ARM LEVER SHAFT PLATE
20 FUEGO LT 6000D	S4092BE	24	6H640701	ARM LEVER SPRING
20 FUEGO LT 6000D	S4092BE	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO LT 6000D	S4092BE	26	6Q134901	ARM LEVER SPRING COVER
20 FUEGO LT 6000D	S4092BE	27	6Q342901	ARM LEVER SPRING COVER SCREW
20 FUEGO LT 6000D	S4092BE	28	6Q121620	ARM LEVER
20 FUEGO LT 6000D	S4092BE	29	6Q121701	ARM LEVER SCREW COLLAR
20 FUEGO LT 6000D	S4092BE	30	6Q343401	ARM LEVER SCREW
20 FUEGO LT 6000D	S4092BE	31	6G195602	ROLLER SCREW
20 FUEGO LT 6000D	S4092BE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 6000D	S4092BE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 6000D	S4092BE	34	6J089901	LINE ROLLER
20 FUEGO LT 6000D	S4092BE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 6000D	S4092BE	36	6Q135001	BAIL
20 FUEGO LT 6000D	S4092BE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 6000D	S4092BE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 6000D	S4092BE	39	6J289301	MAGSEALED PLATE
20 FUEGO LT 6000D	S4092BE	40	6J212901	MAGSEALED PLATE O RING
20 FUEGO LT 6000D	S4092BE	41	6J238801	MAGSEALED PLATE WASHER
20 FUEGO LT 6000D	S4092BE	42	6Q363501	SHIELD PLATE
20 FUEGO LT 6000D	S4092BE	43	6J309101	ONEWAY CLUTCH
20 FUEGO LT 6000D	S4092BE	44	6J690501	CLUTCH RING
20 FUEGO LT 6000D	S4092BE	45	6Q195701	PINION BEARING PLATE SCREW
20 FUEGO LT 6000D	S4092BE	46	6Q205901	PINION BEARING PLATE
20 FUEGO LT 6000D	S4092BE	47	66354801	PINION BALL BEARING (A)
20 FUEGO LT 6000D	S4092BE	48	63712824	PINION BEARING WASHER
20 FUEGO LT 6000D	S4092BE	49	6Q405001	PINION GEAR
20 FUEGO LT 6000D	S4092BE	50	6G572501	PINION SPRING WASHER
20 FUEGO LT 6000D	S4092BE	51	6G467108	PINION BALL BEARING (B)
20 FUEGO LT 6000D	S4092BE	52	-----	-----
20 FUEGO LT 6000D	S4092BE	53	6Q675701	BODY
20 FUEGO LT 6000D	S4092BE	54	6Q362601	MAIN SHAFT
20 FUEGO LT 6000D	S4092BE	55	6Q126303	OSCILLATING POST (A)
20 FUEGO LT 6000D	S4092BE	56	6Q119103	OSCILLATING POST (B)
20 FUEGO LT 6000D	S4092BE	57	6Q133401	STOPPER CAM
20 FUEGO LT 6000D	S4092BE	58	6H697801	STOPPER LEVER SPRING
20 FUEGO LT 6000D	S4092BE	59	6Q118001	STOPPER LEVER
20 FUEGO LT 6000D	S4092BE	60	6Q675901	REAR COVER
20 FUEGO LT 6000D	S4092BE	61	6Q342901	REAR CAP SCREW
20 FUEGO LT 6000D	S4092BE	62	6G644201	OSCILLATING GEAR WASHER
20 FUEGO LT 6000D	S4092BE	63	6Q133501	OSCILLATING GEAR
20 FUEGO LT 6000D	S4092BE	64	6B853101	OSCILLATING GEAR O RING
20 FUEGO LT 6000D	S4092BE	65	6G522103	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 6000D	S4092BE	66	6G467108	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 6000D	S4092BE	67	6H463401	OSCILLATING GEAR SCREW
20 FUEGO LT 6000D	S4092BE	68	6G645301	DRIVE GEAR O RING
20 FUEGO LT 6000D	S4092BE	69	6Q403701	DRIVE GEAR
20 FUEGO LT 6000D	S4092BE	70	63737808	DRIVE WASHER
20 FUEGO LT 6000D	S4092BE	71	6G523405	DRIVE BALL BEARING (A)
20 FUEGO LT 6000D	S4092BE	72	6Q675801	BODY COVER
20 FUEGO LT 6000D	S4092BE	73	6Q342701	BODY COVER SCREW (A)
20 FUEGO LT 6000D	S4092BE	74	6Q342601	BODY COVER SCREW (B)
20 FUEGO LT 6000D	S4092BE	75	6H730801	BODY COVER PACKING
20 FUEGO LT 6000D	S4092BE	76	6Q676301	HANDLE ASSY
20 FUEGO LT 6000D	S4092BE	77	6B861705	DRIVE BALL BEARING (B)
20 FUEGO LT 6000D	S4092BE	78	6G525101	DRIVE BEARING RETAINER
20 FUEGO LT 6000D	S4092BE	79	6G672401	HANDLE CAP O RING

20 FUEGO LT 6000D	S4092BE	80	6Q364801	HANDLE CAP
20 FUEGO LT 6000D	S4092BE	81	-----	-----
20 FUEGO LT 1000	S4010BE	1	6Q376801	DRAG KNOB
20 FUEGO LT 1000	S4010BE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 1000	S4010BE	3	6Q621901	KEY WASHER
20 FUEGO LT 1000	S4010BE	4	6J546801	DRAG WASHER
20 FUEGO LT 1000	S4010BE	5	-----	-----
20 FUEGO LT 1000	S4010BE	6	6Q697301	SPOOL ASSY(2T06)
20 FUEGO LT 1000	S4010BE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 1000	S4010BE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 1000	S4010BE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 1000	S4010BE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 1000	S4010BE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 1000	S4010BE	12	6H416101	CLICK LEAF SPRING
20 FUEGO LT 1000	S4010BE	13	6M021401	CLICK HOLDER
20 FUEGO LT 1000	S4010BE	14	6Q344001	ROTOR WASHER
20 FUEGO LT 1000	S4010BE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 1000	S4010BE	16	6Q177001	ROTOR NUT
20 FUEGO LT 1000	S4010BE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 1000	S4010BE	18	6Q139533	ROTOR
20 FUEGO LT 1000	S4010BE	19	6H443301	BAIL TRIP LEVER SPRING
20 FUEGO LT 1000	S4010BE	20	6Q139601	BAIL TRIP LEVER
20 FUEGO LT 1000	S4010BE	21	6H417701	BAIL TRIP LEVER SCREW
20 FUEGO LT 1000	S4010BE	22	6Q139801	ARM LEVER SHAFT
20 FUEGO LT 1000	S4010BE	23	6H576101	ARM LEVER SHAFT PLATE
20 FUEGO LT 1000	S4010BE	24	6H442401	ARM LEVER SPRING
20 FUEGO LT 1000	S4010BE	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO LT 1000	S4010BE	26	6Q146501	ARM LEVER SPRING COVER
20 FUEGO LT 1000	S4010BE	27	6Q342901	ARM LEVER SPRING COVER SCREW
20 FUEGO LT 1000	S4010BE	28	6Q121620	ARM LEVER
20 FUEGO LT 1000	S4010BE	29	6Q121701	ARM LEVER SCREW COLLAR
20 FUEGO LT 1000	S4010BE	30	6Q343401	ARM LEVER SCREW
20 FUEGO LT 1000	S4010BE	31	6G195602	ROLLER SCREW
20 FUEGO LT 1000	S4010BE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 1000	S4010BE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 1000	S4010BE	34	6J089901	LINE ROLLER
20 FUEGO LT 1000	S4010BE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 1000	S4010BE	36	6Q788301	BAIL
20 FUEGO LT 1000	S4010BE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 1000	S4010BE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 1000	S4010BE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 1000	S4010BE	40	6J354801	MAGSEALED PLATE O RING
20 FUEGO LT 1000	S4010BE	41	-----	-----
20 FUEGO LT 1000	S4010BE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 1000	S4010BE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 1000	S4010BE	44	6J001403	CLUTCH RING
20 FUEGO LT 1000	S4010BE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 1000	S4010BE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 1000	S4010BE	47	6G467302	PINION BALL BEARING (A)
20 FUEGO LT 1000	S4010BE	48	63758502	PINION BEARING WASHER
20 FUEGO LT 1000	S4010BE	49	6Q375701	PINION GEAR
20 FUEGO LT 1000	S4010BE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 1000	S4010BE	51	6H959601	PINION BALL BEARING (B)
20 FUEGO LT 1000	S4010BE	52	6J387701	PINION BEARING COLLAR
20 FUEGO LT 1000	S4010BE	53	6Q625801	BODY
20 FUEGO LT 1000	S4010BE	54	6Q375301	MAIN SHAFT
20 FUEGO LT 1000	S4010BE	55	-----	-----
20 FUEGO LT 1000	S4010BE	56	6Q119104	OSCILLATING POST
20 FUEGO LT 1000	S4010BE	57	6Q118101	STOPPER CAM
20 FUEGO LT 1000	S4010BE	58	6H697801	STOPPER LEVER SPRING
20 FUEGO LT 1000	S4010BE	59	6Q118001	STOPPER LEVER
20 FUEGO LT 1000	S4010BE	60	6Q626501	REAR COVER
20 FUEGO LT 1000	S4010BE	61	6Q342901	REAR COVER SCREW
20 FUEGO LT 1000	S4010BE	62	6H607902	OSCILLATING GEAR WASHER
20 FUEGO LT 1000	S4010BE	63	6Q375201	OSCILLATING GEAR
20 FUEGO LT 1000	S4010BE	64	6H770601	OSCILLATING GEAR O RING
20 FUEGO LT 1000	S4010BE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 1000	S4010BE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 1000	S4010BE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 1000	S4010BE	68	6G670501	DRIVE GEAR O RING
20 FUEGO LT 1000	S4010BE	69	6Q375801	DRIVE GEAR
20 FUEGO LT 1000	S4010BE	70	63758502	DRIVE WASHER
20 FUEGO LT 1000	S4010BE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 1000	S4010BE	72	6Q625901	BODY COVER
20 FUEGO LT 1000	S4010BE	73	6Q342701	BODY COVER SCREW (A)
20 FUEGO LT 1000	S4010BE	74	6Q342601	BODY COVER SCREW (B)
20 FUEGO LT 1000	S4010BE	75	6J100201	BODY COVER PACKING
20 FUEGO LT 1000	S4010BE	76	6Q663401	HANDLE ASSY
20 FUEGO LT 1000	S4010BE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 1000	S4010BE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 1000	S4010BE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 1000	S4010BE	80	6Q345101	HANDLE CAP
20 FUEGO LT 1000	S4010BE	81	6J639901	ONEWAY CLUTCH WASHER
20 FUEGO LT 2000	S4020BE	1	6Q376801	DRAG KNOB
20 FUEGO LT 2000	S4020BE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 2000	S4020BE	3	6Q621901	KEY WASHER
20 FUEGO LT 2000	S4020BE	4	6J546801	DRAG WASHER
20 FUEGO LT 2000	S4020BE	5	-----	-----
20 FUEGO LT 2000	S4020BE	6	6Q697501	SPOOL ASSY(2T06)
20 FUEGO LT 2000	S4020BE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 2000	S4020BE	8	6E332501	SPOOL BALL BEARING

20 FUEGO LT 2000	S4020BE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 2000	S4020BE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 2000	S4020BE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 2000	S4020BE	12	6H416101	CLICK LEAF SPRING
20 FUEGO LT 2000	S4020BE	13	6M021401	CLICK HOLDER
20 FUEGO LT 2000	S4020BE	14	6Q344001	ROTOR WASHER
20 FUEGO LT 2000	S4020BE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 2000	S4020BE	16	6Q177001	ROTOR NUT
20 FUEGO LT 2000	S4020BE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 2000	S4020BE	18	6Q139533	ROTOR
20 FUEGO LT 2000	S4020BE	19	6H443301	BAIL TRIP LEVER SPRING
20 FUEGO LT 2000	S4020BE	20	6Q139601	BAIL TRIP LEVER
20 FUEGO LT 2000	S4020BE	21	6H417701	BAIL TRIP LEVER SCREW
20 FUEGO LT 2000	S4020BE	22	6Q139801	ARM LEVER SHAFT
20 FUEGO LT 2000	S4020BE	23	6H576101	ARM LEVER SHAFT PLATE
20 FUEGO LT 2000	S4020BE	24	6H442401	ARM LEVER SPRING
20 FUEGO LT 2000	S4020BE	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO LT 2000	S4020BE	26	6Q146501	ARM LEVER SPRING COVER
20 FUEGO LT 2000	S4020BE	27	6Q342901	ARM LEVER SPRING COVER SCREW
20 FUEGO LT 2000	S4020BE	28	6Q121620	ARM LEVER
20 FUEGO LT 2000	S4020BE	29	6Q121701	ARM LEVER SCREW COLLAR
20 FUEGO LT 2000	S4020BE	30	6Q343401	ARM LEVER SCREW
20 FUEGO LT 2000	S4020BE	31	6G195602	ROLLER SCREW
20 FUEGO LT 2000	S4020BE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 2000	S4020BE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 2000	S4020BE	34	6J089901	LINE ROLLER
20 FUEGO LT 2000	S4020BE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 2000	S4020BE	36	6Q788301	BAIL
20 FUEGO LT 2000	S4020BE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 2000	S4020BE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 2000	S4020BE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 2000	S4020BE	40	6J354801	MAGSEALED PLATE O RING
20 FUEGO LT 2000	S4020BE	41	-----	-----
20 FUEGO LT 2000	S4020BE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 2000	S4020BE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 2000	S4020BE	44	6J001403	CLUTCH RING
20 FUEGO LT 2000	S4020BE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 2000	S4020BE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 2000	S4020BE	47	6G467302	PINION BALL BEARING (A)
20 FUEGO LT 2000	S4020BE	48	63758502	PINION BEARING WASHER
20 FUEGO LT 2000	S4020BE	49	6Q375701	PINION GEAR
20 FUEGO LT 2000	S4020BE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 2000	S4020BE	51	6H959601	PINION BALL BEARING (B)
20 FUEGO LT 2000	S4020BE	52	6J387701	PINION BEARING COLLAR
20 FUEGO LT 2000	S4020BE	53	6Q625801	BODY
20 FUEGO LT 2000	S4020BE	54	6Q375301	MAIN SHAFT
20 FUEGO LT 2000	S4020BE	55	-----	-----
20 FUEGO LT 2000	S4020BE	56	6Q119104	OSCILLATING POST
20 FUEGO LT 2000	S4020BE	57	6Q118101	STOPPER CAM
20 FUEGO LT 2000	S4020BE	58	6H697801	STOPPER LEVER SPRING
20 FUEGO LT 2000	S4020BE	59	6Q118001	STOPPER LEVER
20 FUEGO LT 2000	S4020BE	60	6Q626501	REAR COVER
20 FUEGO LT 2000	S4020BE	61	6Q342901	REAR COVER SCREW
20 FUEGO LT 2000	S4020BE	62	6H607902	OSCILLATING GEAR WASHER
20 FUEGO LT 2000	S4020BE	63	6Q375201	OSCILLATING GEAR
20 FUEGO LT 2000	S4020BE	64	6H770601	OSCILLATING GEAR O RING
20 FUEGO LT 2000	S4020BE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 2000	S4020BE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 2000	S4020BE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 2000	S4020BE	68	6G670501	DRIVE GEAR O RING
20 FUEGO LT 2000	S4020BE	69	6Q375801	DRIVE GEAR
20 FUEGO LT 2000	S4020BE	70	63758502	DRIVE WASHER
20 FUEGO LT 2000	S4020BE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 2000	S4020BE	72	6Q625901	BODY COVER
20 FUEGO LT 2000	S4020BE	73	6Q342701	BODY COVER SCREW (A)
20 FUEGO LT 2000	S4020BE	74	6Q342601	BODY COVER SCREW (B)
20 FUEGO LT 2000	S4020BE	75	6J100201	BODY COVER PACKING
20 FUEGO LT 2000	S4020BE	76	6Q663401	HANDLE ASSY
20 FUEGO LT 2000	S4020BE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 2000	S4020BE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 2000	S4020BE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 2000	S4020BE	80	6Q345101	HANDLE CAP
20 FUEGO LT 2000	S4020BE	81	6J639901	ONEWAY CLUTCH WASHER
20 FUEGO LT 2500	S4040BE	1	6Q346201	DRAG KNOB
20 FUEGO LT 2500	S4040BE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 2500	S4040BE	3	6Q621901	KEY WASHER
20 FUEGO LT 2500	S4040BE	4	6J546801	DRAG WASHER
20 FUEGO LT 2500	S4040BE	5	6Q346001	EARED WASHER
20 FUEGO LT 2500	S4040BE	6	6Q697701	SPOOL ASSY(2TO6)
20 FUEGO LT 2500	S4040BE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 2500	S4040BE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 2500	S4040BE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 2500	S4040BE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 2500	S4040BE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 2500	S4040BE	12	6H416101	CLICK LEAF SPRING
20 FUEGO LT 2500	S4040BE	13	6M021401	CLICK HOLDER
20 FUEGO LT 2500	S4040BE	14	6Q344001	ROTOR WASHER
20 FUEGO LT 2500	S4040BE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 2500	S4040BE	16	6Q177001	ROTOR NUT
20 FUEGO LT 2500	S4040BE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 2500	S4040BE	18	6Q343022	ROTOR

20 FUEGO LT 2500	S4040BE	19	6H413601	BAIL TRIP LEVER SPRING
20 FUEGO LT 2500	S4040BE	20	6Q343101	BAIL TRIP LEVER
20 FUEGO LT 2500	S4040BE	21	6H417701	BAIL TRIP LEVER SCREW
20 FUEGO LT 2500	S4040BE	22	6Q343301	ARM LEVER SHAFT
20 FUEGO LT 2500	S4040BE	23	6H576101	ARM LEVER SHAFT PLATE
20 FUEGO LT 2500	S4040BE	24	6J642801	ARM LEVER SPRING
20 FUEGO LT 2500	S4040BE	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO LT 2500	S4040BE	26	6Q343501	ARM LEVER SPRING COVER
20 FUEGO LT 2500	S4040BE	27	6Q342901	ARM LEVER SPRING COVER SCREW
20 FUEGO LT 2500	S4040BE	28	6Q121620	ARM LEVER
20 FUEGO LT 2500	S4040BE	29	6Q121701	ARM LEVER SCREW COLLAR
20 FUEGO LT 2500	S4040BE	30	6Q343401	ARM LEVER SCREW
20 FUEGO LT 2500	S4040BE	31	6G195602	ROLLER SCREW
20 FUEGO LT 2500	S4040BE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 2500	S4040BE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 2500	S4040BE	34	6J089901	LINE ROLLER
20 FUEGO LT 2500	S4040BE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 2500	S4040BE	36	6Q777001	BAIL
20 FUEGO LT 2500	S4040BE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 2500	S4040BE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 2500	S4040BE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 2500	S4040BE	40	6J354801	MAGSEALED PLATE O RING
20 FUEGO LT 2500	S4040BE	41	-----	-----
20 FUEGO LT 2500	S4040BE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 2500	S4040BE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 2500	S4040BE	44	6J001403	CLUTCH RING
20 FUEGO LT 2500	S4040BE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 2500	S4040BE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 2500	S4040BE	47	6G467302	PINION BALL BEARING (A)
20 FUEGO LT 2500	S4040BE	48	63758502	PINION BEARING WASHER
20 FUEGO LT 2500	S4040BE	49	6Q341701	PINION GEAR
20 FUEGO LT 2500	S4040BE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 2500	S4040BE	51	6H959601	PINION BALL BEARING (B)
20 FUEGO LT 2500	S4040BE	52	-----	-----
20 FUEGO LT 2500	S4040BE	53	6Q531018	BODY
20 FUEGO LT 2500	S4040BE	54	6Q341501	MAIN SHAFT
20 FUEGO LT 2500	S4040BE	55	6Q126301	OSCILLATING POST (A)
20 FUEGO LT 2500	S4040BE	56	6Q119101	OSCILLATING POST (B)
20 FUEGO LT 2500	S4040BE	57	6Q118101	STOPPER CAM
20 FUEGO LT 2500	S4040BE	58	6H697801	STOPPER LEVER SPRING
20 FUEGO LT 2500	S4040BE	59	6Q118001	STOPPER LEVER
20 FUEGO LT 2500	S4040BE	60	6Q626401	REAR COVER
20 FUEGO LT 2500	S4040BE	61	6Q342901	REAR COVER SCREW
20 FUEGO LT 2500	S4040BE	62	6H595701	OSCILLATING GEAR WASHER
20 FUEGO LT 2500	S4040BE	63	6Q139001	OSCILLATING GEAR
20 FUEGO LT 2500	S4040BE	64	6H770601	OSCILLATING GEAR O RING
20 FUEGO LT 2500	S4040BE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 2500	S4040BE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 2500	S4040BE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 2500	S4040BE	68	6G670501	DRIVE GEAR O RING
20 FUEGO LT 2500	S4040BE	69	6Q341801	DRIVE GEAR
20 FUEGO LT 2500	S4040BE	70	63758502	DRIVE WASHER
20 FUEGO LT 2500	S4040BE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 2500	S4040BE	72	6Q624301	BODY COVER
20 FUEGO LT 2500	S4040BE	73	6Q342701	BODY COVER SCREW (A)
20 FUEGO LT 2500	S4040BE	74	6Q342601	BODY COVER SCREW (B)
20 FUEGO LT 2500	S4040BE	75	6J100201	BODY COVER PACKING
20 FUEGO LT 2500	S4040BE	76	6Q663601	HANDLE ASSY
20 FUEGO LT 2500	S4040BE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 2500	S4040BE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 2500	S4040BE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 2500	S4040BE	80	6Q345101	HANDLE CAP
20 FUEGO LT 2500	S4040BE	81	6J639901	ONEWAY CLUTCH WASHER
20 FUEGO LT 3000 C	S4050BE	1	6Q346201	DRAG KNOB
20 FUEGO LT 3000 C	S4050BE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 3000 C	S4050BE	3	6Q621901	KEY WASHER
20 FUEGO LT 3000 C	S4050BE	4	6J546801	DRAG WASHER
20 FUEGO LT 3000 C	S4050BE	5	6Q346001	EARED WASHER
20 FUEGO LT 3000 C	S4050BE	6	6Q697901	SPOOL ASSY(2T06)
20 FUEGO LT 3000 C	S4050BE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 3000 C	S4050BE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 3000 C	S4050BE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 3000 C	S4050BE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 3000 C	S4050BE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 3000 C	S4050BE	12	6H416101	CLICK LEAF SPRING
20 FUEGO LT 3000 C	S4050BE	13	6M021401	CLICK HOLDER
20 FUEGO LT 3000 C	S4050BE	14	6Q344001	ROTOR WASHER
20 FUEGO LT 3000 C	S4050BE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 3000 C	S4050BE	16	6Q177001	ROTOR NUT
20 FUEGO LT 3000 C	S4050BE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 3000 C	S4050BE	18	6Q120531	ROTOR
20 FUEGO LT 3000 C	S4050BE	19	6H413601	BAIL TRIP LEVER SPRING
20 FUEGO LT 3000 C	S4050BE	20	6Q120701	BAIL TRIP LEVER
20 FUEGO LT 3000 C	S4050BE	21	6H417701	BAIL TRIP LEVER SCREW
20 FUEGO LT 3000 C	S4050BE	22	6Q121201	ARM LEVER SHAFT
20 FUEGO LT 3000 C	S4050BE	23	6H576101	ARM LEVER SHAFT PLATE
20 FUEGO LT 3000 C	S4050BE	24	6H545701	ARM LEVER SPRING
20 FUEGO LT 3000 C	S4050BE	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO LT 3000 C	S4050BE	26	6Q121801	ARM LEVER SPRING COVER
20 FUEGO LT 3000 C	S4050BE	27	6Q342901	ARM LEVER SPRING COVER SCREW
20 FUEGO LT 3000 C	S4050BE	28	6Q121620	ARM LEVER

20 FUEGO LT 3000 C	S4050BE	29	6Q121701	ARM LEVER SCREW COLLAR
20 FUEGO LT 3000 C	S4050BE	30	6Q343401	ARM LEVER SCREW
20 FUEGO LT 3000 C	S4050BE	31	6G195602	ROLLER SCREW
20 FUEGO LT 3000 C	S4050BE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 3000 C	S4050BE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 3000 C	S4050BE	34	6J089901	LINE ROLLER
20 FUEGO LT 3000 C	S4050BE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 3000 C	S4050BE	36	6Q777101	BAIL
20 FUEGO LT 3000 C	S4050BE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 3000 C	S4050BE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 3000 C	S4050BE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 3000 C	S4050BE	40	6J354801	MAGSEALED PLATE O RING
20 FUEGO LT 3000 C	S4050BE	41	-----	-----
20 FUEGO LT 3000 C	S4050BE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 3000 C	S4050BE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 3000 C	S4050BE	44	6J001403	CLUTCH RING
20 FUEGO LT 3000 C	S4050BE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 3000 C	S4050BE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 3000 C	S4050BE	47	6G467302	PINION BALL BEARING (A)
20 FUEGO LT 3000 C	S4050BE	48	63758502	PINION BEARING WASHER
20 FUEGO LT 3000 C	S4050BE	49	6Q341701	PINION GEAR
20 FUEGO LT 3000 C	S4050BE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 3000 C	S4050BE	51	6H959601	PINION BALL BEARING (B)
20 FUEGO LT 3000 C	S4050BE	52	-----	-----
20 FUEGO LT 3000 C	S4050BE	53	6Q659601	BODY
20 FUEGO LT 3000 C	S4050BE	54	6Q461401	MAIN SHAFT
20 FUEGO LT 3000 C	S4050BE	55	6Q126301	OSCILLATING POST (A)
20 FUEGO LT 3000 C	S4050BE	56	6Q119101	OSCILLATING POST (B)
20 FUEGO LT 3000 C	S4050BE	57	6Q118101	STOPPER CAM
20 FUEGO LT 3000 C	S4050BE	58	6H697801	STOPPER LEVER SPRING
20 FUEGO LT 3000 C	S4050BE	59	6Q118001	STOPPER LEVER
20 FUEGO LT 3000 C	S4050BE	60	6Q626401	REAR COVER
20 FUEGO LT 3000 C	S4050BE	61	6Q342901	REAR COVER SCREW
20 FUEGO LT 3000 C	S4050BE	62	6H595701	OSCILLATING GEAR WASHER
20 FUEGO LT 3000 C	S4050BE	63	6Q118401	OSCILLATING GEAR
20 FUEGO LT 3000 C	S4050BE	64	6H770601	OSCILLATING GEAR O RING
20 FUEGO LT 3000 C	S4050BE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 3000 C	S4050BE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 3000 C	S4050BE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 3000 C	S4050BE	68	6G670501	DRIVE GEAR O RING
20 FUEGO LT 3000 C	S4050BE	69	6Q341801	DRIVE GEAR
20 FUEGO LT 3000 C	S4050BE	70	63758502	DRIVE WASHER
20 FUEGO LT 3000 C	S4050BE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 3000 C	S4050BE	72	6Q531209	BODY COVER
20 FUEGO LT 3000 C	S4050BE	73	6Q342701	BODY COVER SCREW (A)
20 FUEGO LT 3000 C	S4050BE	74	6Q342601	BODY COVER SCREW (B)
20 FUEGO LT 3000 C	S4050BE	75	6J100201	BODY COVER PACKING
20 FUEGO LT 3000 C	S4050BE	76	6Q663601	HANDLE ASSY
20 FUEGO LT 3000 C	S4050BE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 3000 C	S4050BE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 3000 C	S4050BE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 3000 C	S4050BE	80	6Q345101	HANDLE CAP
20 FUEGO LT 3000 C	S4050BE	81	6J639901	ONEWAY CLUTCH WASHER
20 FUEGO LT 1000D	S4012VE	1	6Q376801	DRAG KNOB
20 FUEGO LT 1000D	S4012VE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 1000D	S4012VE	3	6Q621901	KEY WASHER
20 FUEGO LT 1000D	S4012VE	4	6J678901	ATD DRAG WASHER (1PC/PK)
20 FUEGO LT 1000D	S4012VE	5	-----	-----
20 FUEGO LT 1000D	S4012VE	2 6	6Q838901	SPOOL ASSY(2 6)
20 FUEGO LT 1000D	S4012VE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 1000D	S4012VE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 1000D	S4012VE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 1000D	S4012VE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 1000D	S4012VE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 1000D	S4012VE	12	6Q797701	CLICK LEAF SPRING
20 FUEGO LT 1000D	S4012VE	13	6Q798201	CLICK SPRING HOLDER
20 FUEGO LT 1000D	S4012VE	14	6Q344001	SPOOL WASHER (E)
20 FUEGO LT 1000D	S4012VE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 1000D	S4012VE	16	6Q177001	ROTOR NUT
20 FUEGO LT 1000D	S4012VE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 1000D	S4012VE	18	6Q139543	ROTOR
20 FUEGO LT 1000D	S4012VE	19	6H443301	BAIL TRIP LEVER SPRING
20 FUEGO LT 1000D	S4012VE	20	6Q139601	BAIL TRIP LEVER
20 FUEGO LT 1000D	S4012VE	21	6H417701	BAIL TRIP LEVER SCREW
20 FUEGO LT 1000D	S4012VE	22	6Q139801	BAIL SPRING SHAFT
20 FUEGO LT 1000D	S4012VE	23	6H576101	BAIL SPRING SHAFT PLATE
20 FUEGO LT 1000D	S4012VE	24	6H442401	BAIL SPRING
20 FUEGO LT 1000D	S4012VE	25	6Q121501	BAIL SPRING HOLDER
20 FUEGO LT 1000D	S4012VE	26	6Q146501	BAIL ARM COVER
20 FUEGO LT 1000D	S4012VE	27	6Q342901	BAIL ARM COVER SCREW
20 FUEGO LT 1000D	S4012VE	28	6Q121620	BAIL ARM
20 FUEGO LT 1000D	S4012VE	29	6Q121701	BAIL ARM SCREW COLLAR
20 FUEGO LT 1000D	S4012VE	30	6Q343401	BAIL ARM SCREW
20 FUEGO LT 1000D	S4012VE	31	6G195602	ROLLER SCREW
20 FUEGO LT 1000D	S4012VE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 1000D	S4012VE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 1000D	S4012VE	34	6J089901	LINE ROLLER
20 FUEGO LT 1000D	S4012VE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 1000D	S4012VE	36	6Q788301	BAIL
20 FUEGO LT 1000D	S4012VE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 1000D	S4012VE	38	63754102	MAGSEALED PLATE SCREW WASHER

20 FUEGO LT 1000D	S4012VE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 1000D	S4012VE	40	6J354801	MAGSEALED PLATE O RING
20 FUEGO LT 1000D	S4012VE	41	-----	-----
20 FUEGO LT 1000D	S4012VE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 1000D	S4012VE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 1000D	S4012VE	44	6J001403	CLUTCH RING
20 FUEGO LT 1000D	S4012VE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 1000D	S4012VE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 1000D	S4012VE	47	6G467302	PINION BALL BEARING (A)
20 FUEGO LT 1000D	S4012VE	48	63758502	PINION BEARING WASHER
20 FUEGO LT 1000D	S4012VE	49	6Q375701	PINION GEAR
20 FUEGO LT 1000D	S4012VE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 1000D	S4012VE	51	6H959601	PINION BALL BEARING (B)
20 FUEGO LT 1000D	S4012VE	52	6J387701	PINION BEARING COLLAR
20 FUEGO LT 1000D	S4012VE	53	6Q625801	BODY
20 FUEGO LT 1000D	S4012VE	54	6Q375301	MAIN SHAFT
20 FUEGO LT 1000D	S4012VE	55	-----	-----
20 FUEGO LT 1000D	S4012VE	56	6Q119104	OSCILLATING POST
20 FUEGO LT 1000D	S4012VE	57	6Q118101	ANTI REVERSE CAM
20 FUEGO LT 1000D	S4012VE	58	6H697801	ANTI REVERSE CAM SPRING
20 FUEGO LT 1000D	S4012VE	59	6Q118001	ANTI REVERSE LEVER
20 FUEGO LT 1000D	S4012VE	60	6Q626501	REAR COVER
20 FUEGO LT 1000D	S4012VE	61	6Q342901	REAR CAP SCREW
20 FUEGO LT 1000D	S4012VE	62	6H607902	OSCILLATING GEAR WASHER
20 FUEGO LT 1000D	S4012VE	63	6Q375201	OSCILLATING GEAR
20 FUEGO LT 1000D	S4012VE	64	6H770601	OSCILLATING GEAR O RING
20 FUEGO LT 1000D	S4012VE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 1000D	S4012VE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 1000D	S4012VE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 1000D	S4012VE	68	6G670501	DRIVE GEAR O RING
20 FUEGO LT 1000D	S4012VE	69	6Q375801	DRIVE GEAR
20 FUEGO LT 1000D	S4012VE	70	63758502	DRIVE GEAR WASHER
20 FUEGO LT 1000D	S4012VE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 1000D	S4012VE	72	6Q625901	SIDE COVER
20 FUEGO LT 1000D	S4012VE	73	6Q342701	SIDE COVER SCREW (A)
20 FUEGO LT 1000D	S4012VE	74	6Q342601	SIDE COVER SCREW (B)
20 FUEGO LT 1000D	S4012VE	75	6J100201	SIDE COVER PACKING
20 FUEGO LT 1000D	S4012VE	76	6Q663401	HANDLE ASSY
20 FUEGO LT 1000D	S4012VE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 1000D	S4012VE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 1000D	S4012VE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 1000D	S4012VE	80	6Q345101	HANDLE CAP
20 FUEGO LT 1000D	S4012VE	81	6J639902	ONEWAY CLUTCH WASHER
20 FUEGO LT 2000D	S4022VE	1	6Q376801	DRAG KNOB
20 FUEGO LT 2000D	S4022VE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 2000D	S4022VE	3	6Q621901	KEY WASHER
20 FUEGO LT 2000D	S4022VE	4	6J678901	ATD DRAG WASHER (1PC/PK)
20 FUEGO LT 2000D	S4022VE	5	-----	-----
20 FUEGO LT 2000D	S4022VE	2 6	6Q839201	SPOOL ASSY(2 6)
20 FUEGO LT 2000D	S4022VE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 2000D	S4022VE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 2000D	S4022VE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 2000D	S4022VE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 2000D	S4022VE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 2000D	S4022VE	12	6Q797701	CLICK LEAF SPRING
20 FUEGO LT 2000D	S4022VE	13	6Q798201	CLICK SPRING HOLDER
20 FUEGO LT 2000D	S4022VE	14	6Q344001	SPOOL WASHER (E)
20 FUEGO LT 2000D	S4022VE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 2000D	S4022VE	16	6Q177001	ROTOR NUT
20 FUEGO LT 2000D	S4022VE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 2000D	S4022VE	18	6Q139543	ROTOR
20 FUEGO LT 2000D	S4022VE	19	6H443301	BAIL TRIP LEVER SPRING
20 FUEGO LT 2000D	S4022VE	20	6Q139601	BAIL TRIP LEVER
20 FUEGO LT 2000D	S4022VE	21	6H417701	BAIL TRIP LEVER SCREW
20 FUEGO LT 2000D	S4022VE	22	6Q139801	BAIL SPRING SHAFT
20 FUEGO LT 2000D	S4022VE	23	6H576101	BAIL SPRING SHAFT PLATE
20 FUEGO LT 2000D	S4022VE	24	6H442401	BAIL SPRING
20 FUEGO LT 2000D	S4022VE	25	6Q121501	BAIL SPRING HOLDER
20 FUEGO LT 2000D	S4022VE	26	6Q146501	BAIL ARM COVER
20 FUEGO LT 2000D	S4022VE	27	6Q342901	BAIL ARM COVER SCREW
20 FUEGO LT 2000D	S4022VE	28	6Q121620	BAIL ARM
20 FUEGO LT 2000D	S4022VE	29	6Q121701	BAIL ARM SCREW COLLAR
20 FUEGO LT 2000D	S4022VE	30	6Q343401	BAIL ARM SCREW
20 FUEGO LT 2000D	S4022VE	31	6G195602	ROLLER SCREW
20 FUEGO LT 2000D	S4022VE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 2000D	S4022VE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 2000D	S4022VE	34	6J089901	LINE ROLLER
20 FUEGO LT 2000D	S4022VE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 2000D	S4022VE	36	6Q788301	BAIL
20 FUEGO LT 2000D	S4022VE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 2000D	S4022VE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 2000D	S4022VE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 2000D	S4022VE	40	6J354801	MAGSEALED PLATE O RING
20 FUEGO LT 2000D	S4022VE	41	-----	-----
20 FUEGO LT 2000D	S4022VE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 2000D	S4022VE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 2000D	S4022VE	44	6J001403	CLUTCH RING
20 FUEGO LT 2000D	S4022VE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 2000D	S4022VE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 2000D	S4022VE	47	6G467302	PINION BALL BEARING (A)
20 FUEGO LT 2000D	S4022VE	48	63758502	PINION BEARING WASHER

20 FUEGO LT 2000D	S4022VE	49	6Q375701	PINION GEAR
20 FUEGO LT 2000D	S4022VE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 2000D	S4022VE	51	6H959601	PINION BALL BEARING (B)
20 FUEGO LT 2000D	S4022VE	52	6J387701	PINION BEARING COLLAR
20 FUEGO LT 2000D	S4022VE	53	6Q625801	BODY
20 FUEGO LT 2000D	S4022VE	54	6Q375301	MAIN SHAFT
20 FUEGO LT 2000D	S4022VE	55	-----	-----
20 FUEGO LT 2000D	S4022VE	56	6Q119104	OSCILLATING POST
20 FUEGO LT 2000D	S4022VE	57	6Q118101	ANTI REVERSE CAM
20 FUEGO LT 2000D	S4022VE	58	6H697801	ANTI REVERSE CAM SPRING
20 FUEGO LT 2000D	S4022VE	59	6Q118001	ANTI REVERSE LEVER
20 FUEGO LT 2000D	S4022VE	60	6Q626501	REAR COVER
20 FUEGO LT 2000D	S4022VE	61	6Q342901	REAR CAP SCREW
20 FUEGO LT 2000D	S4022VE	62	6H607902	OSCILLATING GEAR WASHER
20 FUEGO LT 2000D	S4022VE	63	6Q375201	OSCILLATING GEAR
20 FUEGO LT 2000D	S4022VE	64	6H770601	OSCILLATING GEAR O RING
20 FUEGO LT 2000D	S4022VE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 2000D	S4022VE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 2000D	S4022VE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 2000D	S4022VE	68	6G670501	DRIVE GEAR O RING
20 FUEGO LT 2000D	S4022VE	69	6Q375801	DRIVE GEAR
20 FUEGO LT 2000D	S4022VE	70	63758502	DRIVE GEAR WASHER
20 FUEGO LT 2000D	S4022VE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 2000D	S4022VE	72	6Q625901	SIDE COVER
20 FUEGO LT 2000D	S4022VE	73	6Q342701	SIDE COVER SCREW (A)
20 FUEGO LT 2000D	S4022VE	74	6Q342601	SIDE COVER SCREW (B)
20 FUEGO LT 2000D	S4022VE	75	6J100201	SIDE COVER PACKING
20 FUEGO LT 2000D	S4022VE	76	6Q663401	HANDLE ASSY
20 FUEGO LT 2000D	S4022VE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 2000D	S4022VE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 2000D	S4022VE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 2000D	S4022VE	80	6Q345101	HANDLE CAP
20 FUEGO LT 2000D	S4022VE	81	6J639902	ONEWAY CLUTCH WASHER
20 FUEGO LT 2500D	S4042VE	1	6Q346201	DRAG KNOB
20 FUEGO LT 2500D	S4042VE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 2500D	S4042VE	3	6Q621901	KEY WASHER
20 FUEGO LT 2500D	S4042VE	4	6J678801	ATD DRAG WASHER (3PCS/PK)
20 FUEGO LT 2500D	S4042VE	5	6Q346001	EARED WASHER
20 FUEGO LT 2500D	S4042VE	2 6	6Q839501	SPOOL ASSY(2 6)
20 FUEGO LT 2500D	S4042VE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 2500D	S4042VE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 2500D	S4042VE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 2500D	S4042VE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 2500D	S4042VE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 2500D	S4042VE	12	6Q797701	CLICK LEAF SPRING
20 FUEGO LT 2500D	S4042VE	13	6Q798201	CLICK SPRING HOLDER
20 FUEGO LT 2500D	S4042VE	14	6Q344001	SPOOL WASHER (E)
20 FUEGO LT 2500D	S4042VE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 2500D	S4042VE	16	6Q177001	ROTOR NUT
20 FUEGO LT 2500D	S4042VE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 2500D	S4042VE	18	6Q343031	ROTOR
20 FUEGO LT 2500D	S4042VE	19	6H413601	BAIL TRIP LEVER SPRING
20 FUEGO LT 2500D	S4042VE	20	6Q343101	BAIL TRIP LEVER
20 FUEGO LT 2500D	S4042VE	21	6H417701	BAIL TRIP LEVER SCREW
20 FUEGO LT 2500D	S4042VE	22	6Q343301	BAIL SPRING SHAFT
20 FUEGO LT 2500D	S4042VE	23	6H576101	BAIL SPRING SHAFT PLATE
20 FUEGO LT 2500D	S4042VE	24	6J642801	BAIL SPRING
20 FUEGO LT 2500D	S4042VE	25	6Q121501	BAIL SPRING HOLDER
20 FUEGO LT 2500D	S4042VE	26	6Q343501	BAIL ARM COVER
20 FUEGO LT 2500D	S4042VE	27	6Q342901	BAIL ARM COVER SCREW
20 FUEGO LT 2500D	S4042VE	28	6Q121620	BAIL ARM
20 FUEGO LT 2500D	S4042VE	29	6Q121701	BAIL ARM SCREW COLLAR
20 FUEGO LT 2500D	S4042VE	30	6Q343401	BAIL ARM SCREW
20 FUEGO LT 2500D	S4042VE	31	6G195602	ROLLER SCREW
20 FUEGO LT 2500D	S4042VE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 2500D	S4042VE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 2500D	S4042VE	34	6J089901	LINE ROLLER
20 FUEGO LT 2500D	S4042VE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 2500D	S4042VE	36	6Q777001	BAIL
20 FUEGO LT 2500D	S4042VE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 2500D	S4042VE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 2500D	S4042VE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 2500D	S4042VE	40	6J354801	MAGSEALED PLATE O RING
20 FUEGO LT 2500D	S4042VE	41	-----	-----
20 FUEGO LT 2500D	S4042VE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 2500D	S4042VE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 2500D	S4042VE	44	6J001403	CLUTCH RING
20 FUEGO LT 2500D	S4042VE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 2500D	S4042VE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 2500D	S4042VE	47	6G467302	PINION BALL BEARING (A)
20 FUEGO LT 2500D	S4042VE	48	63758502	PINION BEARING WASHER
20 FUEGO LT 2500D	S4042VE	49	6Q341701	PINION GEAR
20 FUEGO LT 2500D	S4042VE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 2500D	S4042VE	51	6H959601	PINION BALL BEARING (B)
20 FUEGO LT 2500D	S4042VE	52	-----	-----
20 FUEGO LT 2500D	S4042VE	53	6Q624201	BODY
20 FUEGO LT 2500D	S4042VE	54	6Q341501	MAIN SHAFT
20 FUEGO LT 2500D	S4042VE	55	6Q126301	OSCILLATING POST (A)
20 FUEGO LT 2500D	S4042VE	56	6Q119101	OSCILLATING POST (B)
20 FUEGO LT 2500D	S4042VE	57	6Q118101	ANTI REVERSE CAM
20 FUEGO LT 2500D	S4042VE	58	6H697801	ANTI REVERSE CAM SPRING

20 FUEGO LT 2500D	S4042VE	59	6Q118001	ANTI REVERSE LEVER
20 FUEGO LT 2500D	S4042VE	60	6Q626401	REAR COVER
20 FUEGO LT 2500D	S4042VE	61	6Q342901	REAR CAP SCREW
20 FUEGO LT 2500D	S4042VE	62	6H595701	OSCILLATING GEAR WASHER
20 FUEGO LT 2500D	S4042VE	63	6Q139001	OSCILLATING GEAR
20 FUEGO LT 2500D	S4042VE	64	6H770601	OSCILLATING GEAR O RING
20 FUEGO LT 2500D	S4042VE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 2500D	S4042VE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 2500D	S4042VE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 2500D	S4042VE	68	6G670501	DRIVE GEAR O RING
20 FUEGO LT 2500D	S4042VE	69	6Q341801	DRIVE GEAR
20 FUEGO LT 2500D	S4042VE	70	63758502	DRIVE GEAR WASHER
20 FUEGO LT 2500D	S4042VE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 2500D	S4042VE	72	6Q624301	SIDE COVER
20 FUEGO LT 2500D	S4042VE	73	6Q342701	SIDE COVER SCREW (A)
20 FUEGO LT 2500D	S4042VE	74	6Q342601	SIDE COVER SCREW (B)
20 FUEGO LT 2500D	S4042VE	75	6J100201	SIDE COVER PACKING
20 FUEGO LT 2500D	S4042VE	76	6Q663601	HANDLE ASSY
20 FUEGO LT 2500D	S4042VE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 2500D	S4042VE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 2500D	S4042VE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 2500D	S4042VE	80	6Q345101	HANDLE CAP
20 FUEGO LT 2500D	S4042VE	81	6J639902	ONEWAY CLUTCH WASHER
20 FUEGO LT 3000D-C	S4052VE	1	6Q346201	DRAG KNOB
20 FUEGO LT 3000D-C	S4052VE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 3000D-C	S4052VE	3	6Q621901	KEY WASHER
20 FUEGO LT 3000D-C	S4052VE	4	6J678801	ATD DRAG WASHER (3PCS/PK)
20 FUEGO LT 3000D-C	S4052VE	5	6Q346001	EARED WASHER
20 FUEGO LT 3000D-C	S4052VE	2 6	6Q839801	SPOOL ASSY(2 6)
20 FUEGO LT 3000D-C	S4052VE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 3000D-C	S4052VE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 3000D-C	S4052VE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 3000D-C	S4052VE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 3000D-C	S4052VE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 3000D-C	S4052VE	12	6Q797701	CLICK LEAF SPRING
20 FUEGO LT 3000D-C	S4052VE	13	6Q798201	CLICK SPRING HOLDER
20 FUEGO LT 3000D-C	S4052VE	14	6Q344001	SPOOL WASHER (E)
20 FUEGO LT 3000D-C	S4052VE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 3000D-C	S4052VE	16	6Q177001	ROTOR NUT
20 FUEGO LT 3000D-C	S4052VE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 3000D-C	S4052VE	18	6Q120540	ROTOR
20 FUEGO LT 3000D-C	S4052VE	19	6H413601	BAIL TRIP LEVER SPRING
20 FUEGO LT 3000D-C	S4052VE	20	6Q120701	BAIL TRIP LEVER
20 FUEGO LT 3000D-C	S4052VE	21	6H417701	BAIL TRIP LEVER SCREW
20 FUEGO LT 3000D-C	S4052VE	22	6Q121201	BAIL SPRING SHAFT
20 FUEGO LT 3000D-C	S4052VE	23	6H576101	BAIL SPRING SHAFT PLATE
20 FUEGO LT 3000D-C	S4052VE	24	6H545701	BAIL SPRING
20 FUEGO LT 3000D-C	S4052VE	25	6Q121501	BAIL SPRING HOLDER
20 FUEGO LT 3000D-C	S4052VE	26	6Q121801	BAIL ARM COVER
20 FUEGO LT 3000D-C	S4052VE	27	6Q342901	BAIL ARM COVER SCREW
20 FUEGO LT 3000D-C	S4052VE	28	6Q121620	BAIL ARM
20 FUEGO LT 3000D-C	S4052VE	29	6Q121701	BAIL ARM SCREW COLLAR
20 FUEGO LT 3000D-C	S4052VE	30	6Q343401	BAIL ARM SCREW
20 FUEGO LT 3000D-C	S4052VE	31	6G195602	ROLLER SCREW
20 FUEGO LT 3000D-C	S4052VE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 3000D-C	S4052VE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 3000D-C	S4052VE	34	6J089901	LINE ROLLER
20 FUEGO LT 3000D-C	S4052VE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 3000D-C	S4052VE	36	6Q777101	BAIL
20 FUEGO LT 3000D-C	S4052VE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 3000D-C	S4052VE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 3000D-C	S4052VE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 3000D-C	S4052VE	40	6J354801	MAGSEALED PLATE O RING
20 FUEGO LT 3000D-C	S4052VE	41	-----	-----
20 FUEGO LT 3000D-C	S4052VE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 3000D-C	S4052VE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 3000D-C	S4052VE	44	6J001403	CLUTCH RING
20 FUEGO LT 3000D-C	S4052VE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 3000D-C	S4052VE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 3000D-C	S4052VE	47	6G467302	PINION BALL BEARING (A)
20 FUEGO LT 3000D-C	S4052VE	48	63758502	PINION BEARING WASHER
20 FUEGO LT 3000D-C	S4052VE	49	6Q341701	PINION GEAR
20 FUEGO LT 3000D-C	S4052VE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 3000D-C	S4052VE	51	6H959601	PINION BALL BEARING (B)
20 FUEGO LT 3000D-C	S4052VE	52	-----	-----
20 FUEGO LT 3000D-C	S4052VE	53	6Q659601	BODY
20 FUEGO LT 3000D-C	S4052VE	54	6Q461401	MAIN SHAFT
20 FUEGO LT 3000D-C	S4052VE	55	6Q126301	OSCILLATING POST (A)
20 FUEGO LT 3000D-C	S4052VE	56	6Q119101	OSCILLATING POST (B)
20 FUEGO LT 3000D-C	S4052VE	57	6Q118101	ANTI REVERSE CAM
20 FUEGO LT 3000D-C	S4052VE	58	6H697801	ANTI REVERSE CAM SPRING
20 FUEGO LT 3000D-C	S4052VE	59	6Q118001	ANTI REVERSE LEVER
20 FUEGO LT 3000D-C	S4052VE	60	6Q626401	REAR COVER
20 FUEGO LT 3000D-C	S4052VE	61	6Q342901	REAR CAP SCREW
20 FUEGO LT 3000D-C	S4052VE	62	6H595701	OSCILLATING GEAR WASHER
20 FUEGO LT 3000D-C	S4052VE	63	6Q118401	OSCILLATING GEAR
20 FUEGO LT 3000D-C	S4052VE	64	6H770601	OSCILLATING GEAR O RING
20 FUEGO LT 3000D-C	S4052VE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 3000D-C	S4052VE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 3000D-C	S4052VE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 3000D-C	S4052VE	68	6G670501	DRIVE GEAR O RING

20 FUEGO LT 3000D-C	S4052VE	69	6Q341801	DRIVE GEAR
20 FUEGO LT 3000D-C	S4052VE	70	63758502	DRIVE GEAR WASHER
20 FUEGO LT 3000D-C	S4052VE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 3000D-C	S4052VE	72	6Q624301	SIDE COVER
20 FUEGO LT 3000D-C	S4052VE	73	6Q342701	SIDE COVER SCREW (A)
20 FUEGO LT 3000D-C	S4052VE	74	6Q342601	SIDE COVER SCREW (B)
20 FUEGO LT 3000D-C	S4052VE	75	6J100201	SIDE COVER PACKING
20 FUEGO LT 3000D-C	S4052VE	76	6Q663601	HANDLE ASSY
20 FUEGO LT 3000D-C	S4052VE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 3000D-C	S4052VE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 3000D-C	S4052VE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 3000D-C	S4052VE	80	6Q345101	HANDLE CAP
20 FUEGO LT 3000D-C	S4052VE	81	6J639902	ONEWAY CLUTCH WASHER
20 FUEGO LT 4000D-C	S4072VE	1	6Q352901	DRAG KNOB
20 FUEGO LT 4000D-C	S4072VE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 4000D-C	S4072VE	3	6Q621901	KEY WASHER
20 FUEGO LT 4000D-C	S4072VE	4	6J678801	ATD DRAG WASHER (3PCS/PK)
20 FUEGO LT 4000D-C	S4072VE	5	6Q346001	EARED WASHER
20 FUEGO LT 4000D-C	S4072VE	2 6	6Q840101	SPOOL ASSY(2 6)
20 FUEGO LT 4000D-C	S4072VE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 4000D-C	S4072VE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 4000D-C	S4072VE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 4000D-C	S4072VE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 4000D-C	S4072VE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 4000D-C	S4072VE	12	6Q797701	CLICK LEAF SPRING
20 FUEGO LT 4000D-C	S4072VE	13	6Q798201	CLICK SPRING HOLDER
20 FUEGO LT 4000D-C	S4072VE	14	6Q344001	SPOOL WASHER (E)
20 FUEGO LT 4000D-C	S4072VE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 4000D-C	S4072VE	16	6Q177001	ROTOR NUT
20 FUEGO LT 4000D-C	S4072VE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 4000D-C	S4072VE	18	6Q351826	ROTOR
20 FUEGO LT 4000D-C	S4072VE	19	6H413601	BAIL TRIP LEVER SPRING
20 FUEGO LT 4000D-C	S4072VE	20	6Q351901	BAIL TRIP LEVER
20 FUEGO LT 4000D-C	S4072VE	21	6H417701	BAIL TRIP LEVER SCREW
20 FUEGO LT 4000D-C	S4072VE	22	6Q129501	BAIL SPRING SHAFT
20 FUEGO LT 4000D-C	S4072VE	23	6H576101	BAIL SPRING SHAFT PLATE
20 FUEGO LT 4000D-C	S4072VE	24	6H414201	BAIL SPRING
20 FUEGO LT 4000D-C	S4072VE	25	6Q121501	BAIL SPRING HOLDER
20 FUEGO LT 4000D-C	S4072VE	26	6Q352101	BAIL ARM COVER
20 FUEGO LT 4000D-C	S4072VE	27	6Q342901	BAIL ARM COVER SCREW
20 FUEGO LT 4000D-C	S4072VE	28	6Q121620	BAIL ARM
20 FUEGO LT 4000D-C	S4072VE	29	6Q121701	BAIL ARM SCREW COLLAR
20 FUEGO LT 4000D-C	S4072VE	30	6Q343401	BAIL ARM SCREW
20 FUEGO LT 4000D-C	S4072VE	31	6G195602	ROLLER SCREW
20 FUEGO LT 4000D-C	S4072VE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 4000D-C	S4072VE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 4000D-C	S4072VE	34	6J089901	LINE ROLLER
20 FUEGO LT 4000D-C	S4072VE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 4000D-C	S4072VE	36	6Q777201	BAIL
20 FUEGO LT 4000D-C	S4072VE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 4000D-C	S4072VE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 4000D-C	S4072VE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 4000D-C	S4072VE	40	6J354801	MAGSEALED PLATE O RING
20 FUEGO LT 4000D-C	S4072VE	41	-----	-----
20 FUEGO LT 4000D-C	S4072VE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 4000D-C	S4072VE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 4000D-C	S4072VE	44	6J001403	CLUTCH RING
20 FUEGO LT 4000D-C	S4072VE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 4000D-C	S4072VE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 4000D-C	S4072VE	47	6G535104	PINION BALL BEARING (A)
20 FUEGO LT 4000D-C	S4072VE	48	63758502	PINION BEARING WASHER
20 FUEGO LT 4000D-C	S4072VE	49	6Q351201	PINION GEAR
20 FUEGO LT 4000D-C	S4072VE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 4000D-C	S4072VE	51	6G466202	PINION BALL BEARING (B)
20 FUEGO LT 4000D-C	S4072VE	52	-----	-----
20 FUEGO LT 4000D-C	S4072VE	53	6Q674601	BODY
20 FUEGO LT 4000D-C	S4072VE	54	6Q351001	MAIN SHAFT
20 FUEGO LT 4000D-C	S4072VE	55	6Q126302	OSCILLATING POST (A)
20 FUEGO LT 4000D-C	S4072VE	56	6Q119102	OSCILLATING POST (B)
20 FUEGO LT 4000D-C	S4072VE	57	6Q118101	ANTI REVERSE CAM
20 FUEGO LT 4000D-C	S4072VE	58	6H697801	ANTI REVERSE CAM SPRING
20 FUEGO LT 4000D-C	S4072VE	59	6Q118001	ANTI REVERSE LEVER
20 FUEGO LT 4000D-C	S4072VE	60	6Q674801	REAR COVER
20 FUEGO LT 4000D-C	S4072VE	61	6Q342901	REAR CAP SCREW
20 FUEGO LT 4000D-C	S4072VE	62	6H595701	OSCILLATING GEAR WASHER
20 FUEGO LT 4000D-C	S4072VE	63	6Q350901	OSCILLATING GEAR
20 FUEGO LT 4000D-C	S4072VE	64	6G466001	OSCILLATING GEAR O RING
20 FUEGO LT 4000D-C	S4072VE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 4000D-C	S4072VE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 4000D-C	S4072VE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 4000D-C	S4072VE	68	6G670501	DRIVE GEAR O RING
20 FUEGO LT 4000D-C	S4072VE	69	6Q351301	DRIVE GEAR
20 FUEGO LT 4000D-C	S4072VE	70	63758502	DRIVE GEAR WASHER
20 FUEGO LT 4000D-C	S4072VE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 4000D-C	S4072VE	72	6Q674701	SIDE COVER
20 FUEGO LT 4000D-C	S4072VE	73	6Q342701	SIDE COVER SCREW (A)
20 FUEGO LT 4000D-C	S4072VE	74	6Q342601	SIDE COVER SCREW (B)
20 FUEGO LT 4000D-C	S4072VE	75	6J100201	SIDE COVER PACKING
20 FUEGO LT 4000D-C	S4072VE	76	6Q675201	HANDLE ASSY
20 FUEGO LT 4000D-C	S4072VE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 4000D-C	S4072VE	78	6G472401	DRIVE BEARING RETAINER

20 FUEGO LT 4000D-C	S4072VE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 4000D-C	S4072VE	80	6Q345101	HANDLE CAP
20 FUEGO LT 4000D-C	S4072VE	81	6J639902	ONEWAY CLUTCH WASHER
20 FUEGO LT 5000D-C	S4082VE	1	6Q352901	DRAG KNOB
20 FUEGO LT 5000D-C	S4082VE	2	6Q346101	DRAG WASHER RETAINER
20 FUEGO LT 5000D-C	S4082VE	3	6Q621901	KEY WASHER
20 FUEGO LT 5000D-C	S4082VE	4	6J678801	ATD DRAG WASHER (3PCS/PK)
20 FUEGO LT 5000D-C	S4082VE	5	6Q346001	EARED WASHER
20 FUEGO LT 5000D-C	S4082VE	2 6	6Q840401	SPOOL ASSY(2 6)
20 FUEGO LT 5000D-C	S4082VE	7	6Q382701	SPOOL WASHER (A)
20 FUEGO LT 5000D-C	S4082VE	8	6E332501	SPOOL BALL BEARING
20 FUEGO LT 5000D-C	S4082VE	9	6B411706	SPOOL WASHER (B)
20 FUEGO LT 5000D-C	S4082VE	10	6E398003	SPOOL WASHER (C)
20 FUEGO LT 5000D-C	S4082VE	11	6Q348502	SPOOL WASHER (D)
20 FUEGO LT 5000D-C	S4082VE	12	6Q797701	CLICK LEAF SPRING
20 FUEGO LT 5000D-C	S4082VE	13	6Q798201	CLICK SPRING HOLDER
20 FUEGO LT 5000D-C	S4082VE	14	6Q344001	SPOOL WASHER (E)
20 FUEGO LT 5000D-C	S4082VE	15	6H986901	ROTOR NUT PACKING
20 FUEGO LT 5000D-C	S4082VE	16	6Q177001	ROTOR NUT
20 FUEGO LT 5000D-C	S4082VE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 5000D-C	S4082VE	18	6Q129232	ROTOR
20 FUEGO LT 5000D-C	S4082VE	19	6H413601	BAIL TRIP LEVER SPRING
20 FUEGO LT 5000D-C	S4082VE	20	6Q129301	BAIL TRIP LEVER
20 FUEGO LT 5000D-C	S4082VE	21	6H417701	BAIL TRIP LEVER SCREW
20 FUEGO LT 5000D-C	S4082VE	22	6Q129501	BAIL SPRING SHAFT
20 FUEGO LT 5000D-C	S4082VE	23	6H576101	BAIL SPRING SHAFT PLATE
20 FUEGO LT 5000D-C	S4082VE	24	6H414201	BAIL SPRING
20 FUEGO LT 5000D-C	S4082VE	25	6Q121501	BAIL SPRING HOLDER
20 FUEGO LT 5000D-C	S4082VE	26	6Q129601	BAIL ARM COVER
20 FUEGO LT 5000D-C	S4082VE	27	6Q342901	BAIL ARM COVER SCREW
20 FUEGO LT 5000D-C	S4082VE	28	6Q121620	BAIL ARM
20 FUEGO LT 5000D-C	S4082VE	29	6Q121701	BAIL ARM SCREW COLLAR
20 FUEGO LT 5000D-C	S4082VE	30	6Q343401	BAIL ARM SCREW
20 FUEGO LT 5000D-C	S4082VE	31	6G195602	ROLLER SCREW
20 FUEGO LT 5000D-C	S4082VE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 5000D-C	S4082VE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 5000D-C	S4082VE	34	6J089901	LINE ROLLER
20 FUEGO LT 5000D-C	S4082VE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 5000D-C	S4082VE	36	6Q777301	BAIL
20 FUEGO LT 5000D-C	S4082VE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 5000D-C	S4082VE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 5000D-C	S4082VE	39	6J688201	MAGSEALED PLATE
20 FUEGO LT 5000D-C	S4082VE	40	6J354801	MAGSEALED PLATE O RING
20 FUEGO LT 5000D-C	S4082VE	41	-----	-----
20 FUEGO LT 5000D-C	S4082VE	42	6Q266601	SHIELD PLATE
20 FUEGO LT 5000D-C	S4082VE	43	6J388401	ONEWAY CLUTCH
20 FUEGO LT 5000D-C	S4082VE	44	6J001403	CLUTCH RING
20 FUEGO LT 5000D-C	S4082VE	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO LT 5000D-C	S4082VE	46	6Q195601	PINION BEARING PLATE
20 FUEGO LT 5000D-C	S4082VE	47	6G535104	PINION BALL BEARING (A)
20 FUEGO LT 5000D-C	S4082VE	48	63758502	PINION BEARING WASHER
20 FUEGO LT 5000D-C	S4082VE	49	6Q351201	PINION GEAR
20 FUEGO LT 5000D-C	S4082VE	50	6H931701	PINION SPRING WASHER
20 FUEGO LT 5000D-C	S4082VE	51	6G466202	PINION BALL BEARING (B)
20 FUEGO LT 5000D-C	S4082VE	52	-----	-----
20 FUEGO LT 5000D-C	S4082VE	53	6Q674601	BODY
20 FUEGO LT 5000D-C	S4082VE	54	6Q351001	MAIN SHAFT
20 FUEGO LT 5000D-C	S4082VE	55	6Q126302	OSCILLATING POST (A)
20 FUEGO LT 5000D-C	S4082VE	56	6Q119102	OSCILLATING POST (B)
20 FUEGO LT 5000D-C	S4082VE	57	6Q118101	ANTI REVERSE CAM
20 FUEGO LT 5000D-C	S4082VE	58	6H697801	ANTI REVERSE CAM SPRING
20 FUEGO LT 5000D-C	S4082VE	59	6Q118001	ANTI REVERSE LEVER
20 FUEGO LT 5000D-C	S4082VE	60	6Q674801	REAR COVER
20 FUEGO LT 5000D-C	S4082VE	61	6Q342901	REAR CAP SCREW
20 FUEGO LT 5000D-C	S4082VE	62	6H595701	OSCILLATING GEAR WASHER
20 FUEGO LT 5000D-C	S4082VE	63	6Q350901	OSCILLATING GEAR
20 FUEGO LT 5000D-C	S4082VE	64	6G466001	OSCILLATING GEAR O RING
20 FUEGO LT 5000D-C	S4082VE	65	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 5000D-C	S4082VE	66	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 5000D-C	S4082VE	67	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO LT 5000D-C	S4082VE	68	6G670501	DRIVE GEAR O RING
20 FUEGO LT 5000D-C	S4082VE	69	6Q351301	DRIVE GEAR
20 FUEGO LT 5000D-C	S4082VE	70	63758502	DRIVE GEAR WASHER
20 FUEGO LT 5000D-C	S4082VE	71	6G467302	DRIVE BALL BEARING (A)
20 FUEGO LT 5000D-C	S4082VE	72	6Q674701	SIDE COVER
20 FUEGO LT 5000D-C	S4082VE	73	6Q342701	SIDE COVER SCREW (A)
20 FUEGO LT 5000D-C	S4082VE	74	6Q342601	SIDE COVER SCREW (B)
20 FUEGO LT 5000D-C	S4082VE	75	6J100201	SIDE COVER PACKING
20 FUEGO LT 5000D-C	S4082VE	76	6Q675201	HANDLE ASSY
20 FUEGO LT 5000D-C	S4082VE	77	6G522706	DRIVE BALL BEARING (B)
20 FUEGO LT 5000D-C	S4082VE	78	6G472401	DRIVE BEARING RETAINER
20 FUEGO LT 5000D-C	S4082VE	79	6G162401	HANDLE CAP O RING
20 FUEGO LT 5000D-C	S4082VE	80	6Q345101	HANDLE CAP
20 FUEGO LT 5000D-C	S4082VE	81	6J639902	ONEWAY CLUTCH WASHER
20 FUEGO LT 6000D	S4092VE	1	6Q364201	DRAG KNOB
20 FUEGO LT 6000D	S4092VE	2	61704101	DRAG WASHER RETAINER
20 FUEGO LT 6000D	S4092VE	3	6J577501	KEY WASHER
20 FUEGO LT 6000D	S4092VE	4	6J679001	ATD DRAG WASHER (3PCS/PK)
20 FUEGO LT 6000D	S4092VE	5	6Q377601	EARED WASHER
20 FUEGO LT 6000D	S4092VE	2 6	6Q840701	SPOOL ASSY(2 6)
20 FUEGO LT 6000D	S4092VE	7	6Q416201	SPOOL WASHER (A)

20 FUEGO LT 6000D	S4092VE	8	6G466206	SPOOL BALL BEARING
20 FUEGO LT 6000D	S4092VE	9	6E096505	SPOOL WASHER (B)
20 FUEGO LT 6000D	S4092VE	10	6F050104	SPOOL WASHER (C)
20 FUEGO LT 6000D	S4092VE	11	6Q363801	SPOOL WASHER (D)
20 FUEGO LT 6000D	S4092VE	12	6Q797701	CLICK LEAF SPRING
20 FUEGO LT 6000D	S4092VE	13	6Q798301	CLICK SPRING HOLDER
20 FUEGO LT 6000D	S4092VE	14	6Q377501	SPOOL WASHER (E)
20 FUEGO LT 6000D	S4092VE	15	6H995201	ROTOR NUT PACKING
20 FUEGO LT 6000D	S4092VE	16	6Q363701	ROTOR NUT
20 FUEGO LT 6000D	S4092VE	17	6H022701	ROTOR NUT SCREW
20 FUEGO LT 6000D	S4092VE	18	6Q134533	ROTOR
20 FUEGO LT 6000D	S4092VE	19	6H413601	BAIL TRIP LEVER SPRING
20 FUEGO LT 6000D	S4092VE	20	6Q134601	BAIL TRIP LEVER
20 FUEGO LT 6000D	S4092VE	21	6H417701	BAIL TRIP LEVER SCREW
20 FUEGO LT 6000D	S4092VE	22	6Q134801	BAIL SPRING SHAFT
20 FUEGO LT 6000D	S4092VE	23	6H576101	BAIL SPRING SHAFT PLATE
20 FUEGO LT 6000D	S4092VE	24	6H640701	BAIL SPRING
20 FUEGO LT 6000D	S4092VE	25	6Q121501	BAIL SPRING HOLDER
20 FUEGO LT 6000D	S4092VE	26	6Q134901	BAIL ARM COVER
20 FUEGO LT 6000D	S4092VE	27	6Q342901	BAIL ARM COVER SCREW
20 FUEGO LT 6000D	S4092VE	28	6Q121620	BAIL ARM
20 FUEGO LT 6000D	S4092VE	29	6Q121701	BAIL ARM SCREW COLLAR
20 FUEGO LT 6000D	S4092VE	30	6Q343401	BAIL ARM SCREW
20 FUEGO LT 6000D	S4092VE	31	6G195602	ROLLER SCREW
20 FUEGO LT 6000D	S4092VE	32	6G195501	ROLLER COLLAR (A)
20 FUEGO LT 6000D	S4092VE	33	6G220701	ROLLER COLLAR (B)
20 FUEGO LT 6000D	S4092VE	34	6J089901	LINE ROLLER
20 FUEGO LT 6000D	S4092VE	35	6Q203401	ROLLER COLLAR (C)
20 FUEGO LT 6000D	S4092VE	36	6Q135001	BAIL
20 FUEGO LT 6000D	S4092VE	37	6G837101	MAGSEALED PLATE SCREW
20 FUEGO LT 6000D	S4092VE	38	63754102	MAGSEALED PLATE SCREW WASHER
20 FUEGO LT 6000D	S4092VE	39	6J289301	MAGSEALED PLATE
20 FUEGO LT 6000D	S4092VE	40	6J212901	MAGSEALED PLATE O RING
20 FUEGO LT 6000D	S4092VE	41	6J238801	SHIELD PLATE WASHER
20 FUEGO LT 6000D	S4092VE	42	6Q363501	SHIELD PLATE
20 FUEGO LT 6000D	S4092VE	43	6J309101	ONEWAY CLUTCH
20 FUEGO LT 6000D	S4092VE	44	6J690501	CLUTCH RING
20 FUEGO LT 6000D	S4092VE	45	6Q195701	PINION BEARING PLATE SCREW
20 FUEGO LT 6000D	S4092VE	46	6Q205901	PINION BEARING PLATE
20 FUEGO LT 6000D	S4092VE	47	66354801	PINION BALL BEARING (A)
20 FUEGO LT 6000D	S4092VE	48	63712824	PINION BEARING WASHER
20 FUEGO LT 6000D	S4092VE	49	6Q405001	PINION GEAR
20 FUEGO LT 6000D	S4092VE	50	6G572501	PINION SPRING WASHER
20 FUEGO LT 6000D	S4092VE	51	6G467108	PINION BALL BEARING (B)
20 FUEGO LT 6000D	S4092VE	52	-----	-----
20 FUEGO LT 6000D	S4092VE	53	6Q675701	BODY
20 FUEGO LT 6000D	S4092VE	54	6Q362601	MAIN SHAFT
20 FUEGO LT 6000D	S4092VE	55	6Q126303	OSCILLATING POST (A)
20 FUEGO LT 6000D	S4092VE	56	6Q119103	OSCILLATING POST (B)
20 FUEGO LT 6000D	S4092VE	57	6Q133401	ANTI REVERSE CAM
20 FUEGO LT 6000D	S4092VE	58	6H697801	ANTI REVERSE CAM SPRING
20 FUEGO LT 6000D	S4092VE	59	6Q118001	ANTI REVERSE LEVER
20 FUEGO LT 6000D	S4092VE	60	6Q675901	REAR COVER
20 FUEGO LT 6000D	S4092VE	61	6Q342901	REAR CAP SCREW
20 FUEGO LT 6000D	S4092VE	62	6G644201	OSCILLATING GEAR WASHER
20 FUEGO LT 6000D	S4092VE	63	6Q133501	OSCILLATING GEAR
20 FUEGO LT 6000D	S4092VE	64	6B853101	OSCILLATING GEAR O RING
20 FUEGO LT 6000D	S4092VE	65	6G522103	OSCILLATING GEAR BEARING WASHER
20 FUEGO LT 6000D	S4092VE	66	6G467108	OSCILLATING GEAR BALL BEARING
20 FUEGO LT 6000D	S4092VE	67	6H463401	OSCILLATING GEAR SCREW
20 FUEGO LT 6000D	S4092VE	68	6G645301	DRIVE GEAR O RING
20 FUEGO LT 6000D	S4092VE	69	6Q403701	DRIVE GEAR
20 FUEGO LT 6000D	S4092VE	70	63737808	DRIVE GEAR WASHER
20 FUEGO LT 6000D	S4092VE	71	6G523405	DRIVE BALL BEARING (A)
20 FUEGO LT 6000D	S4092VE	72	6Q675801	SIDE COVER
20 FUEGO LT 6000D	S4092VE	73	6Q342701	SIDE COVER SCREW (A)
20 FUEGO LT 6000D	S4092VE	74	6Q342601	SIDE COVER SCREW (B)
20 FUEGO LT 6000D	S4092VE	75	6H730801	SIDE COVER PACKING
20 FUEGO LT 6000D	S4092VE	76	6Q676301	HANDLE ASSY
20 FUEGO LT 6000D	S4092VE	77	6B861705	DRIVE BALL BEARING (B)
20 FUEGO LT 6000D	S4092VE	78	6G525101	DRIVE BEARING RETAINER
20 FUEGO LT 6000D	S4092VE	79	6G672401	HANDLE CAP O RING
20 FUEGO LT 6000D	S4092VE	80	6Q364801	HANDLE CAP
20 FUEGO LT 6000D	S4092VE	81	-----	-----
20 FUEGO PB LT 2500D	S4042GF	1	6Q346201	DRAG KNOB ASSY
20 FUEGO PB LT 2500D	S4042GF	2	6Q346101	DRAG RING
20 FUEGO PB LT 2500D	S4042GF	3	6Q621901	DRAG DISK WASHER
20 FUEGO PB LT 2500D	S4042GF	4	61678801	ATD WASHER ASSY (1pack-3 pcs)
20 FUEGO PB LT 2500D	S4042GF	5	6Q346001	DRAG LIP WASHER
20 FUEGO PB LT 2500D	S4042GF	6	6Q774801	SPOOL ASSY
20 FUEGO PB LT 2500D	S4042GF	7	6Q382701	SPOOL WASHER (A)
20 FUEGO PB LT 2500D	S4042GF	8	6E332501	BALL BEARING (OR)
20 FUEGO PB LT 2500D	S4042GF	9	6B411706	WASHER (=6B411700)
20 FUEGO PB LT 2500D	S4042GF	10	6E398003	WASHER
20 FUEGO PB LT 2500D	S4042GF	11	6Q348502	SPOOL WASHER (B)
20 FUEGO PB LT 2500D	S4042GF	12	6H416101	CLICK LEAF SPRING 10 CERT
20 FUEGO PB LT 2500D	S4042GF	13	6M021401	CLICK HOLDER
20 FUEGO PB LT 2500D	S4042GF	14	6Q344001	CLICK HOLDER WASHER
20 FUEGO PB LT 2500D	S4042GF	15	6H986901	PACKING
20 FUEGO PB LT 2500D	S4042GF	16	6Q177001	ROTER NUT
20 FUEGO PB LT 2500D	S4042GF	17	6H022701	SCREW

20 FUEGO PB LT 2500D	S4042GF	18	6Q343029	ROTOR
20 FUEGO PB LT 2500D	S4042GF	19	6H413601	KICK LEVER SPRING
20 FUEGO PB LT 2500D	S4042GF	20	6Q343101	KICK LEVER
20 FUEGO PB LT 2500D	S4042GF	21	6H417701	KICK LEVER SCREW
20 FUEGO PB LT 2500D	S4042GF	22	6Q343301	ARMLEVER SHAFT
20 FUEGO PB LT 2500D	S4042GF	23	6H576101	PLATE
20 FUEGO PB LT 2500D	S4042GF	24	6J642801	ARM LEVER SHAFT SPRING
20 FUEGO PB LT 2500D	S4042GF	25	6Q121501	BAIL SPRING HOLDER
20 FUEGO PB LT 2500D	S4042GF	26	6Q343501	ARMLEVER SPRING COVER
20 FUEGO PB LT 2500D	S4042GF	27	6Q342901	COVER SCREW
20 FUEGO PB LT 2500D	S4042GF	28	6Q121604	BAIL ARM
20 FUEGO PB LT 2500D	S4042GF	29	6Q121701	COLLAR
20 FUEGO PB LT 2500D	S4042GF	30	6Q343401	ARMLEVER SCREW
20 FUEGO PB LT 2500D	S4042GF	31	6G195602	SCREW
20 FUEGO PB LT 2500D	S4042GF	32	6G195501	COLLAR
20 FUEGO PB LT 2500D	S4042GF	33	6G220701	COLLAR
20 FUEGO PB LT 2500D	S4042GF	34	6J089902	LINE ROLLER
20 FUEGO PB LT 2500D	S4042GF	35	6Q203401	COLLAR
20 FUEGO PB LT 2500D	S4042GF	36	6Q777001	BAIL ASSY
20 FUEGO PB LT 2500D	S4042GF	37	6G837101	SCREW
20 FUEGO PB LT 2500D	S4042GF	38	63754102	WASHER (=63754100)
20 FUEGO PB LT 2500D	S4042GF	39	6J688201	MAGSEALED ASSY
20 FUEGO PB LT 2500D	S4042GF	40	6J354801	O -RING (A)
20 FUEGO PB LT 2500D	S4042GF	41	6Q266601	CAP
20 FUEGO PB LT 2500D	S4042GF	42	6J639902	ONEWAY CLUTCH WASHER
20 FUEGO PB LT 2500D	S4042GF	43	6J388401	ONEWAY CLUTCH AS
20 FUEGO PB LT 2500D	S4042GF	44	6J001403	CLUTCH RING
20 FUEGO PB LT 2500D	S4042GF	45	6Q126201	SCREW
20 FUEGO PB LT 2500D	S4042GF	46	6Q195601	BEARING RETAINER (A)
20 FUEGO PB LT 2500D	S4042GF	47	6G467302	BALL BEARING (OR)
20 FUEGO PB LT 2500D	S4042GF	48	63758511	WASHER (ADJUST) (0.02 MM)
20 FUEGO PB LT 2500D	S4042GF	49	6Q360301	PINION GEAR
20 FUEGO PB LT 2500D	S4042GF	50	6H931701	SPRING WASHER
20 FUEGO PB LT 2500D	S4042GF	51	6H959601	BALL BEARING
20 FUEGO PB LT 2500D	S4042GF	52	6Q774601	BODY
20 FUEGO PB LT 2500D	S4042GF	53	6Q341501	MAIN SHAFT
20 FUEGO PB LT 2500D	S4042GF	54	6Q126301	STABILIZER BAR
20 FUEGO PB LT 2500D	S4042GF	55	6Q119101	STABILIZER BAR
20 FUEGO PB LT 2500D	S4042GF	56	6Q118101	ANTI-REVERSE CAM
20 FUEGO PB LT 2500D	S4042GF	57	6H697801	ANTI-REVERSE CAM SPRING
20 FUEGO PB LT 2500D	S4042GF	58	6Q118001	ANTI-REVERSE LEVER
20 FUEGO PB LT 2500D	S4042GF	59	6Q626401	REAR CAP
20 FUEGO PB LT 2500D	S4042GF	60	6Q342901	COVER SCREW
20 FUEGO PB LT 2500D	S4042GF	61	6H595701	WASHER
20 FUEGO PB LT 2500D	S4042GF	62	6Q139001	OSCILLATING GEAR
20 FUEGO PB LT 2500D	S4042GF	63	6H770601	O-RING
20 FUEGO PB LT 2500D	S4042GF	64	6H129201	WASHER (=6H129200)
20 FUEGO PB LT 2500D	S4042GF	65	6G469005	BALL BEARING (OR)
20 FUEGO PB LT 2500D	S4042GF	66	6Q126101	SCREW
20 FUEGO PB LT 2500D	S4042GF	67	6G670501	O RING
20 FUEGO PB LT 2500D	S4042GF	68	6Q360401	DRIVE GEAR
20 FUEGO PB LT 2500D	S4042GF	69	63758511	WASHER (ADJUST) (0.02 MM)
20 FUEGO PB LT 2500D	S4042GF	70	6G467302	BALL BEARING (OR)
20 FUEGO PB LT 2500D	S4042GF	71	6Q774701	SIDE COVER
20 FUEGO PB LT 2500D	S4042GF	72	6Q342701	BODY COVER SCREW
20 FUEGO PB LT 2500D	S4042GF	73	6Q342601	BODY COVER SCREW
20 FUEGO PB LT 2500D	S4042GF	74	6J100201	PACKING
20 FUEGO PB LT 2500D	S4042GF	75	6Q775001	HANDLE ASSY
20 FUEGO PB LT 2500D	S4042GF	76	6G522706	PINION BALL BEARING
20 FUEGO PB LT 2500D	S4042GF	77	6G472401	RING
20 FUEGO PB LT 2500D	S4042GF	78	6G162401	O-RING
20 FUEGO PB LT 2500D	S4042GF	79	6Q345101	HANDLE CAP
20 FUEGO PB LT 2500D	S4042GF	1	6Q346201	DRAG KNOB
20 FUEGO PB LT 2500D	S4042GF	2	6Q346101	DRAG RING
20 FUEGO PB LT 2500D	S4042GF	3	6Q621901	DRAG DISC WASHER
20 FUEGO PB LT 2500D	S4042GF	4	6J678801	DRAG WASHER
20 FUEGO PB LT 2500D	S4042GF	5	6Q346001	DRAG RIP WASHER
20 FUEGO PB LT 2500D	S4042GF	2~6	6Q774801	SPOOL ASSY
20 FUEGO PB LT 2500D	S4042GF	7	6Q382701	SPOOL WASHER(A)
20 FUEGO PB LT 2500D	S4042GF	8	6E332501	SPOOL BALL BEARING
20 FUEGO PB LT 2500D	S4042GF	9	6B411706	SPOOL WASHER(B)
20 FUEGO PB LT 2500D	S4042GF	10	6E398003	SPOOL WASHER(C)
20 FUEGO PB LT 2500D	S4042GF	11	6Q348502	SPOOL WASHER(D)
20 FUEGO PB LT 2500D	S4042GF	12	6Q797701	CLICK LEAF SPRING
20 FUEGO PB LT 2500D	S4042GF	13	6Q798201	CLICK HOLDER
20 FUEGO PB LT 2500D	S4042GF	14	6Q344001	CLICK HOLDER WASHER
20 FUEGO PB LT 2500D	S4042GF	15	6H986901	ROTOR NUT PACKING
20 FUEGO PB LT 2500D	S4042GF	16	6Q177001	ROTOR NUT
20 FUEGO PB LT 2500D	S4042GF	17	6H022701	ROTOR NUT SCREW
20 FUEGO PB LT 2500D	S4042GF	18	6Q343037	ROTOR
20 FUEGO PB LT 2500D	S4042GF	19	6H413601	KICK LEVER SPRING
20 FUEGO PB LT 2500D	S4042GF	20	6Q343101	KICK LEVER
20 FUEGO PB LT 2500D	S4042GF	21	6H417701	KICK LEVER SCREW
20 FUEGO PB LT 2500D	S4042GF	22	6Q343301	ARM LEVER SHAFT
20 FUEGO PB LT 2500D	S4042GF	23	6H576101	ARM LEVER SHAFT PLATE
20 FUEGO PB LT 2500D	S4042GF	24	6J642801	ARM LEVER SPRING
20 FUEGO PB LT 2500D	S4042GF	25	6Q121501	ARM LEVER SPRING HOLDER
20 FUEGO PB LT 2500D	S4042GF	26	6Q343501	ARM LEVER SPRING COVER
20 FUEGO PB LT 2500D	S4042GF	27	6Q342901	COVER SCREW
20 FUEGO PB LT 2500D	S4042GF	28	6Q121604	ARM LEVER
20 FUEGO PB LT 2500D	S4042GF	29	6Q121701	ARM LEVER SCREW COLLAR

20 FUEGO PB LT 2500D	S4042GF	30	6Q343401	ARM LEVER SCREW
20 FUEGO PB LT 2500D	S4042GF	31	6G195602	ROLLER SCREW
20 FUEGO PB LT 2500D	S4042GF	32	6G195501	ROLLER COLLAR(A)
20 FUEGO PB LT 2500D	S4042GF	33	6G220701	ROLLER COLLAR(B)
20 FUEGO PB LT 2500D	S4042GF	34	6J089902	LINE ROLLER
20 FUEGO PB LT 2500D	S4042GF	35	6Q203401	ROLLER COLLAR(C)
20 FUEGO PB LT 2500D	S4042GF	36	6Q777001	BAIL ASSY
20 FUEGO PB LT 2500D	S4042GF	37	6G837101	MAGSHIELD PLATE SCREW
20 FUEGO PB LT 2500D	S4042GF	38	63754102	MAGSHIELD PLATE SCREW WASHER
20 FUEGO PB LT 2500D	S4042GF	39	6J688201	MAGSHIELD PLATE
20 FUEGO PB LT 2500D	S4042GF	40	6J354801	MAG SHIELD PLATE O RING
20 FUEGO PB LT 2500D	S4042GF	41	6Q266601	MAGSHIELD CAP
20 FUEGO PB LT 2500D	S4042GF	42	6J639902	ONEWAY CLUTCH WASHER
20 FUEGO PB LT 2500D	S4042GF	43	6J388401	ONEWAY CLUTCH
20 FUEGO PB LT 2500D	S4042GF	44	6J001403	CLUTCH RING
20 FUEGO PB LT 2500D	S4042GF	45	6Q126201	PINION BEARING PLATE SCREW
20 FUEGO PB LT 2500D	S4042GF	46	6Q195601	PINION BEARING PLATE
20 FUEGO PB LT 2500D	S4042GF	47	6G467302	PINION BALL BEARING(A)
20 FUEGO PB LT 2500D	S4042GF	48	63758502	PINION BEARING(A) WASHER
20 FUEGO PB LT 2500D	S4042GF	49	6Q360301	PINION GEAR
20 FUEGO PB LT 2500D	S4042GF	50	6H931701	PINION BEARING(B) WASHER
20 FUEGO PB LT 2500D	S4042GF	51	6H959601	PINION BALL BEARING(B)
20 FUEGO PB LT 2500D	S4042GF	52	6Q774601	BODY
20 FUEGO PB LT 2500D	S4042GF	53	6Q341501	MAIN SHAFT
20 FUEGO PB LT 2500D	S4042GF	54	6Q126301	OSCILLATING POST(A)
20 FUEGO PB LT 2500D	S4042GF	55	6Q119101	OSCILLATING POST(B)
20 FUEGO PB LT 2500D	S4042GF	56	6Q118101	STOPPER CAM
20 FUEGO PB LT 2500D	S4042GF	57	6H697801	STOPPER CAM LEAF SPRING
20 FUEGO PB LT 2500D	S4042GF	58	6Q118001	STOPPER LEVER
20 FUEGO PB LT 2500D	S4042GF	59	6Q626401	REAR CAP
20 FUEGO PB LT 2500D	S4042GF	60	6Q342901	REAR CAP SCREW
20 FUEGO PB LT 2500D	S4042GF	61	6H595701	OSCILLATING GEAR WASHER
20 FUEGO PB LT 2500D	S4042GF	62	6Q139001	OSCILLATING GEAR
20 FUEGO PB LT 2500D	S4042GF	63	6H770601	OSCILLATING GEAR O RING
20 FUEGO PB LT 2500D	S4042GF	64	6H129201	OSCILLATING GEAR BEARING WASHER
20 FUEGO PB LT 2500D	S4042GF	65	6G469005	OSCILLATING GEAR BALL BEARING
20 FUEGO PB LT 2500D	S4042GF	66	6Q126101	OSCILLATING GEAR SCREW
20 FUEGO PB LT 2500D	S4042GF	67	6G670501	DRIVE GEAR RING
20 FUEGO PB LT 2500D	S4042GF	68	6Q360401	DRIVE GEAR
20 FUEGO PB LT 2500D	S4042GF	69	63758501	DRIVE WASHER
20 FUEGO PB LT 2500D	S4042GF	70	6G467302	DRIVE BALL BEARING(A)
20 FUEGO PB LT 2500D	S4042GF	71	6Q774701	BODY COVER
20 FUEGO PB LT 2500D	S4042GF	72	6Q342701	BODY COVER SCREW(A)
20 FUEGO PB LT 2500D	S4042GF	73	6Q342601	BODY COVER SCREW(B)
20 FUEGO PB LT 2500D	S4042GF	74	6J100201	HANDLE PACKING
20 FUEGO PB LT 2500D	S4042GF	75	6Q775001	HANDLE ASSY
20 FUEGO PB LT 2500D	S4042GF	76	6G522706	DRIVE BALL BEARING(B)
20 FUEGO PB LT 2500D	S4042GF	77	6G472401	DRIVE BEARING RING
20 FUEGO PB LT 2500D	S4042GF	78	6G162401	HANDLE CAP O RING
20 FUEGO PB LT 2500D	S4042GF	79	6Q345101	HANDLE CAP
20 FUEGO PB LT 2500D	S4042GF	51	6H959601	
20 FUEGO PB LT 2500D	S4042GF	52	6Q774601	
20 FUEGO PB LT 2500D	S4042GF	53	6Q341501	
20 FUEGO PB LT 2500D	S4042GF	54	6Q126301	
20 FUEGO PB LT 2500D	S4042GF	55	6Q119101	
20 FUEGO PB LT 2500D	S4042GF	56	6Q118101	
20 FUEGO PB LT 2500D	S4042GF	57	6H697801	
20 FUEGO PB LT 2500D	S4042GF	58	6Q118001	
20 FUEGO PB LT 2500D	S4042GF	59	6Q626401	
20 FUEGO PB LT 2500D	S4042GF	60	6Q342901	
20 FUEGO PB LT 2500D	S4042GF	61	6H595701	
20 FUEGO PB LT 2500D	S4042GF	62	6Q139001	
20 FUEGO PB LT 2500D	S4042GF	63	6H770601	
20 FUEGO PB LT 2500D	S4042GF	64	6H129201	
20 FUEGO PB LT 2500D	S4042GF	65	6G469005	
20 FUEGO PB LT 2500D	S4042GF	66	6Q126101	
20 FUEGO PB LT 2500D	S4042GF	67	6G670501	
20 FUEGO PB LT 2500D	S4042GF	68	6Q360401	
20 FUEGO PB LT 2500D	S4042GF	69	63758511	
20 FUEGO PB LT 2500D	S4042GF	70	6G467302	
20 FUEGO PB LT 2500D	S4042GF	71	6Q774701	
20 FUEGO PB LT 2500D	S4042GF	72	6Q342701	
20 FUEGO PB LT 2500D	S4042GF	73	6Q342601	
20 FUEGO PB LT 2500D	S4042GF	74	6J100201	
20 FUEGO PB LT 2500D	S4042GF	75	6Q775001	
20 FUEGO PB LT 2500D	S4042GF	76	6G522706	
20 FUEGO PB LT 2500D	S4042GF	77	6G472401	
20 FUEGO PB LT 2500D	S4042GF	78	6G162401	
20 FUEGO PB LT 2500D	S4042GF	79	6Q345101	
20 FUEGO PB LT 2500D	S4042GF	1	6Q346201	
20 FUEGO PB LT 2500D	S4042GF	2	6Q346101	
20 FUEGO PB LT 2500D	S4042GF	3	6Q621901	
20 FUEGO PB LT 2500D	S4042GF	4	6J678801	
20 FUEGO PB LT 2500D	S4042GF	5	6Q346001	
20 FUEGO PB LT 2500D	S4042GF	2~6	6Q774801	
20 FUEGO PB LT 2500D	S4042GF	7	6Q382701	
20 FUEGO PB LT 2500D	S4042GF	8	6E332501	
20 FUEGO PB LT 2500D	S4042GF	9	6B411706	
20 FUEGO PB LT 2500D	S4042GF	10	6E398003	
20 FUEGO PB LT 2500D	S4042GF	11	6Q348502	
20 FUEGO PB LT 2500D	S4042GF	12	6Q797701	

20 FUEGO PB LT 2500D	S4042GF	13	6Q798201
20 FUEGO PB LT 2500D	S4042GF	14	6Q344001
20 FUEGO PB LT 2500D	S4042GF	15	6H986901
20 FUEGO PB LT 2500D	S4042GF	16	6Q177001
20 FUEGO PB LT 2500D	S4042GF	17	6H022701
20 FUEGO PB LT 2500D	S4042GF	18	6Q343037
20 FUEGO PB LT 2500D	S4042GF	19	6H413601
20 FUEGO PB LT 2500D	S4042GF	20	6Q343101
20 FUEGO PB LT 2500D	S4042GF	21	6H417701
20 FUEGO PB LT 2500D	S4042GF	22	6Q343301
20 FUEGO PB LT 2500D	S4042GF	23	6H576101
20 FUEGO PB LT 2500D	S4042GF	24	6J642801
20 FUEGO PB LT 2500D	S4042GF	25	6Q121501
20 FUEGO PB LT 2500D	S4042GF	26	6Q343501
20 FUEGO PB LT 2500D	S4042GF	27	6Q342901
20 FUEGO PB LT 2500D	S4042GF	28	6Q121604
20 FUEGO PB LT 2500D	S4042GF	29	6Q121701
20 FUEGO PB LT 2500D	S4042GF	30	6Q343401
20 FUEGO PB LT 2500D	S4042GF	31	6G195602
20 FUEGO PB LT 2500D	S4042GF	32	6G195501
20 FUEGO PB LT 2500D	S4042GF	33	6G220701
20 FUEGO PB LT 2500D	S4042GF	34	6J089902
20 FUEGO PB LT 2500D	S4042GF	35	6Q203401
20 FUEGO PB LT 2500D	S4042GF	36	6Q777001
20 FUEGO PB LT 2500D	S4042GF	37	6G837101
20 FUEGO PB LT 2500D	S4042GF	38	63754102
20 FUEGO PB LT 2500D	S4042GF	39	6J688201
20 FUEGO PB LT 2500D	S4042GF	40	6J354801
20 FUEGO PB LT 2500D	S4042GF	41	6Q266601
20 FUEGO PB LT 2500D	S4042GF	42	6J639902
20 FUEGO PB LT 2500D	S4042GF	43	6J388401
20 FUEGO PB LT 2500D	S4042GF	44	6J001403
20 FUEGO PB LT 2500D	S4042GF	45	6Q126201
20 FUEGO PB LT 2500D	S4042GF	46	6Q195601
20 FUEGO PB LT 2500D	S4042GF	47	6G467302
20 FUEGO PB LT 2500D	S4042GF	48	63758502
20 FUEGO PB LT 2500D	S4042GF	49	6Q360301
20 FUEGO PB LT 2500D	S4042GF	50	6H931701
20 FUEGO PB LT 2500D	S4042GF	51	6H959601
20 FUEGO PB LT 2500D	S4042GF	52	6Q774601
20 FUEGO PB LT 2500D	S4042GF	53	6Q341501
20 FUEGO PB LT 2500D	S4042GF	54	6Q126301
20 FUEGO PB LT 2500D	S4042GF	55	6Q119101
20 FUEGO PB LT 2500D	S4042GF	56	6Q118101
20 FUEGO PB LT 2500D	S4042GF	57	6H697801
20 FUEGO PB LT 2500D	S4042GF	58	6Q118001
20 FUEGO PB LT 2500D	S4042GF	59	6Q626401
20 FUEGO PB LT 2500D	S4042GF	60	6Q342901
20 FUEGO PB LT 2500D	S4042GF	61	6H595701
20 FUEGO PB LT 2500D	S4042GF	62	6Q139001
20 FUEGO PB LT 2500D	S4042GF	63	6H770601
20 FUEGO PB LT 2500D	S4042GF	64	6H129201
20 FUEGO PB LT 2500D	S4042GF	65	6G469005
20 FUEGO PB LT 2500D	S4042GF	66	6Q126101
20 FUEGO PB LT 2500D	S4042GF	67	6G670501
20 FUEGO PB LT 2500D	S4042GF	68	6Q360401
20 FUEGO PB LT 2500D	S4042GF	69	63758501
20 FUEGO PB LT 2500D	S4042GF	70	6G467302
20 FUEGO PB LT 2500D	S4042GF	71	6Q774701
20 FUEGO PB LT 2500D	S4042GF	72	6Q342701
20 FUEGO PB LT 2500D	S4042GF	73	6Q342601
20 FUEGO PB LT 2500D	S4042GF	74	6J100201
20 FUEGO PB LT 2500D	S4042GF	75	6Q775001
20 FUEGO PB LT 2500D	S4042GF	76	6G522706
20 FUEGO PB LT 2500D	S4042GF	77	6G472401
20 FUEGO PB LT 2500D	S4042GF	78	6G162401
20 FUEGO PB LT 2500D	S4042GF	79	6Q345101