



F565RJ1 J HYPER TANACOM500F
 F5650BU U TANACOM 500(U)

F565RJ1
 F5650BU

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	LATES T PARTS	DESCRIPTION
TANACOM 500(U)	F5650BU	1	6G632205		SIDE PLATE(L)(IC)
TANACOM 500(U)	F5650BU	2	6E033201		MECHANICAL BRAKE LEAF SPRING
TANACOM 500(U)	F5650BU	3	6E489609		MECHANICAL BRAKE KNOB
TANACOM 500(U)	F5650BU	4	6B175503		MECHANICAL BRAKE WASHER(A)
TANACOM 500(U)	F5650BU	5	63757405		MECHANICAL BRAKE WASHER(B)
TANACOM 500(U)	F5650BU	6	6F462901		MOTORGear(A)
TANACOM 500(U)	F5650BU	7	6B181602		MOTORGear(A) BALL BEARING
TANACOM 500(U)	F5650BU	8	6F463001		MOTORGear RING
TANACOM 500(U)	F5650BU	9	63538207		MOTORGear(A) SCREW
TANACOM 500(U)	F5650BU	10	66372102		SPOOL SHAFT BALL BEARING
TANACOM 500(U)	F5650BU	11	6E280201		MOTORGear BALL BEARING
TANACOM 500(U)	F5650BU	12	6J415101		SPOOL AS
TANACOM 500(U)	F5650BU	13	6F656901		SPOOL GEAR
TANACOM 500(U)	F5650BU	14	6F657001		SPOOL GEAR RING
TANACOM 500(U)	F5650BU	15	6H565801		SPOOL SHAFT
TANACOM 500(U)	F5650BU	16	6G536001		SPOOL BALL BEARING(B)
TANACOM 500(U)	F5650BU	17	6F463901		RS SPOOL GEAR
TANACOM 500(U)	F5650BU	18	6F550501		RS SPOOL GEAR RETAINER
TANACOM 500(U)	F5650BU	19	6G077201		MOTORGear (B) COLLAR
TANACOM 500(U)	F5650BU	20	6G632301		MOTORGear (B)
TANACOM 500(U)	F5650BU	21	6G523405		SPOOL PLATE BALL BEARING
TANACOM 500(U)	F5650BU	22	6G579901		SPOOL PLATE
TANACOM 500(U)	F5650BU	23	6B395503		SPOOL PLATE SCREW
TANACOM 500(U)	F5650BU	24	6G536001		SPOOL SHAFT(B) BALL BEARING
TANACOM 500(U)	F5650BU	25	6G087501		SPOOL SHAFT GEAR
TANACOM 500(U)	F5650BU	26	63208702		SPOOL SHAFT GEAR RETAINER
TANACOM 500(U)	F5650BU	27	6B411703		SPOOL SHAFT GEAR WASHER
TANACOM 500(U)	F5650BU	28	6E292702		SPOOL PLATE BALL BEARING
TANACOM 500(U)	F5650BU	29	6J415201		FRAME AS
TANACOM 500(U)	F5650BU	30	6G116602		MOTOR AS
TANACOM 500(U)	F5650BU	31	6B055201		MOTOR O-RING

TANACOM 500(U)	F5650BU	32	6F024901			MOTOR GEAR(C) BEARING
TANACOM 500(U)	F5650BU	33	6F465701			MOTOR HOLDER AS
TANACOM 500(U)	F5650BU	34	6F465901			MOTOR HOLDER O-RING
TANACOM 500(U)	F5650BU	35	6F657501			MOTOR HOLDER PACKING
TANACOM 500(U)	F5650BU	36	63511801			MOTOR HOLDER SCREW
TANACOM 500(U)	F5650BU	37	6G087601			MOTORGEAR (C)
TANACOM 500(U)	F5650BU	38	6F657801			MOTORGEAR O-RING
TANACOM 500(U)	F5650BU	39	6G087801			MOTOR CASE PLATE
TANACOM 500(U)	F5650BU	40	6F274501			MOTOR CASE PLATE O-RING
TANACOM 500(U)	F5650BU	41	6F466601			MOTOR CASE RING
TANACOM 500(U)	F5650BU	42	6B738001			MOTOR CASE BEARING
TANACOM 500(U)	F5650BU	43	6G087501			MOTOR GEAR(D)
TANACOM 500(U)	F5650BU	44	63208702			MOTOR GEAR(D) RETAINER
TANACOM 500(U)	F5650BU	45	6G580701			LEVEL WIND AS
TANACOM 500(U)	F5650BU	46	61220602			PAWL
TANACOM 500(U)	F5650BU	47	6F950201			PAWL WASHER
TANACOM 500(U)	F5650BU	48	6E354101			PAWL HOLDER NUT
TANACOM 500(U)	F5650BU	49	6G580801			WORM SHAFT
TANACOM 500(U)	F5650BU	50	63716904			WORM SHAFT WASHER
TANACOM 500(U)	F5650BU	51	6F658201			WORM SHAFT GEAR
TANACOM 500(U)	F5650BU	52	63205901			WORM SHAFT GEAR RETAINER
TANACOM 500(U)	F5650BU	53	6F467201			WORM SHAFT BUSH(L)
TANACOM 500(U)	F5650BU	54	6F467301			WORM SHIELD
TANACOM 500(U)	F5650BU	55	6F467201			WORM SHAFT BUSH(R)
TANACOM 500(U)	F5650BU	56	6B411702			WORM SHAFT HOLDER WASHER
TANACOM 500(U)	F5650BU	57	63205901			WORM SHAFT RETAINER
TANACOM 500(U)	F5650BU	58	6F467401			LEVEL WIND POST
TANACOM 500(U)	F5650BU	59	6B864101			LEVEL WIND POST RETAINER
TANACOM 500(U)	F5650BU	60	6F716101			GEAR SHAFT BUSH
TANACOM 500(U)	F5650BU	61	6F725501			GEAR SHAFT
TANACOM 500(U)	F5650BU	62	6F481201			GEAR SHAFT COLLAR
TANACOM 500(U)	F5650BU	63	63207601			GEAR SHAFT RETAINER
TANACOM 500(U)	F5650BU	64	6F541701			FRAME SCREW
TANACOM 500(U)	F5650BU	65	6F467601			FRAME SCREW
TANACOM 500(U)	F5650BU	66	6F467602			FRAME SCREW
TANACOM 500(U)	F5650BU	67	6F467726			FINGER GUARD
TANACOM 500(U)	F5650BU	68	6F467801			SLIDE PLATE
TANACOM 500(U)	F5650BU	69	6E252102			CLUTCH PLATE
TANACOM 500(U)	F5650BU	70	6G581201			PINION
TANACOM 500(U)	F5650BU	71	6F935201			CLUTCH SPRING
TANACOM 500(U)	F5650BU	72	6F673401			STOPPER SPRING
TANACOM 500(U)	F5650BU	73	6F468101			STOPPER
TANACOM 500(U)	F5650BU	74	6F658701			STOPPER SCREW
TANACOM 500(U)	F5650BU	75	6E290801			RATCHET
TANACOM 500(U)	F5650BU	76	63746604			RATCHET WASHER
TANACOM 500(U)	F5650BU	77	6F657801			DRIVE GEAR O-RING
TANACOM 500(U)	F5650BU	78	6F725601			DRIVE GEAR
TANACOM 500(U)	F5650BU	79	6F659302			DRAG WASHER
TANACOM 500(U)	F5650BU	80	6F659404			DRAG LIP WASHER
TANACOM 500(U)	F5650BU	81	6F659505			DRAG DISC WASHER
TANACOM 500(U)	F5650BU	82	6F657801			DRIVE GEAR O-RING
TANACOM 500(U)	F5650BU	83	6F659601			DRAG PACKING
TANACOM 500(U)	F5650BU	84	6F659701			DRAG COLLAR(A)
TANACOM 500(U)	F5650BU	85	6F659801			DRAG COLLAR(B)
TANACOM 500(U)	F5650BU	86	6J415301			RS PLATE
TANACOM 500(U)	F5650BU	87	6F469006			CLUTCH LEVER
TANACOM 500(U)	F5650BU	88	6F469201			CLUTCH CAM
TANACOM 500(U)	F5650BU	89	6G341101			CLUTCH CAM SPRING

TANACOM 500(U)	F5650BU	90	61608001		CLUTCH CAM WASHER
TANACOM 500(U)	F5650BU	91	63538212		CLUTCH CAM SCREW
TANACOM 500(U)	F5650BU	92	6E286001		LINE STOPPER
TANACOM 500(U)	F5650BU	93	6F469620		FINGER COVER
TANACOM 500(U)	F5650BU	94	6G876302		RS PLATE SCREW
TANACOM 500(U)	F5650BU	95	6F285901		POWER LEVER WASHER
TANACOM 500(U)	F5650BU	96	6F303102		POWER LEVER NUT(A)
TANACOM 500(U)	F5650BU	97	6F429702		POWER LEVER
TANACOM 500(U)	F5650BU	98	63424004		POWER LEVER NUT(B)
TANACOM 500(U)	F5650BU	99	6F430005		POWER LEVER COVER
TANACOM 500(U)	F5650BU	100	6F673601		DRAG SPRING WASHER
TANACOM 500(U)	F5650BU	101	6F470002		DRAG HOLDER
TANACOM 500(U)	F5650BU	102	6B747702		DRAG HOLDER LEAF SPRING
TANACOM 500(U)	F5650BU	103	6F470101		STAR DRAG WASHER
TANACOM 500(U)	F5650BU	104	6F470209		STAR DRAG
TANACOM 500(U)	F5650BU	105	6H636501		HANDLE COLLAR
TANACOM 500(U)	F5650BU	106	6J415401		HANDLE AS
TANACOM 500(U)	F5650BU	107	6B862102		HANDLE NUT
TANACOM 500(U)	F5650BU	108	6F471205		HANDLE CAP
TANACOM 500(U)	F5650BU	109	6F661001		CONNECTER CAP
TANACOM 500(U)	F5650BU	110	6G868701		CODE
TANACOM 500(U)	F5650BU	111	6F682601		SPOOL BRAKES WASHER
TANACOM 500(U)	F5650BU	112	6F462201		SET PLATE
TANACOM 500(U)	F5650BU	113	6F540701		IDLE GEAR(A)COLLAR
TANACOM 500(U)	F5650BU	114	6F462301		IDEL GEAR(A)
TANACOM 500(U)	F5650BU	115	6F113401		IDEL GEAR(A) SCREW
TANACOM 500(U)	F5650BU	116	6F462404		SET PLATE GEAR
TANACOM 500(U)	F5650BU	117	6F462701		IDLE GEAR(B)COLLAR
TANACOM 500(U)	F5650BU	118	6F462802		IDEL GEAR(B)
TANACOM 500(U)	F5650BU	119	6B864101		IDEL GEAR(B) RETAINER
TANACOM 500(U)	F5650BU	120	6H080501		SET PLATE SCREW
TANACOM 500(U)	F5650BU	121	6G905401		FERRITE CORE