


F566PA1	TANACOM 750(A)
F566QE1	TANACOM 750(E)
F566QT1	TANACOM 750(T)
F566RJ1	TANACOM 750(J)



REEL NAME	MGFT CODE	KEY NO	PARTS CODE		LATEST PARTS CODE	DESCRIPTION
TANACOM 750(E)	F566QE1	1	6J103601			SIDE PLATE(L) AS
TANACOM 750(E)	F566QE1	2	6E096504			WASHER
TANACOM 750(E)	F566QE1	3	6H439801			COLLAR
TANACOM 750(E)	F566QE1	4	6H439901			GEAR
TANACOM 750(E)	F566QE1	5	6F571902			WASHER
TANACOM 750(E)	F566QE1	6	63517706			SCREW
TANACOM 750(E)	F566QE1	7	6E033201			LEAF SPRING
TANACOM 750(E)	F566QE1	8	6E489622			SCREW
TANACOM 750(E)	F566QE1	9	63205901			RETAINER
TANACOM 750(E)	F566QE1	10	6G225103			WASHER
TANACOM 750(E)	F566QE1	11	6F673802			WASHER
TANACOM 750(E)	F566QE1	12	6G225201			GEAR
TANACOM 750(E)	F566QE1	13	6G070301			BALL BEARING
TANACOM 750(E)	F566QE1	14	6G070201			RING
TANACOM 750(E)	F566QE1	15	63538207			SCREW
TANACOM 750(E)	F566QE1	16	66372102			BALL BEARING
TANACOM 750(E)	F566QE1	17	66375601			BEARING
TANACOM 750(E)	F566QE1	18	6B411703			WASHER
TANACOM 750(E)	F566QE1	19	6G780603			SPOOL AS
TANACOM 750(E)	F566QE1	20	6G225601			MAIN SHAFT
TANACOM 750(E)	F566QE1	21	63716906			WASHER
TANACOM 750(E)	F566QE1	22	6F817101			BEARING
TANACOM 750(E)	F566QE1	23	6G126402			GEAR
TANACOM 750(E)	F566QE1	24	6G126501			RETAINER
TANACOM 750(E)	F566QE1	25	63754102			WASHER
TANACOM 750(E)	F566QE1	26	6G126602			METAL AS

TANACOM 750(E)	F566QE1	27	6F594001			COLLAR
TANACOM 750(E)	F566QE1	28	6F594101			PLATE
TANACOM 750(E)	F566QE1	29	6F206901			SCREW
TANACOM 750(E)	F566QE1	30	66366403			BALL BEARING
TANACOM 750(E)	F566QE1	31	6G225701			GEAR
TANACOM 750(E)	F566QE1	32	63201611			RETAINER
TANACOM 750(E)	F566QE1	33	6F682601			WASHER
TANACOM 750(E)	F566QE1	34	6F389102			BALL BEARING
TANACOM 750(E)	F566QE1	35	6G988901			FRAME AS
TANACOM 750(E)	F566QE1	36	6G488801			O-RING
TANACOM 750(E)	F566QE1	37	6G810402			MOTOR AS
TANACOM 750(E)	F566QE1	38	6F701101			SCREW
TANACOM 750(E)	F566QE1	39	6F701201			WASHER
TANACOM 750(E)	F566QE1	40	6F595101			MOTOR HOLDER AS
TANACOM 750(E)	F566QE1	43	6F595301			O-RING
TANACOM 750(E)	F566QE1	44	63516101			TRUSS SCREW
TANACOM 750(E)	F566QE1	45	6F714601			PACKING
TANACOM 750(E)	F566QE1	46	6G141302			METAL AS
TANACOM 750(E)	F566QE1	47	6F714801			O-RING
TANACOM 750(E)	F566QE1	48	6F739601			PLATE
TANACOM 750(E)	F566QE1	49	6F595801			O-RING
TANACOM 750(E)	F566QE1	50	6F595901			RING
TANACOM 750(E)	F566QE1	51	6F739701			BEARING
TANACOM 750(E)	F566QE1	52	6G225701			GEAR
TANACOM 750(E)	F566QE1	53	63201611			RETAINER
TANACOM 750(E)	F566QE1	54	6G812101			LEVEL WIND AS
TANACOM 750(E)	F566QE1	55	61220602			PIN
TANACOM 750(E)	F566QE1	56	6F950201			WASHER
TANACOM 750(E)	F566QE1	57	6E354101			NUT
TANACOM 750(E)	F566QE1	58	6G834701			WORM SHAFT AS
TANACOM 750(E)	F566QE1	59	6F596501			PIPE
TANACOM 750(E)	F566QE1	60	6F467201			COLLAR
TANACOM 750(E)	F566QE1	61	6B411706			WASHER
TANACOM 750(E)	F566QE1	62	63205901			RETAINER
TANACOM 750(E)	F566QE1	63	6F596601			PILLAR
TANACOM 750(E)	F566QE1	64	6B864101			RETAINER
TANACOM 750(E)	F566QE1	65	6E252501			BUSH
TANACOM 750(E)	F566QE1	66	6F715303			GEAR SHAFT
TANACOM 750(E)	F566QE1	67	6F657801			O-RING
TANACOM 750(E)	F566QE1	68	63755801			WASHER
TANACOM 750(E)	F566QE1	69	63207601			RETAINER
TANACOM 750(E)	F566QE1	70	6F596907			MOTOR COVER
TANACOM 750(E)	F566QE1	71	6F556501			SCREW
TANACOM 750(E)	F566QE1	72	6F639701			SCREW
TANACOM 750(E)	F566QE1	73	6F597001			SLIDE PLATE
TANACOM 750(E)	F566QE1	74	6E290601			CLUCH PLATE
TANACOM 750(E)	F566QE1	75	6F740201			PINION
TANACOM 750(E)	F566QE1	76	6G127001			SPRING
TANACOM 750(E)	F566QE1	77	6F773001			PIN
TANACOM 750(E)	F566QE1	78	6F608301			SPRING
TANACOM 750(E)	F566QE1	79	6F597201			STOPPER
TANACOM 750(E)	F566QE1	80	6F597301			RATCHET AS
TANACOM 750(E)	F566QE1	81	63746604			WASHER
TANACOM 750(E)	F566QE1	82	6G812001			DRIVE GEAR
TANACOM 750(E)	F566QE1	83	6B360212			WASHER
TANACOM 750(E)	F566QE1	84	63723833			WASHER

TANACOM 750(E)	F566QE1	85	6B360302		WASHER
TANACOM 750(E)	F566QE1	86	6F817001		PACKING
TANACOM 750(E)	F566QE1	87	6F657801		O-RING
TANACOM 750(E)	F566QE1	88	6G829001		COLLAR
TANACOM 750(E)	F566QE1	89	6F715601		BEARING
TANACOM 750(E)	F566QE1	90	6F597610		FINGER GUARD
TANACOM 750(E)	F566QE1	91	6H992801		SIDE PLATE(R) AS
TANACOM 750(E)	F566QE1	92	6F469006		LEVER
TANACOM 750(E)	F566QE1	93	6F597901		PLATE AS
TANACOM 750(E)	F566QE1	94	6F598201		SPRING
TANACOM 750(E)	F566QE1	95	61608001		SPRING WASHER
TANACOM 750(E)	F566QE1	96	63538212		SCREW
TANACOM 750(E)	F566QE1	97	6E286001		LINE STOPPER
TANACOM 750(E)	F566QE1	98	63538705		SCREW
TANACOM 750(E)	F566QE1	99	6F598301		SCREW
TANACOM 750(E)	F566QE1	100	6F285901		SPRING WASHER
TANACOM 750(E)	F566QE1	101	6F303102		NUT
TANACOM 750(E)	F566QE1	102	6F429701		LEVER AS
TANACOM 750(E)	F566QE1	103	63424004		NUT
TANACOM 750(E)	F566QE1	104	6F430002		CAP
TANACOM 750(E)	F566QE1	105	6E253501		SPRING WASHER
TANACOM 750(E)	F566QE1	106	6F470002		CAP
TANACOM 750(E)	F566QE1	107	6B747702		LEAF SPRING
TANACOM 750(E)	F566QE1	108	6F470101		WASHER
TANACOM 750(E)	F566QE1	109	6F550415		STAR DRAG
TANACOM 750(E)	F566QE1	110	6H636501		COLLAR
TANACOM 750(E)	F566QE1	111	6H991801		HANDLE AS
TANACOM 750(E)	F566QE1	112	6B862102		NUT
TANACOM 750(E)	F566QE1	113	6F471205		CAP
TANACOM 750(E)	F566QE1	114	6F661002		CAP
TANACOM 750(E)	F566QE1	115	6G868701		ELECTRIC POWER CORD
TANACOM 750(E)	F566QE1	116	6G905401		FERRITE CORE
TANACOM 750(E)	F566QE1	200	6F187601		BOLT
TANACOM 750(E)	F566QE1	201	6F187801		NUT
TANACOM 750(E)	F566QE1	202	60415601		PLATE
TANACOM 750(E)	F566QE1	203	6F187701		NUT
TANACOM 750(E)	F566QE1	204	6X090801		LINE FEEDER
TANACOM 750(E)	F566QE1	1	6J103601		SIDE PLATE(L) AS
TANACOM 750(E)	F566QE1	2	6E096504		WASHER
TANACOM 750(E)	F566QE1	3	6H439801		COLLAR
TANACOM 750(E)	F566QE1	4	6H439901		GEAR
TANACOM 750(E)	F566QE1	5	6F571902		WASHER
TANACOM 750(E)	F566QE1	6	63517706		SCREW
TANACOM 750(E)	F566QE1	7	6E033201		LEAF SPRING
TANACOM 750(E)	F566QE1	8	6E489622		SCREW
TANACOM 750(E)	F566QE1	9	63205901		RETAINER
TANACOM 750(E)	F566QE1	10	6G225103		WASHER
TANACOM 750(E)	F566QE1	11	6F673802		WASHER
TANACOM 750(E)	F566QE1	12	6G225201		GEAR
TANACOM 750(E)	F566QE1	13	6G070301		BALL BEARING
TANACOM 750(E)	F566QE1	14	6G070201		RING
TANACOM 750(E)	F566QE1	15	63538207		SCREW
TANACOM 750(E)	F566QE1	16	66372102		BALL BEARING
TANACOM 750(E)	F566QE1	17	66375601		BEARING
TANACOM 750(E)	F566QE1	18	6B411703		WASHER
TANACOM 750(E)	F566QE1	19	6G780603		SPOOL AS

TANACOM 750(E)	F566QE1	20	6G225601		MAIN SHAFT
TANACOM 750(E)	F566QE1	21	63716906		WASHER
TANACOM 750(E)	F566QE1	22	6F817101		BEARING
TANACOM 750(E)	F566QE1	23	6G126402		GEAR
TANACOM 750(E)	F566QE1	24	6G126501		RETAINER
TANACOM 750(E)	F566QE1	25	63754102		WASHER
TANACOM 750(E)	F566QE1	26	6G126602		METAL AS
TANACOM 750(E)	F566QE1	27	6F594001		COLLAR
TANACOM 750(E)	F566QE1	28	6F594101		PLATE
TANACOM 750(E)	F566QE1	29	6F206901		SCREW
TANACOM 750(E)	F566QE1	30	66366403		BALL BEARING
TANACOM 750(E)	F566QE1	31	6G225701		GEAR
TANACOM 750(E)	F566QE1	32	63201611		RETAINER
TANACOM 750(E)	F566QE1	33	6F682601		WASHER
TANACOM 750(E)	F566QE1	34	6F389102		BALL BEARING
TANACOM 750(E)	F566QE1	35	6G988901		FRAME AS
TANACOM 750(E)	F566QE1	36	6G488801		O-RING
TANACOM 750(E)	F566QE1	37	6G810402		MOTOR AS
TANACOM 750(E)	F566QE1	38	6F701101		SCREW
TANACOM 750(E)	F566QE1	39	6F701201		WASHER
TANACOM 750(E)	F566QE1	40	6F595101		MOTOR HOLDER AS
TANACOM 750(E)	F566QE1	43	6F595301		O-RING
TANACOM 750(E)	F566QE1	44	63516101		TRUSS SCREW
TANACOM 750(E)	F566QE1	45	6F714601		PACKING
TANACOM 750(E)	F566QE1	46	6G141302		METAL AS
TANACOM 750(E)	F566QE1	47	6F714801		O-RING
TANACOM 750(E)	F566QE1	48	6F739601		PLATE
TANACOM 750(E)	F566QE1	49	6F595801		O-RING
TANACOM 750(E)	F566QE1	50	6F595901		RING
TANACOM 750(E)	F566QE1	51	6F739701		BEARING
TANACOM 750(E)	F566QE1	52	6G225701		GEAR
TANACOM 750(E)	F566QE1	53	63201611		RETAINER
TANACOM 750(E)	F566QE1	54	6G812101		LEVEL WIND AS
TANACOM 750(E)	F566QE1	55	61220602		PIN
TANACOM 750(E)	F566QE1	56	6F950201		WASHER
TANACOM 750(E)	F566QE1	57	6E354101		NUT
TANACOM 750(E)	F566QE1	58	6G834701		WORM SHAFT AS
TANACOM 750(E)	F566QE1	59	6F596501		PIPE
TANACOM 750(E)	F566QE1	60	6F467201		COLLAR
TANACOM 750(E)	F566QE1	61	6B411706		WASHER
TANACOM 750(E)	F566QE1	62	63205901		RETAINER
TANACOM 750(E)	F566QE1	63	6F596601		PILLAR
TANACOM 750(E)	F566QE1	64	6B864101		RETAINER
TANACOM 750(E)	F566QE1	65	6E252501		BUSH

TANACOM 750(E)	F566QE1	66	6F715303		GEAR SHAFT
TANACOM 750(E)	F566QE1	67	6F657801		O-RING
TANACOM 750(E)	F566QE1	68	63755801		WASHER
TANACOM 750(E)	F566QE1	69	63207601		RETAINER
TANACOM 750(E)	F566QE1	70	6F596907		MOTOR COVER
TANACOM 750(E)	F566QE1	71	6F556501		SCREW
TANACOM 750(E)	F566QE1	72	6F639701		SCREW
TANACOM 750(E)	F566QE1	73	6F597001		SLIDE PLATE
TANACOM 750(E)	F566QE1	74	6E290601		CLUCH PLATE
TANACOM 750(E)	F566QE1	75	6F740201		PINION
TANACOM 750(E)	F566QE1	76	6G127001		SPRING
TANACOM 750(E)	F566QE1	77	6F773001		PIN
TANACOM 750(E)	F566QE1	78	6F608301		SPRING
TANACOM 750(E)	F566QE1	79	6F597201		STOPPER
TANACOM 750(E)	F566QE1	80	6F597301		RATCHET AS
TANACOM 750(E)	F566QE1	81	63746604		WASHER
TANACOM 750(E)	F566QE1	82	6G812001		DRIVE GEAR
TANACOM 750(E)	F566QE1	83	6B360212		WASHER
TANACOM 750(E)	F566QE1	84	63723833		WASHER
TANACOM 750(E)	F566QE1	85	6B360302		WASHER
TANACOM 750(E)	F566QE1	86	6F817001		PACKING
TANACOM 750(E)	F566QE1	87	6F657801		O-RING
TANACOM 750(E)	F566QE1	88	6G829001		COLLAR
TANACOM 750(E)	F566QE1	89	6F715601		BEARING
TANACOM 750(E)	F566QE1	90	6F597610		FINGER GUARD
TANACOM 750(E)	F566QE1	91	6H992801		SIDE PLATE(R) AS
TANACOM 750(E)	F566QE1	92	6F469006		LEVER
TANACOM 750(E)	F566QE1	93	6F597901		PLATE AS
TANACOM 750(E)	F566QE1	94	6F598201		SPRING
TANACOM 750(E)	F566QE1	95	61608001		SPRING WASHER
TANACOM 750(E)	F566QE1	96	63538212		SCREW
TANACOM 750(E)	F566QE1	97	6E286001		LINE STOPPER
TANACOM 750(E)	F566QE1	98	63538705		SCREW
TANACOM 750(E)	F566QE1	99	6F598301		SCREW
TANACOM 750(E)	F566QE1	100	6F285901		SPRING WASHER
TANACOM 750(E)	F566QE1	101	6F303102		NUT
TANACOM 750(E)	F566QE1	102	6F429701		LEVER AS
TANACOM 750(E)	F566QE1	103	63424004		NUT
TANACOM 750(E)	F566QE1	104	6F430002		CAP
TANACOM 750(E)	F566QE1	105	6E253501		SPRING WASHER
TANACOM 750(E)	F566QE1	106	6F470002		CAP
TANACOM 750(E)	F566QE1	107	6B747702		LEAF SPRING
TANACOM 750(E)	F566QE1	108	6F470101		WASHER
TANACOM 750(E)	F566QE1	109	6F550415		STAR DRAG
TANACOM 750(E)	F566QE1	110	6H636501		COLLAR
TANACOM 750(E)	F566QE1	111	6H991801		HANDLE AS
TANACOM 750(E)	F566QE1	112	6B862102		NUT
TANACOM 750(E)	F566QE1	113	6F471205		CAP
TANACOM 750(E)	F566QE1	114	6F661002		CAP
TANACOM 750(E)	F566QE1	115	6G868701		ELECTRIC POWER CORD
TANACOM 750(E)	F566QE1	116	6G905401		FERRITE CORE
TANACOM 750(E)	F566QE1	200	6F187601		BOLT
TANACOM 750(E)	F566QE1	201	6F187801		NUT
TANACOM 750(E)	F566QE1	202	60415601		PLATE
TANACOM 750(E)	F566QE1	203	6F187701		NUT
TANACOM 750(E)	F566QE1	204	6X090801		LINE FEEDER