SALTIST MQ 6000D H

Si prega di ordinare le parti di ricambio esclusivamente mediante il codice denominato **Parts Code**. Si ricorda inoltre che la vendita delle parti di ricambio viene effettuata esclusivamente tramite distributori ufficiali Daiwa.

©Daiwa Italy



DI CODE	ReelName	KeyNo	PartsCode	Description	VENDIBILI	Parts RRP
21SALMQ6000DH	SALTIST MQ 6000DH	1	6J961701	DRAG KNOB	○	18,00
21SALMQ6000DH	SALTIST MQ 6000DH	2	61704101	DRAG WASHER RETAINER	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	3	6J979901	DRAG KNOB WASHER	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	4	6J577501	KEY WASHER	○	4,00
21SALMQ6000DH	SALTIST MQ 6000DH	5	6J577203	DRAG WASHER	○	6,00
21SALMQ6000DH	SALTIST MQ 6000DH	6	6J577301	EARED WASHER	○	4,00
21SALMQ6000DH	SALTIST MQ 6000DH	7	6J568601	LINE STOPPER PLATE	○	2,00
21SALMQ6000DH	SALTIST MQ 6000DH	8	6J558001	LINE STOPPER	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	9	6J314801	LINE STOPPER SPRING	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	10	6M170701	SPOOL ASSY	○	69,78
21SALMQ6000DH	SALTIST MQ 6000DH	11	6M005501	SPOOL BEARING WASHER (A)	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	12	6G466206	SPOOL BALL BEARING (A)	○	6,00
21SALMQ6000DH	SALTIST MQ 6000DH	13	6E096505	SPOOL BEARING WASHER (B)	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	14	6F050104	SPOOL WASHER (A)	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	15	6F050002	SPOOL WASHER (B)	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	16	6M069601	CLICK SPRING HOLDER	○	2,00
21SALMQ6000DH	SALTIST MQ 6000DH	17	6B747701	CLICK LEAF SPRING	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	18	6F049901	SPOOL WASHER (C)	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	19	6H995201	ROTOR NUT PACKING	○	2,00
21SALMQ6000DH	SALTIST MQ 6000DH	20	6M057201	ROTOR NUT	○	6,00
21SALMQ6000DH	SALTIST MQ 6000DH	21	6G162401	ROTOR NUT O RING	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	22	6H417701	ROTOR COVER SCREW	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	23	6J964501	ROTOR COVER	○	2,00
21SALMQ6000DH	SALTIST MQ 6000DH	24	6H620203	ROTOR		27,91
21SALMQ6000DH	SALTIST MQ 6000DH	25	6H620701	ARM LEVER COVER	○	6,00
21SALMQ6000DH	SALTIST MQ 6000DH	26	6H503901	ARM LEVER COVER SCREW	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	27	6H620401	ROTOR BRAKE SPRING	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	28	6G685401	ROTOR BRAKE WASHER	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	29	6H620301	ROTOR BRAKE SHAFT	○	4,00
21SALMQ6000DH	SALTIST MQ 6000DH	30	6H620501	ARM LEVER SHAFT HOLDER	○	2,00
21SALMQ6000DH	SALTIST MQ 6000DH	31	6H736301	ARM LEVER SPRING	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	32	6G017503	ARM LEVER SHAFT	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	33	6H620605	ARM LEVER	○	9,00
21SALMQ6000DH	SALTIST MQ 6000DH	34	6H638403	RETAINING SCREW	○	4,00
21SALMQ6000DH	SALTIST MQ 6000DH	35	6H503701	ARM LEVER SCREW	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	36	6H504701	ROLLER SCREW	○	2,00
21SALMQ6000DH	SALTIST MQ 6000DH	37	6E096501	ROLLER WASHER	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	38	6M162701	ROLLER COLLAR (A)	○	4,00
21SALMQ6000DH	SALTIST MQ 6000DH	39	6M162801	ROLLER COLLAR (B)	○	6,00
21SALMQ6000DH	SALTIST MQ 6000DH	40	6J186601	LINE ROLLER	○	6,00
21SALMQ6000DH	SALTIST MQ 6000DH	41	6J186501	ROLLER COLLAR (C)	○	2,00
21SALMQ6000DH	SALTIST MQ 6000DH	42	6J192901	ROLLER COLLAR (D)	○	2,00
21SALMQ6000DH	SALTIST MQ 6000DH	43	6H620801	BAIL	○	56,00
21SALMQ6000DH	SALTIST MQ 6000DH	44	6H503701	BAIL HOLDER SCREW	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	45	6J961602	MAGSEALED CAP		9,00
21SALMQ6000DH	SALTIST MQ 6000DH	46	6M170401	MAGSEALED PLATE		9,00
21SALMQ6000DH	SALTIST MQ 6000DH	47	6M175401	MAGSEALED CAP O RING		1,00

DI CODE	ReelName	KeyNo	PartsCode	Description	VENDIBILI	Parts RRP
21SALMQ6000DH	SALTIST MQ 6000DH	48	6M170601	MAGSEALED COLLAR		6,00
21SALMQ6000DH	SALTIST MQ 6000DH	49	6J309101	ONEWAY CLUTCH		12,00
21SALMQ6000DH	SALTIST MQ 6000DH	50	6J690501	CLUTCH RING		12,00
21SALMQ6000DH	SALTIST MQ 6000DH	51	6J020801	BEARING PLATE		2,00
21SALMQ6000DH	SALTIST MQ 6000DH	52	6J000901	BEARING PLATE SCREW		1,00
21SALMQ6000DH	SALTIST MQ 6000DH	53	6G522802	PINION BALL BEARING (A)		6,00
21SALMQ6000DH	SALTIST MQ 6000DH	54	63712824	PINION BEARING (A) WASHER01mm		1,00
21SALMQ6000DH	SALTIST MQ 6000DH	55	6M057101	PINION COLLAR		4,00
21SALMQ6000DH	SALTIST MQ 6000DH	56	6Z025299	PINION DRIVE GEAR SET		41,87
21SALMQ6000DH	SALTIST MQ 6000DH	57	6G572501	PINION WASHER		1,00
21SALMQ6000DH	SALTIST MQ 6000DH	58	6G467102	PINION BALL BEARING (B)		6,00
21SALMQ6000DH	SALTIST MQ 6000DH	59	6J428101	PINION BEARING (B) COLLAR		4,00
21SALMQ6000DH	SALTIST MQ 6000DH	60	6J964001	ROTOR BRAKE RING		4,00
21SALMQ6000DH	SALTIST MQ 6000DH	61	6M170201	BODY		55,83
21SALMQ6000DH	SALTIST MQ 6000DH	62	6J960201	MAIN SHAFT		9,00
21SALMQ6000DH	SALTIST MQ 6000DH	63	6H614301	OSCILLATING POST		1,00
21SALMQ6000DH	SALTIST MQ 6000DH	64	6J960901	REAR COVER PACKING		4,00
21SALMQ6000DH	SALTIST MQ 6000DH	65	6J961001	REAR COVER		6,00
21SALMQ6000DH	SALTIST MQ 6000DH	66	6M056601	REAR COVER SCREW (A)		1,00
21SALMQ6000DH	SALTIST MQ 6000DH	67	6M056602	REAR COVER SCREW (B)		1,00
21SALMQ6000DH	SALTIST MQ 6000DH	68	6G644201	OSCILLATING GEAR WASHER		1,00
21SALMQ6000DH	SALTIST MQ 6000DH	69	6G644302	OSCILLATING GEAR		4,00
21SALMQ6000DH	SALTIST MQ 6000DH	70	6B853101	OSCILLATING GEAR O RING		1,00
21SALMQ6000DH	SALTIST MQ 6000DH	71	6G522103	OSCILLATING BEARING WASHER01mm		1,00
21SALMQ6000DH	SALTIST MQ 6000DH	72	6G467105	OSCILLATING GEAR BALL BEARING		6,00
21SALMQ6000DH	SALTIST MQ 6000DH	73	6H272202	OSCILLATING GEAR SCREW		1,00
21SALMQ6000DH	SALTIST MQ 6000DH	74	6G645301	DRIVE O RING		1,00
21SALMQ6000DH	SALTIST MQ 6000DH	75	63737808	DRIVE BEARING WASHER01mm		1,00
21SALMQ6000DH	SALTIST MQ 6000DH	76	6G523405	DRIVE BALL BEARING (A)		6,00
21SALMQ6000DH	SALTIST MQ 6000DH	77	6H502602	BODY COVER O RING		1,00
21SALMQ6000DH	SALTIST MQ 6000DH	78	6M170301	BODY COVER (L)		27,91
21SALMQ6000DH	SALTIST MQ 6000DH	79	6H730801	BODY COVER PACKING		2,00
21SALMQ6000DH	SALTIST MQ 6000DH	80	6M170901	HANDLE ASSY	○	56,00
21SALMQ6000DH	SALTIST MQ 6000DH	81	6B861704	DRIVE BALL BEARING (B)		6,00
21SALMQ6000DH	SALTIST MQ 6000DH	82	6G525101	DRIVE BEARING RETAINER		1,00
21SALMQ6000DH	SALTIST MQ 6000DH	83	6G672401	HANDLE CAP O RING	○	1,00
21SALMQ6000DH	SALTIST MQ 6000DH	84	6J964101	HANDLE CAP	○	6,00